



Low Level Reader Protocol (LLRP), Version 1.0.1

Ratified Standard with Approved Fixed Errata

August 13, 2007

Disclaimer

EPCglobal Inc™ is providing this document as a service to interested industries. This document was developed through a consensus process of interested parties.

Although efforts have been to assure that the document is correct, reliable, and technically accurate, EPCglobal Inc makes NO WARRANTY, EXPRESS OR IMPLIED, THAT THIS DOCUMENT IS CORRECT, WILL NOT REQUIRE MODIFICATION AS EXPERIENCE AND TECHNOLOGICAL ADVANCES DICTATE, OR WILL BE SUITABLE FOR ANY PURPOSE OR WORKABLE IN ANY APPLICATION, OR OTHERWISE. Use of this document is with the understanding that EPCglobal Inc has no liability for any claim to the contrary, or for any damage or loss of any kind or nature.

Copyright notice

© 2006, 2007, EPCglobal Inc.

All rights reserved. Unauthorized reproduction, modification, and/or use of this document is not permitted. Requests for permission to reproduce should be addressed to epcglobal@epcglobalinc.org.

EPCglobal Inc.™ is providing this document as a service to interested industries. This document was developed through a consensus process of interested parties. Although efforts have been to assure that the document is correct, reliable, and technically accurate, EPCglobal Inc. makes NO WARRANTY, EXPRESS OR IMPLIED, THAT THIS DOCUMENT IS CORRECT, WILL NOT REQUIRE MODIFICATION AS EXPERIENCE AND TECHNOLOGICAL ADVANCES DICTATE, OR WILL BE SUITABLE FOR ANY PURPOSE OR WORKABLE IN ANY APPLICATION, OR OTHERWISE. Use of this Document is with the understanding that EPCglobal Inc. has no liability for any claim to the contrary, or for any damage or loss of any kind or nature

35 **Abstract**

36 This document specifies an interface between RFID Readers and Clients. The interface
37 protocol is called *low-level* because it provides control of RFID air protocol operation
38 timing and access to air protocol command parameters. The design of this interface
39 recognizes that in some RFID systems, there is a requirement for explicit knowledge of
40 RFID air protocols and the ability to control Readers that implement RFID air protocol
41 communications. It also recognizes that coupling control to the physical layers of an
42 RFID infrastructure may be useful for the purpose of mitigating RFID interference.

43 **Audience for this document**

44 The target audience for this specification includes:

45 RFID Network Infrastructure vendors

46 Reader vendors

47 EPC Middleware vendors

48 System integrators

49 **Status of this document**

50 This section describes the status of this document at the time of its publication. Other
51 documents may supersede this document. The latest status of this document series is
52 maintained at EPCglobal. See www.epcglobalinc.org for more information.

53 This draft fixes errata in version 1.0 of LLRP that was ratified on April 12, 2007. A
54 summary of the fixed errata is contained in the table below. Note that Section and Line
55 numbers referenced are per version 1 of LLRP. Line numbers may be slightly different in
56 this version 1.0.1.

57 Comments on this document should be sent to the EPCglobal Software Action Group
58 Reader Operations Working Group mailing list at
59 sag_readerop@epclinklist.epcglobalinc.org.

60 **Fixed Errata**

Section#	Line #	Description	Disposition
16.2.3.4.1	2921	It should be a generic UHF RFModeTable Parameter (1-n) with Notes under the parameter that for C1G2 it is UHFC1G2RFModeTable	Replace with UHF RFMode Table Parameter (1-n)
15.2.1.3.1.1	2402	No length field	Remove the length field from the abstract
15.2.1.2.1.1.1	2309	No length field	Remove the length field from the abstract
9.2.1.1	1269	Range of Rx sensitivity	0-128 (relative to max sensitivity)

16.1.2	2593	C1G2LLRPCapabilities should be replaced by AirProtocolLLRPCapabilities Parameter (0-1)	Replace with AirProtocolLLRPCapabilities Parameter (0-1)
9.2.4.1.2.1	1336	This is followed by a list of the frequencies (in Khz) in hop table order. The position of a frequency in the list is its ChannelIndex. (These are used by the hopping event parameter)	This is followed by a list of the frequencies (in Khz) in hop table order. The one-based position of a frequency in the list is its ChannelIndex (i.e. the first frequency is referred to as ChannelIndex 1)
9.2.4.1.2.2	1343	This parameter carries the fixed frequency list that can be used by the Reader. The position of a frequency in the list is its ChannelIndex.	This parameter carries the fixed frequency list that can be used by the Reader. The one-based position of a frequency in the list is its ChannelIndex (i.e. the first frequency is referred to as ChannelIndex 1...)
12.2.6.2, 13.2.3.8, 13.2.6.2	1825, 2013, 2105	TheseChannelIndexes are used by the RfTransmitter Parameter , Channel Index Parameter, HoppingEventParameter	Possibly denote in these usages that they are 1-based
11.1.3	1552	Delete access spec does not allow 0 like all other access spec commands. This is believed to be an errata	Possibly add zero to mean all access specs, as in other access spec commands.
16.2.7.1	3088	Custom parameter is 0-1. All others are 0-N. This is believed to be an errata	Extend this to 0-N to correct errata
16	2535, 2538	Encoding example:: message length is 32 bits, but shown as 16 bits and 32-bit messageID is not shown	Correct figures to match documentation
14.2.2, 16.2.8.1	2215, 3270	The abstract LLRPStatusParameter contains a field called statusCode. The binding references the same field as ErrorCode	Correct binding section to match abstract
16.4	3480	In 16.4, table 5, "ReaderSensitivityTableEntry" should be ReceiveSensitivityTableElement	Change ReaderSensitivity to ReceiveSensitivity
10.2.1, 16.2.4.1	1452, 2947	In 10.2.1, the field "Current State" is listed as the last element of the ROSpec Parameter, the binding lists the same field as the 4th last element.	Change position of "Current State" field in abstract ROSpec Parameter
16.4	3742	ReadEventNotification	Change to ReaderEventNotification
8.2	1194	Possible Values 0-255	Remove possible values. Changed to unsigned integer
6.1	717	An AISpec binds a stop trigger and a set of antennas to a set of InventoryParameterSpecs and is identified by a spec Identifier	Change the spec Identifier to a "one-based index called the SpecIndex"

61

various	various	multiple instances of Khz	Replace with kHz
---------	---------	---------------------------	------------------

62 Contents

63	INDEX OF FIGURES.....	13
64	INDEX OF TABLES.....	14
65	1 (INFORMATIVE) GLOSSARY.....	15
66	2 INTRODUCTION.....	18
67	3 ROLE WITHIN THE EPCGLOBAL NETWORK ARCHITECTURE.....	19
68	4 TERMINOLOGY AND TYPOGRAPHICAL CONVENTIONS.....	21
69	5 OVERVIEW OF LLRP.....	21
70	5.1 TYPICAL LLRP TIMELINE	22
71	6 LLRP OPERATION.....	23
72	6.1 INVENTORY, RF SURVEY AND ACCESS OPERATIONS	23
73	6.1.1 Operation Triggers.....	32
74	6.1.1.1 Summary.....	32
75	6.1.1.2 Reader Operation Triggers.....	33
76	6.1.1.3 Access Operation Triggers.....	34
77	6.2 REPORTING, EVENT NOTIFICATION AND KEEPALIVES.....	34
78	7 MESSAGES, PARAMETERS AND FIELDS	35
79	7.1 OVERVIEW	35
80	7.1.1 Formatting Conventions.....	35
81	7.1.2 Messages.....	36
82	7.1.3 Parameters	37
83	7.1.3.1 General Parameters	37
84	7.1.3.1.1 Timestamp	37
85	7.1.3.1.1.1 UTCTimestamp Parameter	37
86	7.1.3.1.1.2 Uptime Parameter	37
87	7.1.4 Fields.....	38
88	7.1.5 Functional Grouping	38
89	7.1.6 LLRP Messages and Actions	40
90	8 CUSTOM EXTENSION	41
91	8.1 CUSTOM_MESSAGE.....	42
92	8.2 CUSTOM_PARAMETER.....	42
93	8.3 CUSTOM EXTENSION IN COMMANDS.....	42
94	8.4 CUSTOM EXTENSION IN INDIVIDUAL LLRP PARAMETERS	43
95	8.5 ALLOWABLE PARAMETER EXTENSION	43
96	9 READER DEVICE CAPABILITIES.....	43
97	9.1 MESSAGES	44
98	9.1.1 GET_READER_CAPABILITIES	44
99	9.1.2 GET_READER_CAPABILITIES_RESPONSE	44
100	9.2 PARAMETERS	45
101	9.2.1 GeneralDeviceCapabilities Parameter.....	45
102	9.2.1.1 ReceiveSensitivityTableEntry Parameter.....	45
103	9.2.1.2 PerAntennaReceiveSensitivityRange Parameter.....	46
104	9.2.1.3 PerAntennaAirProtocol Parameter.....	46

105	9.2.1.4	GPIOCapabilities Parameter	47
106	9.2.2	LLRPCapabilities Parameter	47
107	9.2.3	AirProtocolLLRPCapabilities Parameter	48
108	9.2.4	RegulatoryCapabilities Parameter	48
109	9.2.4.1	UHFBandCapabilities Parameter	49
110	9.2.4.1.1	TransmitPowerLevelTableEntry Parameter	49
111	9.2.4.1.2	FrequencyInformation Parameter	50
112	9.2.4.1.2.1	FrequencyHopTable Parameter	50
113	9.2.4.1.2.2	FixedFrequencyTable Parameter	50
114	10	READER OPERATION (RO).....	51
115	10.1	MESSAGES	51
116	10.1.1	ADD_ROSPEC	51
117	10.1.2	ADD_ROSPEC_RESPONSE	51
118	10.1.3	DELETE_ROSPEC	52
119	10.1.4	DELETE_ROSPEC_RESPONSE	52
120	10.1.5	START_ROSPEC	52
121	10.1.6	START_ROSPEC_RESPONSE	52
122	10.1.7	STOP_ROSPEC	53
123	10.1.8	STOP_ROSPEC_RESPONSE	53
124	10.1.9	ENABLE_ROSPEC	53
125	10.1.10	ENABLE_ROSPEC_RESPONSE	54
126	10.1.11	DISABLE_ROSPEC	54
127	10.1.12	DISABLE_ROSPEC_RESPONSE	54
128	10.1.13	GET_ROSPECS	54
129	10.1.14	GET_ROSPECS_RESPONSE	55
130	10.2	PARAMETERS	55
131	10.2.1	ROSpec Parameter	55
132	10.2.1.1	ROBoundarySpec Parameter	55
133	10.2.1.1.1	ROSpecStartTrigger Parameter	56
134	10.2.1.1.1.1	PeriodicTriggerValue Parameter	56
135	10.2.1.1.1.2	GPITriggerValue Parameter	57
136	10.2.1.1.2	ROSpecStopTrigger Parameter	57
137	10.2.2	AISpec Parameter	57
138	10.2.2.1	AISpecStopTrigger Parameter	58
139	10.2.2.1.1	TagObservationTrigger Parameter	58
140	10.2.2.2	InventoryParameterSpec Parameter	59
141	10.2.3	RFSurveySpec Parameter	59
142	10.2.3.1	RFSurveySpecStopTrigger Parameter	60
143	11	ACCESS OPERATION.....	60
144	11.1	MESSAGES	60
145	11.1.1	ADD_ACCESSSPEC	60
146	11.1.2	ADD_ACCESSSPEC_RESPONSE	61
147	11.1.3	DELETE_ACCESSSPEC	61
148	11.1.4	DELETE_ACCESSSPEC_RESPONSE	61
149	11.1.5	ENABLE_ACCESSSPEC	62
150	11.1.6	ENABLE_ACCESSSPEC_RESPONSE	62
151	11.1.7	DISABLE_ACCESSSPEC	62
152	11.1.8	DISABLE_ACCESSSPEC_RESPONSE	63
153	11.1.9	GET_ACCESSSPECS	63
154	11.1.10	GET_ACCESSSPECS_RESPONSE	63
155	11.1.11	CLIENT_REQUEST_OP	63
156	11.1.12	CLIENT_REQUEST_OP_RESPONSE	64
157	11.2	PARAMETERS	64
158	11.2.1	AccessSpec Parameter	64
159	11.2.1.1	AccessSpecStopTrigger Parameter	65

160	11.2.1.2	AccessCommand Parameter.....	65
161	11.2.1.2.1	ClientRequestOpSpec Parameter.....	66
162	11.2.2	ClientRequestResponse Parameter.....	66
163	12	READER DEVICE CONFIGURATION	67
164	12.1	MESSAGES	67
165	12.1.1	GET_READER_CONFIG.....	67
166	12.1.2	GET_READER_CONFIG_RESPONSE.....	68
167	12.1.3	SET_READER_CONFIG.....	69
168	12.1.4	SET_READER_CONFIG_RESPONSE.....	70
169	12.1.5	CLOSE_CONNECTION.....	70
170	12.1.6	CLOSE_CONNECTION_RESPONSE.....	71
171	12.2	PARAMETERS	71
172	12.2.1	LLRPConfigurationStateValue Parameter.....	71
173	12.2.2	Identification Parameter.....	72
174	12.2.3	GPOWriteData Parameter.....	72
175	12.2.4	KeepaliveSpec Parameter.....	73
176	12.2.5	AntennaProperties Parameter.....	73
177	12.2.6	AntennaConfiguration Parameter.....	74
178	12.2.6.1	RFReceiver Parameter.....	74
179	12.2.6.2	RFTransmitter Parameter.....	74
180	12.2.6.3	GPIOCurrentState Parameter.....	75
181	12.2.6.4	EventsAndReports Parameter.....	75
182	13	REPORTS, NOTIFICATIONS AND KEEPALIVES	76
183	13.1	MESSAGES	76
184	13.1.1	GET_REPORT.....	76
185	13.1.2	RO_ACCESS_REPORT.....	77
186	13.1.3	KEEPALIVE.....	77
187	13.1.4	KEEPALIVE_ACK.....	77
188	13.1.5	READER_EVENT_NOTIFICATION.....	77
189	13.1.6	ENABLE_EVENTS_AND_REPORTS.....	78
190	13.2	PARAMETERS	78
191	13.2.1	ROReportSpec Parameter.....	78
192	13.2.1.1	TagReportContentSelector Parameter.....	79
193	13.2.2	AccessReportSpec Parameter.....	79
194	13.2.3	TagReportData Parameter.....	80
195	13.2.3.1	Accumulation of TagReportData.....	81
196	13.2.3.2	EPCData Parameter.....	82
197	13.2.3.3	ROSpecID Parameter.....	82
198	13.2.3.4	SpecIndex Parameter.....	82
199	13.2.3.5	InventoryParameterSpecID Parameter.....	83
200	13.2.3.6	AntennaID Parameter.....	83
201	13.2.3.7	PeakRSSI Parameter.....	83
202	13.2.3.8	ChannelIndex Parameter.....	83
203	13.2.3.9	FirstSeenTimestampUTC Parameter.....	83
204	13.2.3.10	FirstSeenTimestampUptime Parameter.....	84
205	13.2.3.11	LastSeenTimestampUTC Parameter.....	84
206	13.2.3.12	LastSeenTimestampUptime Parameter.....	84
207	13.2.3.13	TagSeenCount Parameter.....	84
208	13.2.3.14	ClientRequestOpSpecResult Parameter.....	85
209	13.2.3.15	AccessSpecID Parameter.....	85
210	13.2.4	RFSurveyReportData Parameter.....	85
211	13.2.4.1	FrequencyRSSIlevelEntry Parameter.....	85
212	13.2.5	ReaderEventNotificationSpec Parameter.....	86
213	13.2.5.1	EventNotificationState Parameter.....	86
214	13.2.6	ReaderEventNotificationData Parameter.....	86
215	13.2.6.1	Requirements for Ordering of Event Reporting.....	87

216	13.2.6.2	HoppingEvent Parameter	88
217	13.2.6.3	GPIEvent Parameter.....	88
218	13.2.6.4	ROSpecEvent Parameter	89
219	13.2.6.5	ReportBufferLevelWarningEvent Parameter	89
220	13.2.6.6	ReportBufferOverflowErrorEvent Parameter.....	89
221	13.2.6.7	ReaderExceptionEvent Parameter.....	90
222	13.2.6.7.1	OpSpecID Parameter	90
223	13.2.6.8	RFSurveyEvent Parameter	90
224	13.2.6.9	AIEvent Parameter	91
225	13.2.6.10	AntennaEvent Parameter.....	91
226	13.2.6.11	ConnectionAttemptEvent Parameter	92
227	13.2.6.12	ConnectionCloseEvent Parameter.....	92
228	14	ERRORS.....	92
229	14.1	MESSAGES	93
230	14.1.1	ERROR_MESSAGE	93
231	14.2	PARAMETERS	93
232	14.2.1	LLRP Status Codes	93
233	14.2.2	LLRPStatus Parameter	95
234	14.2.2.1	FieldError Parameter.....	96
235	14.2.2.2	ParameterError Parameter	96
236	15	AIR PROTOCOL SPECIFIC PARAMETERS	97
237	15.1	LLRP AIR PROTOCOL CROSS-REFERENCE TABLES.....	97
238	15.1.1	Class-1 Generation-2 (C1G2) Air Protocol.....	97
239	15.2	LLRP AIR PROTOCOL SPECIFIC PARAMETERS	98
240	15.2.1	Class-1 Generation-2 (C1G2) Air Protocol.....	98
241	15.2.1.1	Reader Device Capabilities	98
242	15.2.1.1.1	C1G2LLRPCapabilities Parameter.....	98
243	15.2.1.1.2	UHFC1G2RFModeTable Parameter.....	98
244	15.2.1.1.2.1	UHFC1G2RFModeTableEntry Parameter.....	99
245	15.2.1.2	Inventory Operation	100
246	15.2.1.2.1	C1G2InventoryCommand Parameter.....	100
247	15.2.1.2.1.1	C1G2Filter Parameter.....	101
248	15.2.1.2.1.1.1	C1G2TagInventoryMask Parameter.....	102
249	15.2.1.2.1.1.2	C1G2TagInventoryStateAwareFilterAction Parameter	102
250	15.2.1.2.1.1.3	C1G2TagInventoryStateUnawareFilterAction Parameter	103
251	15.2.1.2.1.2	C1G2RF Control Parameter	104
252	15.2.1.2.1.3	C1G2SingulationControl Parameter	104
253	15.2.1.2.1.3.1	C1G2TagInventoryStateAwareSingulationAction Parameter	105
254	15.2.1.3	Access Operation	106
255	15.2.1.3.1	C1G2TagSpec Parameter.....	106
256	15.2.1.3.1.1	C1G2TargetTag Parameter.....	106
257	15.2.1.3.2	C1G2 OpSpec Parameters	107
258	15.2.1.3.2.1	C1G2Read Parameter	107
259	15.2.1.3.2.2	C1G2Write Parameter	107
260	15.2.1.3.2.3	C1G2Kill Parameter	108
261	15.2.1.3.2.4	C1G2Lock Parameter	108
262	15.2.1.3.2.4.1	C1G2LockPayload Parameter	109
263	15.2.1.3.2.5	C1G2BlockErase Parameter	109
264	15.2.1.3.2.6	C1G2BlockWrite Parameter.....	110
265	15.2.1.4	Reader Device Configuration.....	110
266	15.2.1.5	Reports.....	110
267	15.2.1.5.1	C1G2EPCMemorySelector Parameter.....	110
268	15.2.1.5.2	C1G2PC Parameter.....	111
269	15.2.1.5.3	C1G2CRC Parameter.....	111
270	15.2.1.5.4	C1G2SingulationDetails Parameter	111
271	15.2.1.5.5	C1G2 OpSpec Results	111
272	15.2.1.5.5.1	C1G2ReadOpSpecResult Parameter.....	111
273	15.2.1.5.5.2	C1G2WriteOpSpecResult Parameter.....	112
274	15.2.1.5.5.3	C1G2KillOpSpecResult Parameter.....	112

275	15.2.1.5.5.4	C1G2LockOpSpecResult Parameter.....	113
276	15.2.1.5.5.5	C1G2BlockEraseOpSpecResult Parameter.....	113
277	15.2.1.5.5.6	C1G2BlockWriteOpSpecResult Parameter	113
278	16	BINARY ENCODING FOR LLRP.....	114
279	16.1	MESSAGES	115
280	16.1.1	GET_READER_CAPABILITIES.....	117
281	16.1.2	GET_READER_CAPABILITIES_RESPONSE	117
282	16.1.3	ADD_ROSPEC	117
283	16.1.4	ADD_ROSPEC_RESPONSE	118
284	16.1.5	DELETE_ROSPEC.....	118
285	16.1.6	DELETE_ROSPEC_RESPONSE.....	118
286	16.1.7	START_ROSPEC	118
287	16.1.8	START_ROSPEC_RESPONSE	119
288	16.1.9	STOP_ROSPEC.....	119
289	16.1.10	STOP_ROSPEC_RESPONSE.....	119
290	16.1.11	ENABLE_ROSPEC.....	119
291	16.1.12	ENABLE_ROSPEC_RESPONSE.....	120
292	16.1.13	DISABLE_ROSPEC.....	120
293	16.1.14	DISABLE_ROSPEC_RESPONSE.....	120
294	16.1.15	GET_ROSPECS.....	120
295	16.1.16	GET_ROSPECS_RESPONSE.....	121
296	16.1.17	ADD_ACCESSSPEC.....	121
297	16.1.18	ADD_ACCESSSPEC_RESPONSE	121
298	16.1.19	DELETE_ACCESSSPEC.....	122
299	16.1.20	DELETE_ACCESSSPEC_RESPONSE.....	122
300	16.1.21	ENABLE_ACCESSSPEC.....	122
301	16.1.22	ENABLE_ACCESSSPEC_RESPONSE.....	122
302	16.1.23	DISABLE_ACCESSSPEC.....	123
303	16.1.24	DISABLE_ACCESSSPEC_RESPONSE.....	123
304	16.1.25	GET_ACCESSSPECS	123
305	16.1.26	GET_ACCESSSPECS_RESPONSE.....	123
306	16.1.27	CLIENT_REQUEST_OP	124
307	16.1.28	CLIENT_REQUEST_OP_RESPONSE	124
308	16.1.29	GET_REPORT.....	124
309	16.1.30	RO_ACCESS_REPORT	125
310	16.1.31	KEEPALIVE.....	125
311	16.1.32	KEEPALIVE_ACK.....	125
312	16.1.33	READER_EVENT_NOTIFICATION	126
313	16.1.34	ENABLE_EVENTS_AND_REPORTS.....	126
314	16.1.35	ERROR_MESSAGE	126
315	16.1.36	GET_READER_CONFIG.....	126
316	16.1.37	GET_READER_CONFIG_RESPONSE.....	127
317	16.1.38	SET_READER_CONFIG.....	127
318	16.1.39	SET_READER_CONFIG_RESPONSE.....	128
319	16.1.40	CLOSE_CONNECTION	128
320	16.1.41	CLOSE_CONNECTION_RESPONSE.....	128
321	16.1.42	CUSTOM_MESSAGE.....	129
322	16.2	LLRP PARAMETERS.....	129
323	16.2.1	TLV and TV Encoding of LLRP Parameter	129
324	16.2.1.1	TLV-Parameters.....	129
325	16.2.1.1.1	Encoding Guidelines for TLV-Parameters.....	130
326	16.2.1.2	TV-Parameters	130
327	16.2.1.2.1	Encoding Guidelines for TV-Parameters	131
328	16.2.2	General Parameters.....	131
329	16.2.2.1	UTCTimestamp Parameter.....	131
330	16.2.2.2	Uptime Parameter	131

331	16.2.3	<i>Reader Device Capabilities Parameters</i>	131
332	16.2.3.1	GeneralDeviceCapabilities Parameter.....	131
333	16.2.3.1.1	ReceiveSensitivityTableEntry Parameter.....	132
334	16.2.3.1.2	PerAntennaReceiveSensitivityRange Parameter.....	132
335	16.2.3.1.3	PerAntennaAirProtocol Parameter.....	132
336	16.2.3.1.4	GPIOCapabilities Parameter.....	133
337	16.2.3.2	LLRPCapabilities Parameter.....	133
338	16.2.3.3	AirProtocolLLRPCapabilities Parameter.....	133
339	16.2.3.4	RegulatoryCapabilities Parameter.....	133
340	16.2.3.4.1	UHFBandCapabilities Parameter.....	134
341	16.2.3.4.1.1	TransmitPowerLevelTableEntry Parameter.....	134
342	16.2.3.4.1.2	FrequencyInformation Parameter.....	134
343	16.2.3.4.1.2.1	FrequencyHopTable Parameter.....	134
344	16.2.3.4.1.2.2	FixedFrequencyTable Parameter.....	135
345	16.2.4	<i>Reader Operations Parameters</i>	135
346	16.2.4.1	ROSpec Parameter.....	135
347	16.2.4.1.1	ROBoundarySpec Parameter.....	135
348	16.2.4.1.1.1	ROSpecStartTrigger Parameter.....	136
349	16.2.4.1.1.1.1	PeriodicTriggerValue Parameter.....	136
350	16.2.4.1.1.1.2	GPITriggerValue Parameter.....	136
351	16.2.4.1.1.2	ROSpecStopTrigger Parameter.....	136
352	16.2.4.2	AISpec Parameter.....	137
353	16.2.4.2.1	AISpecStopTrigger Parameter.....	137
354	16.2.4.2.1.1	TagObservationTrigger Parameter.....	137
355	16.2.4.2.2	InventoryParameterSpec Parameter.....	137
356	16.2.4.3	RFSurveySpec Parameter.....	138
357	16.2.4.3.1	RFSurveySpecStopTrigger Parameter.....	138
358	16.2.5	<i>Access Operation Parameters</i>	138
359	16.2.5.1	AccessSpec Parameter.....	138
360	16.2.5.1.1	AccessSpecStopTrigger Parameter.....	139
361	16.2.5.1.2	AccessCommand Parameter.....	139
362	16.2.5.1.3	ClientRequestOpSpec Parameter.....	139
363	16.2.5.1.3.1	ClientRequestResponse Parameter.....	139
364	16.2.6	<i>Configuration Parameters</i>	140
365	16.2.6.1	LLRPConfigurationStateValue Parameter.....	140
366	16.2.6.2	Identification Parameter.....	140
367	16.2.6.3	GPOWriteData Parameter.....	140
368	16.2.6.4	KeepaliveSpec Parameter.....	140
369	16.2.6.5	AntennaProperties Parameter.....	141
370	16.2.6.6	AntennaConfiguration Parameter.....	141
371	16.2.6.7	RFReceiver Parameter.....	141
372	16.2.6.8	RFTransmitter Parameter.....	141
373	16.2.6.9	GPIOPortCurrentState Parameter.....	142
374	16.2.6.10	EventsAndReports Parameter.....	142
375	16.2.7	<i>Reporting Parameters</i>	142
376	16.2.7.1	ROReportSpec Parameter.....	142
377	16.2.7.1.1	TagReportContentSelector Parameter.....	142
378	16.2.7.2	AccessReportSpec Parameter.....	143
379	16.2.7.3	TagReportData Parameter.....	143
380	16.2.7.3.1	EPCData Parameter.....	144
381	16.2.7.3.2	EPC-96 Parameter (TV-Encoding).....	144
382	16.2.7.3.3	ROSpecID Parameter (TV-Encoding).....	144
383	16.2.7.3.4	SpecIndex Parameter (TV-Encoding).....	145
384	16.2.7.3.5	InventoryParameterSpecID Parameter (TV-Encoding).....	145
385	16.2.7.3.6	AntennaID Parameter (TV-Encoding).....	145
386	16.2.7.3.7	PeakRSSI Parameter (TV-Encoding).....	145
387	16.2.7.3.8	ChannelIndex Parameter (TV-Encoding).....	145
388	16.2.7.3.9	FirstSeenTimestampUTC Parameter (TV-Encoding).....	145
389	16.2.7.3.10	FirstSeenTimestampUptime Parameter (TV-Encoding).....	145
390	16.2.7.3.11	LastSeenTimestampUTC Parameter (TV-Encoding).....	146
391	16.2.7.3.12	LastSeenTimestampUptime Parameter (TV-Encoding).....	146
392	16.2.7.3.13	TagSeenCount Parameter (TV-Encoding).....	146

393	16.2.7.3.14	ClientRequestOpSpecResult Parameter (TV-Encoding)	146
394	16.2.7.3.15	AccessSpecID Parameter (TV-Encoding)	146
395	16.2.7.4	RFSurveyReportData Parameter	147
396	16.2.7.4.1	FrequencyRSSIlevelEntry Parameter	147
397	16.2.7.5	ReaderEventNotificationSpec Parameter	147
398	16.2.7.5.1	EventNotificationState Parameter	148
399	16.2.7.6	ReaderEventNotificationData Parameter	148
400	16.2.7.6.1	HoppingEvent Parameter	148
401	16.2.7.6.2	GPiEvent Parameter	149
402	16.2.7.6.3	ROSpecEvent Parameter	149
403	16.2.7.6.4	ReportBufferLevelWarningEvent Parameter	149
404	16.2.7.6.5	ReportBufferOverflowErrorEvent Parameter	149
405	16.2.7.6.6	ReaderExceptionEvent Parameter	149
406	16.2.7.6.6.1	OpSpecID Parameter (TV-Encoding)	150
407	16.2.7.6.7	RFSurveyEvent Parameter	150
408	16.2.7.6.8	AI SpecEvent Parameter	150
409	16.2.7.6.9	AntennaEvent Parameter	150
410	16.2.7.6.10	ConnectionAttemptEvent Parameter	151
411	16.2.7.6.11	ConnectionCloseEvent Parameter	151
412	16.2.8	LLRP Error Parameters	151
413	16.2.8.1	LLRPStatus Parameter	151
414	16.2.8.1.1	FieldError Parameter	151
415	16.2.8.1.2	ParameterError Parameter	152
416	16.2.9	Custom Parameter	152
417	16.3	AIR PROTOCOL SPECIFIC PARAMETERS	152
418	16.3.1	Class-1 Generation-2 (C1G2) Protocol Parameters	152
419	16.3.1.1	Capabilities Parameters	153
420	16.3.1.1.1	C1G2LLRPCapabilities Parameter	153
421	16.3.1.1.2	UHFC1G2RFModeTable Parameter	153
422	16.3.1.1.2.1	UHFC1G2RFModeTableEntry Parameter	153
423	16.3.1.2	Reader Operations Parameters	154
424	16.3.1.2.1	C1G2InventoryCommand Parameter	154
425	16.3.1.2.1.1	C1G2Filter Parameter	154
426	16.3.1.2.1.1.1	C1G2TagInventoryMask Parameter	154
427	16.3.1.2.1.1.2	C1G2TagInventoryStateAwareFilterAction Parameter	155
428	16.3.1.2.1.1.3	C1G2TagInventoryStateUnawareFilterAction Parameter	155
429	16.3.1.2.1.2	C1G2RFControl Parameter	155
430	16.3.1.2.1.3	C1G2SingulationControl Parameter	155
431	16.3.1.2.1.3.1	C1G2TagInventoryStateAwareSingulationAction Parameter	156
432	16.3.1.3	Access Operation Parameters	156
433	16.3.1.3.1	C1G2TagSpec Parameter	156
434	16.3.1.3.1.1	C1G2TargetTag Parameter	156
435	16.3.1.3.2	C1G2 OpSpecs	156
436	16.3.1.3.2.1	C1G2Read Parameter	157
437	16.3.1.3.2.2	C1G2Write Parameter	157
438	16.3.1.3.2.3	C1G2Kill Parameter	157
439	16.3.1.3.2.4	C1G2Lock Parameter	157
440	16.3.1.3.2.4.1	C1G2LockPayload Parameter	158
441	16.3.1.3.2.5	C1G2BlockErase Parameter	158
442	16.3.1.3.2.6	C1G2BlockWrite Parameter	158
443	16.3.1.4	Configuration Parameters	158
444	16.3.1.5	Reporting Parameters	159
445	16.3.1.5.1	C1G2EPCMemorySelector Parameter	159
446	16.3.1.5.2	C1G2PC Parameter (TV-Encoding)	159
447	16.3.1.5.3	C1G2CRC Parameter (TV-Encoding)	159
448	16.3.1.5.4	C1G2SingulationDetails Parameter (TV-Encoding)	159
449	16.3.1.5.5	C1G2 OpSpec Results	159
450	16.3.1.5.5.1	C1G2ReadOpSpecResult Parameter	159
451	16.3.1.5.5.2	C1G2WriteOpSpecResult Parameter	160
452	16.3.1.5.5.3	C1G2KillOpSpecResult Parameter	160
453	16.3.1.5.5.4	C1G2LockOpSpecResult Parameter	160
454	16.3.1.5.5.5	C1G2BlockEraseOpSpecResult Parameter	160

455	16.3.1.5.5.6	C1G2BlockWriteOpSpecResult Parameter	161
456	16.4	LISTING OF MESSAGE AND PARAMETER TYPES.....	161
457	17	TRANSMITTER BEHAVIOR OF A READER.....	165
458	18	CONNECTION AND TRANSPORT.....	166
459	18.1	TCP TRANSPORT.....	166
460	18.2	SECURITY IN TCP TRANSPORT.....	173
461	18.2.1	<i>Normative Section</i>	173
462	18.2.2	<i>Informative Section</i>	173
463	18.2.2.1	Overview of TLS	173
464	18.2.2.2	Threat Analysis for LLRP.....	174
465	18.2.2.3	Configuration Elements for TLS.....	174
466	18.2.2.4	Why different TLS server port?.....	175
467	19	(INFORMATIVE) OBJECT MODEL.....	175
468	19.1	CAPABILITIES	177
469	19.2	CONFIGURATION	178
470	19.3	ROSPEC	180
471	19.4	ACCESSPEC	181
472	19.5	C1G2 PARAMETERS	182
473	19.6	REPORTING AND NOTIFICATION	183
474	19.7	GENERAL	186
475	20	(INFORMATIVE) TCP KEEPALIVES.....	186
476	21	(INFORMATIVE) REFERENCES.....	187
477	22	ACKNOWLEDGEMENT OF CONTRIBUTORS AND COMPANIES OPT'D-IN DURING	
478		THE CREATION OF THIS STANDARD (INFORMATIVE)	189
479			
480			

481 Index of Figures

482	FIGURE 1: LLRP IN THE EPCGLOBAL ARCHITECTURE	19
483	FIGURE 2: LLRP ENDPOINTS.....	22
484	FIGURE 3: TYPICAL LLRP TIMELINE.....	23
485	FIGURE 4: ROSPEC STATECHART	25
486	FIGURE 5: ANTENNA INVENTORY SPEC STATES	26
487	FIGURE 6: ACCESS OPERATIONS INTERLEAVED IN AN ANTENNA INVENTORY OPERATION	27
488	FIGURE 7: CLIENT REQUEST OpSPEC	28
489	FIGURE 8: ACCESS SPEC STATES.....	29
490	FIGURE 9: RFSURVEYSPEC STATES	30
491	FIGURE 10: BOX FORMATS FOR MESSAGES AND PARAMETERS.....	35
492	FIGURE 11: LLRP MESSAGES AND READER ACTIONS.....	41
493	FIGURE 12: NETWORK ORDER.....	114
494	FIGURE 13: BIT ORDER IN FIELDS	114
495	FIGURE 14: READER INITIATED CONNECTION (NORMAL)	167
496	FIGURE 15: READER INITIATED CONNECTION (EXCEPTION).....	168
497	FIGURE 16: CLIENT INITIATED CONNECTION (NORMAL).....	168
498	FIGURE 17: CLIENT INITIATED CONNECTION (EXCEPTION #1)	169
499	FIGURE 18: CLIENT INITIATED CONNECTION (EXCEPTION #2).....	169
500	FIGURE 19: CLIENT INITIATED CONNECTION (EXCEPTION #3).....	170
501	FIGURE 20: CLIENT INITIATED CONNECTION (EXCEPTION #4).....	170
502	FIGURE 21: CLIENT INITIATED CONNECTION (EXCEPTION #5).....	171
503	FIGURE 22: READER INITIATED CLOSE.....	171
504	FIGURE 23: CLIENT INITIATED CLOSE (NORMAL)	172
505	FIGURE 24: CLIENT INITIATED CLOSE (EXCEPTION).....	172
506	FIGURE 25: CAPABILITIES	177
507	FIGURE 26: CONFIGURATION.....	178
508	FIGURE 27: CONFIGURATION COMMANDS.....	179
509	FIGURE 28: RO COMMANDS.....	180
510	FIGURE 29: ROSPEC.....	180
511	FIGURE 30: ACCESS COMMANDS.....	181
512	FIGURE 31: ACCESSSPEC.....	181
513	FIGURE 32: C1G2 PARAMETERS.....	182
514	FIGURE 33: C1G2 INVENTORY COMMAND.....	182
515	FIGURE 34: C1G2 ACCESSSPEC	183
516	FIGURE 35: REPORTING AND NOTIFICATION	183
517	FIGURE 36: TAGREPORTDATA	184
518	FIGURE 37: RFSURVEYREPORTDATA	185
519	FIGURE 38: READER EVENT NOTIFICATION DATA	185
520	FIGURE 39: GENERAL DATA.....	186
521		

522 **Index of Tables**

523 TABLE 1: OPERATION TRIGGERS 32
524 TABLE 2: REPORTING TRIGGERS 34
525 TABLE 3: AIR PROTOCOL ENUMERATIONS USED IN LLRP 38
526 TABLE 4: MESSAGE LISTING 161
527 TABLE 5: PARAMETER LISTING 162
528

529 **1 (Informative) Glossary**

530 This section provides a non-normative summary of terms used within this specification.

Term	Meaning
Access	The operation of communicating with (reading from and/or writing to) a Tag. An individual Tag must be uniquely identified prior to access. Access comprises multiple commands, some of which employ one-time-pad based cover-coding of the R=>T link.
Air Interface	The complete communication link between a Reader and a Tag including the physical layer, collision arbitration algorithm, command and response structure, and data-coding methodology.
Antenna	An atomic, specifically-addressable RF transmission and/or reception device used for communication with RFID tags. For the purposes of this spec, multiplicity of antenna is going to be referred to as antennas.
Capabilities	The set of intrinsic Reader properties relevant to protocol operation. This may include physical, functional, or protocol support information.
Compatibility	A general term used to describe a consistency of terminology and/or operation between one or more specifications and/or implementations. It is specifically not intended to be used to define expectations on protocol operation. The proper term for this is 'Interoperability' as defined below.
Configuration	Data and parameters to control specific operation of a Reader or the Client that is typically instantiated at boot time or as a result of specific management actions on a timescale much greater than the operations of LLRP. It is possible that certain parameters may be controlled via LLRP and have corresponding default configuration parameters.
Client	From the perspective of LLRP, a <i>Client</i> is synonymous with <i>Controller</i> (see below). The specification uses the term Client to identify the endpoint opposite to the Reader.
Controller	The function that implements the Reader Protocol (Interface) opposite the Reader (i.e., an LLRP endpoint). In the EPCGlobal Architecture, this function could comprise part of the Filtering & Collection (Role), but it may be implemented in a wide range of devices, including dedicated RFID infrastructure, Readers, and middleware running on server hardware.

Term	Meaning
GPI	General purpose input
GPO	General purpose output
Interference	There are two types of interference that impact a RFID system's operating capacity: Reader-to-tag, and Reader-to-Reader. Reader-to-tag interference happens when a tag receives signals of comparable strengths from more than one Reader at the same time. This causes the tag to respond arbitrarily to the Readers, and makes its state unpredictable. Reader-to-Reader interference happens when a Reader in the midst of listening to a tag's reply at a particular frequency, receives signals much stronger than the tag's reply, from another Reader operating at the same frequency at the same time. This causes the Reader's receiver logic to not be able to correctly decode the tag's reply. Both these interference scenarios can potentially degrade the system performance.
Interoperability	The ability for two implementations of protocol endpoints to properly function with each other. Proper function may require negotiation of supported capabilities between the two endpoints.
Interrogator	Synonymous with Reader. The EPCglobal Class-1 Gen-2 air protocol specification refers to Readers as Interrogators. However, since the term Reader is included in the title of this specification <i>Low Level Reader Protocol</i> , the term Reader is used instead of Interrogator.
Inventory	The operation of identifying Tags. A Reader begins an inventory round by transmitting a Query command (Query starts the round) in one of four sessions. One or more Tags may reply. The Reader detects a single Tag reply and requests the PC, EPC, and CRC-16 from the Tag. Inventory comprises multiple commands. An inventory round operates in one and only one session (defined below) at a time.
LLRP	Low Level Reader Protocol
LLRP connection	Instance of LLRP between the Reader and the Client.
LLRP endpoint	The endpoints of a LLRP instance (i.e., either a Reader or a Client).

Term	Meaning
Q	A parameter that a Reader uses to regulate the probability of Tag response. A Reader commands Tags in an inventory round to load a Q-bit random (or pseudo-random) number into their slot counter; the Reader may also command Tags to decrement their slot counter. Tags reply when the value in their slot counter is zero. Q is an integer in the range (0,15); the corresponding Tag-response probabilities range from $2^0 = 1$ to $2^{-15} = 0.000031$.
Q algorithm	A collision-arbitration algorithm where Tags load a random (or pseudo-random) number into a slot counter, decrement this slot counter based on Reader commands, and reply to the Reader when their slot counter reaches zero.
Reader	The function that implements the RFID Reader (Role) in the EPCGlobal Architecture Specification. It is one of the two endpoints of the Reader Protocol (Interface) which is, for the purposes of this specification, LLRP. The Reader comprises of one or more antennas which are used to communicate with RFID tags. Note that a Reader can not only read RFID tags, it can perform other operations on tags such as write and kill.
Receive Sensitivity	Receiver sensitivity is a measure of the weakest tag signal an RFID reader is able to detect and demodulate. Changing this affects the minimum detectable signal (MDS) so as to prevent weaker responses from tying up the receiver. The other commonly used term for such a control is squelch.
Select	The operation of choosing a tag population for inventory and access. A Select command may be applied successively to select a particular Tag population based on user-specified criteria. This operation is analogous to selecting records from a database.
Session	An inventory process comprising a Reader and an associated Tag population. A Reader chooses one of four sessions and inventories Tags within that session. The Reader and associated Tag population operate in one and only one session for the duration of an inventory round. For each session, Tags maintain a corresponding inventoried flag. Sessions allow Tags to keep track of their inventoried status separately for each of four possible time-interleaved inventory processes, using an independent inventoried flag for each process.
Singulation	Identifying an individual Tag in a multiple-Tag environment.
Spec	The document uses the term 'Spec' to denote the parameter specification for an operation.

Term	Meaning
UTC	Coordinated Universal Time (UTC) is the international time standard as maintained by the Bureau International des Poids et Mesures (BIPM).

531 **2 Introduction**

532 This document specifies an interface between RFID Readers and Clients. The design of
533 this interface recognizes that in some RFID systems, there is a requirement for explicit
534 knowledge of RFID air protocols and the ability to control Readers that implement RFID
535 air protocol communications. It also recognizes that coupling control to the physical
536 layers of an RFID infrastructure may be useful for the purpose of mitigating RFID
537 interference. The interface described herein, and the functionality it implies, is called
538 “Low Level Reader Protocol,” or LLRP.

539 Following are the responsibilities of this interface:


- 540 • Provide means to command an RFID Reader to inventory tags (read the EPC
541 codes carried on tags), read tags (read other data on the tags apart from the EPC
542 code), write tags, and execute other protocol-dependent access commands (such
543 as ‘kill’ and ‘lock’ from EPCglobal Class 1 Generation 2).
- 544 • Provide means for robust status reporting and error handling during tag access
545 operations.
- 546 • Provide means for conveying tag passwords necessary to effect commands that
547 may require them, such as the ‘Kill’ command in the EPCglobal Class 1
548 Generation 2 UHF Air Interface Protocol.
- 549 • Provide means to control the forward and reverse RF link operation to manage RF
550 power levels and spectrum utilization, and assess RF interference, among RFID
551 Readers in a system.
- 552 • Provide means to control aspects of Tag Protocol operation, including protocol
553 parameters and singulation parameters.
- 554 • Provide means to facilitate the addition of support for new air protocols.
- 555 • Provide means for the retrieval of Reader device capabilities.
- 556 • Provide means for vendors of Reader devices to define vendor-specific extensions
557 to the protocol in a manner that is non-interfering among vendors, and which, to
558 the extent possible, is vendor-administered.

559 In addition LLRP is “regulatory requirements-aware,” such that its functions are
560 applicable in regulatory jurisdictions worldwide.

561 The overall organization of this specification is as follows: - General Overview (sections
562 3-6); Abstract Model (sections 7-15, 17), which describes the protocol, its message types
563 and contents without specifying the protocol syntax; Binary Encoding (section 16),
564 which specifies the syntax for representing the abstract protocol; Transport Binding
565 (section 18), which specifies the mechanism for delivery of protocol messages;
566 Informative Descriptions (sections 19-21). Guidelines for adding support of a new air
567 protocol to LLRP are presented in section 15.1.

568 **3 Role within the EPCglobal Network Architecture**

569 The RFID infrastructure consists of network elements that participate in the management
570 (e.g., read/write/lock) and transmission of tag data. The consumers of the tag data are the
571 Client network elements (e.g., end-user applications). The network elements between the
572 tag and the Clients form the conduit to transport tag data over the network to the
573 applications, and convey tag operational commands over the network to the tags. The
574 EPCGlobal Architecture (ARC) framework has outlined the roles and the associated
575 functions performed by the various elements in this network. The elements relevant to the
576 LLRP specification are the Tags, Readers and F&C Role.



577 **Figure 1: LLRP in the EPCGlobal Architecture**

578 Figure 1 illustrates the position of LLRP in the EPCGlobal architecture stack between the
579 F&C role and the Tag role.

580 The responsibilities of the elements and interfaces below the F&C role can be classified
581 into three broad functional groups: tag data processing (*Data path*), Reader device
582 management (*Management path*) and Reader control and coordination (*Control path*).

583 With the advent of sophisticated air protocols like UHF Class-1 Gen-2, and deployments
584 of larger numbers of Readers, the need for Reader control and coordination (*Control*
585 *path*) of the network of Readers in the architecture becomes important. The LLRP
586 interface facilitates the control path function by exposing air protocol relevant control

587 knobs to the F&C role. To that effect, LLRP is designed to be extensible in terms of
588 supporting multiple air protocols.

589 The physical and logical requirements for the communication between the Reader and the
590 tag are defined by the air protocol. Specifically, the air protocol defines the signaling
591 layer of the communication link, the Reader and tag operating procedures and commands,
592 and the collision arbitration (also known as singulation) scheme to identify a specific tag
593 in a multiple-tag environment. One such air protocol is the EPCGlobal Class-1
594 Generation 2 (C1G2) protocol. The tag memory in the C1G2 protocol is logically
595 separated into four distinct banks: reserved memory, EPC memory, TID memory and
596 user memory. The physical memory map of the tag is vendor-specific. The air protocol
597 commands that access memory have a parameter that selects the bank, and an address
598 parameter to select a particular memory location within that bank.

599 The fundamental operations a Reader performs on a tag population are inventory and
600 access. Inventory is the operation of identifying tags, and comprises multiple air protocol
601 commands. Using the singulation scheme, the Reader detects a single tag reply and
602 requests the EPC memory contents from the tag. Access is the operation of
603 communicating with (reading from and/or writing to) a tag. An individual tag must be
604 uniquely identified prior to access. Similar to the inventory operation, access comprises
605 multiple air protocol commands. In addition, a Reader can choose a subset of the tag
606 population for inventory and access. This operation is called Select in the C1G2 protocol.
607 The select operation is used to select and/or de-select a particular tag population for the
608 subsequent inventory and/or access operation. This helps focus the operations on the
609 desired subset of tags, and also thins the tag population participating in the singulation
610 operation, thereby improving the overall singulation rate.

611 It is anticipated that overall system performance may be optimized by tuning the RF,
612 singulation and air protocol parameters within and across Readers. The performance can
613 be further optimized if the tuning is done cognizant of the RF environment in the vicinity
614 of the Reader.

615 The LLRP interface between the Client and the Reader facilitates the management of
616 Reader devices to mitigate Reader-to-tag and Reader-to-Reader interference and
617 maximize the efficiency of singulation and data operations over the tag population. This
618 is achieved by enabling the Reader device operation at the full performance level of the
619 air protocol. In addition, LLRP provides the interface to transport the results of RF
620 monitoring (a.k.a RF survey) if the Reader device is capable of performing that function.

621 In addition, there will be a number of applications that perform operations on the RFID
622 tag data. Operations may range from reading EPC IDs to performing other tag access
623 operations exposed by the air protocol like read, write, kill, lock, etc. Multiple application
624 requirements translate into a set of access operations that a Reader or a set of Readers
625 perform on tags as and when they are in the field of view. The LLRP interface provides a
626 scalable mechanism to manage the access operations at the Reader devices.

627 Lastly, scalable device management capabilities are critical for operations of a large
628 network of Reader devices. The LLRP interface facilitates device status and error
629 reporting, and device capabilities discovery.

630 **4 Terminology and Typographical Conventions**

631 Within this specification, the terms SHALL, SHALL NOT, SHOULD, SHOULD NOT,
632 MAY, NEED NOT, CAN, and CANNOT are to be interpreted as specified in Annex G of
633 the ISO/IEC Directives, Part 2, 2001, 4th edition [ISODir2]. When used in this way,
634 these terms will always be shown in ALL CAPS; when these words appear in ordinary
635 typeface they are intended to have their ordinary English meaning. However in this
636 document only a subset of the terms listed above SHALL be used. The subset of
637 acceptable terms includes the following: SHALL, SHALL NOT and MAY. The terms
638 SHOULD, SHOULD NOT, NEED NOT, CAN, and CANNOT, SHALL NOT be used.

639 All sections of this document, with the exception of section 1-3, 19-21, are normative,
640 except where explicitly noted as non-normative. All figures within the document are non-
641 normative unless otherwise specified.

642 The following typographical conventions are used throughout the document:

643 ALL CAPS type is used for the special terms from [ISODir2] enumerated above.

644 ALL_CAPS_UNDERSCORE type is used for LLRP message names.

645 CamelBackType is used for LLRP parameter and data field names.


646 Monospace type is used to denote programming language, UML, and XML identifiers,
647 as well as for the text of XML documents.

648 **5 Overview of LLRP**

649 LLRP is specifically concerned with providing the formats and procedures of
650 communications between a Client and a Reader. The LLRP protocol data units are called
651 messages. Messages from the Client to the Reader include getting and setting
652 configuration of Readers, capabilities discovery of Readers and managing the inventory
653 and access operations at the Readers. Messages from the Reader to the Client include the
654 reporting of Reader status, RF survey, and inventory and access results.

655 LLRP is an application layer protocol and does not provide retransmission, or reordering
656 facilities. State consistency between the Client and the Reader is critical for the correct
657 functioning of the system. Using LLRP messages, the Client updates the Reader state
658 which includes Reader configuration parameters, dynamically created data structures
659 (e.g., ROSpecs, AccessSpecs, etc), and possibly vendor defined data. For this reason,
660 LLRP requires acknowledgements for the Client to Reader transactions – this provides a
661 fail-safe mechanism at the LLRP layer to cope with network error situations. Also, to
662 cope with intermittent connections, a Client can request a Reader's configuration state to
663 confirm that a Reader's state is consistent with the Client after the Client reconnects (see
664 LLRPConfigurationStateValue in section 12.2.1). The Reader to Client messages are
665 primarily reports, status notifications or keepalives. Only the keepalives are
666 acknowledged by the Client.

667



668

669 **Figure 2: LLRP Endpoints**

670 As shown in Figure 2, from LLRP’s perspective, a Reader contains a collection of one or
 671 more antennas. Moreover, Readers as used in this specification may not necessarily be in
 672 one-to-one correspondence with hardware devices.


673 **5.1 Typical LLRP Timeline**

674 LLRP operation consists of the following phases of execution:

- 675 • Capability discovery
- 676 • Device configuration
- 677 • [optional] Inventory and access operations setup
- 678 • Inventory cycles executed
- 679 If tag conditions matched, access operations will be executed during inventory
 680 cycle execution. Access operations include reading, writing, and locking tag
 681 memory, killing tags, etc.
- 682 • RF Survey operations executed
- 683 • Reports returned to the Client

684 A typical timeline of both LLRP and air protocol interactions between a Client, a Reader
 685 and a population of tags is depicted in Figure 3.

686



687
688

689 **Figure 3: Typical LLRP Timeline**

690 **6 LLRP Operation**

691 LLRP uses protocol data units called messages (See section 7.1.2 for details) to
 692 communicate between the Client and the Reader. Using LLRP, the Client updates or
 693 retrieves configuration of the Reader; by doing so, it controls the Reader's operation. This
 694 section provides an overview of the abstract model of the LLRP interface, and the data
 695 structures used in LLRP to and from the Reader.

696 Section 19 presents an informative description of the LLRP object model based upon
 697 UML notation.

698 **6.1 Inventory, RF Survey and Access Operations**

699 LLRP is based upon an abstraction of RFID air protocols and their respective commands.
 700 There are two principal concepts to the LLRP abstraction of RF operations by a Reader:
 701 1) Reader Operations, and 2) Access operations. The remainder of this section provides a
 702 detailed description of these LLRP concepts.

703 Reader Operations (RO) define the parameters for operations such as Antenna Inventory
704 and RF Survey. Access Operations define the parameters for performing data access
705 operations to and from a tag.

706 The timing control of an operation is specified using boundary specification, which
707 specifies how the beginning (using start trigger) and the end (using stop trigger) of the
708 operation is to be determined.

709 An *antenna inventory* (AI) is the smallest unit of interaction between a Reader and tags in
710 the antenna's *field-of-view* (FOV). An *InventoryParameterSpec* defines the parameters to
711 be used during the inventory operation including protocol, protocol-specific parameters,
712 and RF parameters. During an AI, the tags in the FOV of the antennas are singulated
713 using air protocol commands based on the contents of the *InventoryParameterSpec*. An
714 *AISpec* binds a stop trigger and a set of antennas to a set of *InventoryParameterSpecs*,
715 and is identified by a one based index called the *SpecIndex*. The stop trigger defines the
716 termination condition of the aggregate *AISpec* operation comprising of $N * M$ antenna
717 inventory operations, where N and M are the cardinality of the antenna set and
718 *InventoryParameterSpecs* set respectively. For example, if there is a single antenna and a
719 single *InventoryParameterSpec* defined in an *AISpec*, the AI operation specified by the
720 $\langle \text{antenna}, \text{InventoryParameterSpec} \rangle$ tuple is bounded by the stop trigger specification.

721 It should be noted that the stop trigger specification of each individual AI is not specified,
722 which means the Reader is not limited to execute the AIs in the order in which they
723 appear in an *AISpec*. The timing control and the sequencing of the individual AIs within
724 an *AISpec* will be determined by the Reader.

725 *RF Survey* is an operation during which the Reader performs a scan and measures the
726 power levels across a set of frequencies at an antenna. The RF survey operational
727 parameters are described in a *RFSurveySpec* and it defines the survey operation at a
728 single antenna. It comprises an identifier for the spec, an antenna identifier, stop trigger
729 and set of parameters for the survey operation.

730 A *Reader Operation* (RO) describes the operations to be executed at one or more
731 antennas of the Reader. A RO comprises at least one Spec, where a Spec is either an
732 *AISpec* or a *RFSurveySpec*. If a RO comprises multiple Specs, each Spec is an *AISpec* or
733 a *RFSurveySpec*. Each RO's operational parameters are described in a *ROSpec*. The
734 *ROSpec* contains a spec identifier, the boundary specification for the entire RO operation,
735 priority, a list of *AISpecs* and/or *RFSurveySpecs*, and optionally a reporting specification.
736 The reporting specification defines the contents of RO Report and the trigger conditions
737 when to send the inventory report and survey report. The order of *AISpec* and
738 *RFSurveySpec* execution within a *ROSpec* is the order in which they appear in the
739 *ROSpec*.

740 Figure 4 illustrates the statechart of a *ROSpec*. The *ROSpec* has three states: Disabled,
741 Inactive and Active. The Client configures a new *ROSpec* using an *ADD_ROSPEC*
742 message for the *ROSpec*. The *ROSpec* starts at the Disabled state waiting for the
743 *ENABLE_ROSPEC* message for the *ROSpec* from the Client, upon which it transitions
744 to the Inactive state. The *ROSpec* does not respond to start or stop triggers in the
745 Disabled state. The Client disables a *ROSpec* using a *DISABLE_ROSPEC* message for
746 the *ROSpec*.


747 The *ROSpec* transitions from the Inactive state to the Active state when
 748 ROSpecStartCondition occurs for the *ROSpec*. The *ROSpec* transitions back to the
 749 inactive state when ROSpecDoneCondition happens.

ROSpecStartCondition = ROSpecStartTrigger or START_ROSPEC

ROSpecDoneCondition = AllSpecsDone or ROSpecStopTrigger or preempted or
 (STOP_ROSPEC message for the ROSpec from the Client)

750

751 The *ROSpec* when undefined is no longer considered for execution. The Client undefines
 752 the *ROSpec* using a DELETE_ROSPEC message for the *ROSpec*.




753

754 **Figure 4: ROSpec Statechart**


755 LLRP supports configuring multiple *ROSpecs*. Each *ROSpec* has a priority field. The
 756 default is for all the *ROSpecs* to have the same priority. Since the start trigger for the
 757 *ROSpec* can be an asynchronous event, there may be situations where a *ROSpec*'s start
 758 trigger event occurs when the Reader is busy executing another *ROSpec*. The Client,
 759 when setting up a *ROSpec*, can set the appropriate priority so that a high priority *ROSpec*
 760 can preempt a currently active lower priority *ROSpec* and start execution as soon as the
 761 ROSpecStartCondition for the higher priority, inactive *ROSpec* occurs. The *ROSpec* that
 762 got preempted transitions to the Inactive state.

763 Figure 5 illustrates the *AISpec* statechart. When the parent *ROSpec* moves to the active
 764 state, each *AISpec* in the *ROSpec* starts at the inactive state. During an active *ROSpec*'s
 765 execution, when an inactive *AISpec* is selected for execution, that *AISpec* moves to the
 766 active state. If there are multiple antennas and *InventoryParameterSpecs* in that *AISpec*,
 767 the Reader picks the next <antenna, *InventoryParameterSpec*> to execute. In the figure,

768 the ID of the selected antenna is A, and the protocol for the selected
 769 *InventoryParameterSpec* is P. The Reader starts tag singulation for air protocol P on
 770 antenna A using the operational parameters specified in the *InventoryParameterSpec*.
 771 This involves one or more air protocol commands from the Reader via the antenna to the
 772 tags in the antenna's FOV. The tags get singulated and each tag's EPC information is
 773 received by the antenna. If further tag memory operations are to be performed, such as
 774 writing or reading other memory regions, it will be performed at this point. As illustrated
 775 in Figure 6, these access operations are interleaved with the execution of an *AISpec*.
 776 Access operations are described using *AccessSpecs*. *AccessSpecs* describe the tags
 777 (*TagSpec*) on which some operations are to be performed, the operations to be performed
 778 (*OpSpec*), the boundary specification, and optionally a reporting specification for the
 779 Access operation. The *AccessSpec* may contain antenna information at which this access
 780 operation needs to be executed and contains the air protocol to be used to perform the
 781 access operations. In addition, to accommodate scenarios where an access operation
 782 needs to be performed only during a particular *ROSpec* execution, the *AccessSpec*
 783 optionally contains the *ROSpec* information. There can be one or more *AccessSpecs* set
 784 up at the Reader.



785
 786 **Figure 5: Antenna Inventory Spec States**
 787




788

789 **Figure 6: Access Operations Interleaved in an Antenna Inventory Operation**

790 In Figure 5, when tags are received as a result of singulation, a check is performed to
 791 determine if the received tag matches the TagSpec defined in any of the Active (See
 792 statechart in Figure 8) *AccessSpecs*. In case there are multiple *AccessSpecs* that get
 793 matched during a tagSpec lookup, the Reader will execute the first *AccessSpec* that
 794 matches, where the ordering of the *AccessSpecs* is the order in which the *AccessSpecs*
 795 were created by the Client.

796 When an *AccessSpec* is executed, the set of operations as specified in *OpSpecs* of the
 797 *AccessSpec* are performed on the tag, which results in one or more air protocol
 798 commands and responses transacted between the Reader and the tag via antenna A over
 799 air protocol P. In order to support cases where the Reader needs to query the Client for
 800 further information to complete the operation on the tag, there is an *OpSpec* called the
 801 *ClientRequestOpSpec*.



802

803 **Figure 7: Client Request OpSpec**

804 Figure 7 illustrates the message interaction between the Client, Reader and Tag for a
 805 ClientRequestOpSpec. For OpSpecs that are not ClientRequestOpSpec, the Reader
 806 performs the operations on the tag using the the air protocol commands. If an OpSpec is
 807 of the ClientRequestOpSpec, the Reader sends the result of the ongoing AccessSpec till
 808 that point in a CLIENT_REQUEST_OP message, so that the Client has all the relevant
 809 information to send a response. The client response is carried in a
 810 CLIENT_REQUEST_OP_RESPONSE message. This message is the set of OpSpecs that
 811 the reader should execute. The reader continues to execute the OpSpecs within an
 812 AccessSpec until all opSpecs have been executed or until an error occurs. When
 813 execution completes, the reader resumes the inventory operation.


814 The AISpec transitions back to the inactive state when AISpecDoneCondition occurs or
 815 when the parent *ROSpec*'s ROSpecDoneCondition occurs.

816

AISpecDoneCondition = AISpecStopTrigger

817

818



819

820 **Figure 8: Access Spec States**

821 Figure 8 illustrates the *AccessSpec*'s states. The Client configures an *AccessSpec* using an
 822 *ADD_ACCESS_SPEC* message for the *AccessSpec*. The *AccessSpec* starts at the
 823 Disabled state, waiting for an *ENABLE_ACCESS_SPEC* message from the Client for
 824 that *AccessSpec*, upon which it enters the Active state. It is only in the Active state that
 825 the *AccessSpec* is considered for execution. The Client can disable an *AccessSpec* using a
 826 *DISABLE_ACCESS_SPEC* message for the *AccessSpec*. The *AccessSpec* when
 827 undefined is no longer considered for execution. The Client undefines the *AccessSpec*
 828 using a *DELETE_ACCESS_SPEC* message for the *AccessSpec*.

829 In order for the Reader to take a local action to limit the validity of an *AccessSpec*, the
 830 Client can configure a stop trigger for the *AccessSpec*. An example use case of the stop
 831 trigger is when an *AccessSpec* is defined on all the antennas, and the desired behavior is
 832 to operate on the tag only once, the first time it is seen at any antenna. When the
 833 *AccessStopCondition* occurs, the *AccessSpec* transitions to undefined and is no longer
 834 considered for execution.

835

AccessStopCondition = AccessSpecStopTrigger

836


837

838 Figure 9 illustrates the *RFSurveySpec* statechart. When the parent *ROSpec* moves to the
 839 active state, each *RFSurveySpec* in the *ROSpec* starts at the inactive state. During an
 840 active *ROSpec*'s execution, when an inactive *RFSurveySpec* is selected for execution,
 841 that *RFSurveySpec* moves to the active state. In the active state, the Reader executes the
 842 survey operation as specified by the *RFSurveySpec*. The *RFSurveySpec* transitions back
 843 to the inactive state when the *RFSurveySpecDoneCondition* occurs or when the parent
 844 *ROSpec*'s *ROSpecDoneCondition* occurs.

845

RFSurveyStopCondition = RFSurveySpecStopTrigger

846



847

848 **Figure 9: RFSurveySpec States**

849 In summary, the Reader operation and Access operation specific data structures pass the
 850 following information between a Client and a Reader:

851 **ROSpec:** Details of a Reader operation

- 852 • ROSpecID: This identifier is generated by the Client. This identifier is used by the
 853 Client to perform operations on this ROSpec, like start, stop, enable, disable and
 854 delete. Reports that are generated as a result of the execution of this ROSpec also
 855 carry this identifier.
- 856 • ROBoundarySpec:
 - 857 ○ ROSpecStartTrigger, ROSpecStopTrigger: This is the start and stop
 858 trigger for this ROSpec. The triggers that are specifiable for a ROSpec are
 859 listed in Table 1.
- 860 • Priority: This is the priority of this ROSpec.
- 861 • CurrentState: This is the current state of the ROSpec – disabled, inactive, active.
 862 This field is kept up to date by the Reader based on the ROSpec’s current state.
- 863 • Set of Specs: Each Spec is either an *AISpec* or *RFSurveySpec*. The Specs are
 864 executed in the order in which it is defined in the ROSpec. The position of the
 865 Spec (*AISpec* or *RFSurveySpec*) in the ROSpec is called the SpecIndex. The
 866 SpecIndex is used during reporting to identify the spec inside of ROSpec whose
 867 execution generated the data in the report. The numbering of SpecIndex is 1
 868 based.
- 869 • ROReportingSpec: If specified, this defines when to send the results of this
 870 ROSpec, and also the contents and format of the report.

871

872 **AISpec:** Details of one of more antenna inventory operations

- 873 • AISpecStopTrigger: This is the stop trigger for the AISpec. The triggers that are
 874 specifiable for an AISpec are listed in Table 1.
- 875 • Set of Antenna IDs: This is the set of antennas at which the inventory operations
 876 described in the InventoryParameterSpecs are executed. If there are N antennas
 877 and M InventoryParameterSpecs, the Reader will execute the M inventory
 878 operations at each of the specified antennas. Thus, in aggregate, the Reader will

879 execute $N * M$ AIs (Antenna inventory operations). The ordering of the AIs is
880 determined by the Reader.

881 • Set of InventoryParameterSpecs: There can be one or more
882 InventoryParameterSpecs specified as part of the AISpec. Collectively, they are
883 bound by the AISpecStopTrigger. The order in which the antenna inventory
884 operations described as <Antenna, InventoryParameterSpec> are executed is
885 determined in a proprietary manner inside the Reader.

886

887 **InventoryParameterSpec:** Operational parameters for an inventory using a single air
888 protocol.

889 • InventoryParameterSpecID: This identifier is generated by the Client. Reports that
890 are generated as a result of the execution of this InventoryParameterSpec carry
891 this identifier.

892 • Air Protocol: This is the air protocol that is used to inventory the tags in the field
893 of view of the antenna.

894 • Set of Antenna Configuration Settings: Each Antenna Configuration setting
895 comprises of

896 ○ Antenna ID: The identifier of the antenna

897 ○ RFTransmitterSettings: This describes the configuration of the transmitter
898 during the inventory operation.

899 ○ RFReceiverSettings: This describes the configuration of the receiver
900 during the inventory operation.

901 ○ AirProtocolInventoryCommandSettings parameters: This describes the
902 configuration of the air protocol parameters for the inventory operation.

903

904 **RFSurveySpec:** Details of a RF Survey operation

905 • RFSurveySpecID: This identifier is generated by the Client. Reports that are
906 generated as a result of the survey operation carry this identifier.

907 • RFSurveySpecStopTrigger: This is the stop trigger for the RFSurveySpec. The
908 triggers that are specifiable for a RFSurveySpec are listed in Table 1.

909 • AntennaID: This is the antenna at which the survey operation is to be executed.

910 • StartFrequency: This is the starting channel for which power levels need to be
911 measured during this RF survey operation.

912 • EndFrequency: This is the ending channel for which power levels need to be
913 measured during this RF survey operation. The RF survey operation is performed
914 on frequency channels between the specified Start Frequency and End frequency.

915

916 **AccessSpec:** Details of an access operation.

- 917 • AccessSpecID: This identifier is generated by the Client upon creation of this
918 AccessSpec. This identifier is used by the Client to perform operations on this
919 AccessSpec, like start, stop and delete. Reports that are generated as a result of
920 the execution of this AccessSpec also carry this identifier.
- 921 • AntennaID: This is the identifier of the antenna for whose tag observations this
922 AccessSpec is executed.
- 923 • Air Protocol: This is the air protocol used to perform access operations on the tag.
- 924 • ROSpecID: This is the identifier of the ROSpec during whose tag observations
925 this AccessSpec is executed.
- 926 • CurrentState: This is the current state of the AccessSpec – disabled, active. This
927 field is kept up to date by the Reader based on the AccessSpec’s current state.
- 928 • AccessSpecStopTrigger: If specified, this is the trigger to undefine the
929 AccessSpec upon the occurrence of the stop trigger.
- 930 • AccessCommand: This parameter is used to configure the air protocol parameters
931 for the access operation. At a minimum, this specifies the tag filters for which the
932 access operations are to be performed, and the list of operations to be performed
933 on the tag.
 - 934 ○ TagSpec: This describes the tag filters and is specified in terms of the air
935 protocol’s tag memory layout.
 - 936 ○ List of OpSpecs: This is specified in terms of the air protocol’s tag access
937 operations. The order of execution is determined by the order in which it is
938 configured in the AccessSpec.
- 939 • AccessReportSpec: If specified, this defines when to send the results of this
940 AccessSpec, and also the contents and format of the report.

941 6.1.1 Operation Triggers

942 This section describes the triggers that can be configured using LLRP to control the
943 various operations.

944 6.1.1.1 Summary

945 The specific triggers used to control the various operations are presented in a tabular
946 fashion.

947 **Table 1: Operation Triggers**

<i>Trigger Name</i>	<i>ROSpecStart</i>	<i>ROSpecStop</i>	<i>AISpecStop</i>	<i>AccessSpecStop</i>	<i>RFSurveySpec Stop</i>
GPI Trigger	X	-	-	-	-
GPI Trigger with Timeout	-	X	X	-	-
N attempts	-	-	X	-	-

N tag observations	-	-	X	-	-
No tag observations for t ms	-	-	X	-	-
Immediate	X	-	-	-	-
Null	X	X	X	X	X
Time Based Periodic	X	-	-	-	-
Time Based Duration	-	X	X	-	X
Operation Count	-	-	-	X	X

948

949 **6.1.1.2 Reader Operation Triggers**

950 The triggers SHALL operate as follows:

- 951 • Null: When used as a start or a stop trigger, it implies no start or stop conditions
952 have been specified, respectively.
- 953 • Immediate: This is used as a start trigger. Operations using this trigger will start
954 immediately.
- 955 • Time-based: There are two different types of time-based triggers defined in LLRP
956 – periodic and duration.
- 957 ○ Periodic: This is used as a start trigger. This is specified using UTC time
958 [UTC], offset and period. For one-shot inventory, period is set to 0, and
959 for periodic inventory operation, period > 0. If UTC time is not specified,
960 the first start time is determined as (time of message receipt + offset), else,
961 the first start time is determined as (UTC time + offset). Subsequent start
962 times = first start time + k * period (where, k > 0).
- 963 ○ Duration: This is used as a stop trigger.
- 964 • Tag observation based: There are three different types of tag-observation based
965 triggers defined in LLRP. They are all used only as stop triggers. Each of these
966 trigger types have a timeout value. So the trigger event happens when either the
967 tag observation event happens or the timeout expires.
- 968 ○ Upon seeing N tags, or timeout.
- 969 ○ Upon seeing no more new tags for t milliseconds, or timeout
- 970 ○ N attempts to see all the tags in the field of view, or timeout
- 971 • External events: These are due to events received at Reader interfaces like signal
972 transition on a GPI port or a message on the network port.
- 973 ○ GPI event at a GPI port, or a timeout
- 974 ○ Client triggers: A Client can instruct the Reader to start/stop a particular
975 operation using LLRP messages.

976 • Operation count: This is used as a stop trigger for RFSurvey. This trigger limits
 977 the number of times the Reader takes survey measurements across the specified
 978 frequency range.

979 AI and RFSurvey specs do not contain start triggers. The first spec (AISpec or
 980 RFSurveySpec) starts when the ROSpec enters the active state. The kth Spec in the
 981 ROSpec starts immediately after the completion of the k-1th Spec.

982 When Null is specified as a stop trigger for a Spec ((either AISpec or RFSurveySpec), the
 983 execution of the Spec is stopped only when the parent ROSpec’s ROSpecDoneCondition
 984 occurs.

985 **6.1.1.3 Access Operation Triggers**

986 AccessSpecs do not contain start triggers. An AccessSpec when enabled using
 987 ENABLE_ACCESS_SPEC will transition to the active state. There is only one type of
 988 stop trigger for controlling the validity of an AccessSpec:

989 • Operation count: This is used as a stop trigger. This trigger is useful to limit the
 990 number of times the instance of the operation is executed during its lifetime.

991 **6.2 Reporting, Event Notification and Keepalives**

992 The results of the inventory, access and RF survey operations, will be sent by the Reader
 993 to the Client in the form of reports. Using LLRP, the Client is capable of setting up the
 994 triggers that determine when the report is to be sent by the Reader, and also the contents
 995 and format of the report. The report message is RO_ACCESS_REPORT. The triggers
 996 and report contents can be configured in one of the following ways:

997 • Differently for each ROSpec and AccessSpec when creating them using the
 998 ADD_ROSPEC and ADD_ACCESSSPEC messages, respectively.

999 • Global default using the SET_READER_CONFIG message.

1000 Table 2 summarizes the triggers available in LLRP to control when the RO report and the
 1001 AccessReport is to be generated and sent by the Reader.

1002 **Table 2: Reporting Triggers**

<i>Trigger Name</i>	<i>ROReport</i>	<i>AccessReport</i>
None	X	-
(Upon N tags or End of Spec), where Spec = AISpec or RFSurveySpec	X	-
Upon N tags or End of ROSpec	X	-
End of AccessSpec	-	X
Whenever ROReport is generated for the RO that triggered the execution of	-	X

this AccessSpec		
-----------------	--	--

1003

1004 In addition to data reports, the Client can configure the Reader to enable or disable
 1005 notification of events as and when it happens at the Reader. Some examples of events are
 1006 frequency hop, buffer overflow, etc.

1007 In order to monitor the LLRP-layer connectivity with the Reader, the Client can
 1008 configure the Reader to send Keepalives periodically. The Keepalive message is
 1009 acknowledged by the Client, using which, the Reader can also monitor the LLRP-layer
 1010 connectivity with a Client. The Keepalives can be disabled. If enabled, the periodicity of
 1011 the message is specified by the Client.

1012 **7 Messages, Parameters and Fields**


1013 LLRP is a message-oriented protocol made up of data elements called protocol data units.
 1014 This section provides the details of each message type and parameter type, and expresses
 1015 them in an abstract manner. The section starts with an overview of the message types and
 1016 parameters, where the messages are grouped into separate functional groups.

1017 **7.1 Overview**

1018 LLRP provides an extensible mechanism to support existing and new air protocols. It is
 1019 achieved by decoupling messages from parameters – using a common message structure
 1020 across air protocols, and providing extensibility in the form of parameters.

1021 **7.1.1 Formatting Conventions**

1022 LLRP messages and parameters are defined using the graphical notation below.



1023

1024 **Figure 10: Box Formats for Messages and Parameters**

1025

1026 Contained within the box is an ordered list of sub-parameters and fields contained within
 1027 the message or parameter. The field/parameter names are shown in **boldface**, followed

1028 by the data type and a brief description of the field/parameter when necessary. Fields
1029 with values that are restricted to a subset of the range of their data type have their
1030 possible and legal values shown in *italics* below the field name.

1031

1032 Fields are composed of one of the following basic data types:

1033 **Bit** – An integer with only two possible values, 0 or 1

1034 **Bit Array** – A sequence of bits.

1035 **Byte Array** – A sequence of bytes.

1036 **Boolean** – A field that can take the values TRUE or FALSE.

1037 **Integer** – An integer can take any whole number. When this value is used in the abstract
1038 specification, the *Possible Values* element will specify the possible and legal value for a
1039 particular field.

1040 **Short Array** – A sequence of unsigned short integers

1041 **Signed Integer** – A signed integer can take any whole number value between -2^{31} through
1042 $2^{31}-1$ inclusive. Within the abstract specification, the *Possible Values* element will
1043 enumerate any restrictions beyond these limits for a particular field.

1044 **Signed Short Integer** – A signed short integer can take any whole number value between
1045 -2^{15} through $2^{15}-1$ inclusive. Within the abstract specification, the *Possible Values*
1046 element will enumerate any restrictions beyond these limits for a particular field

1047 **Unsigned Integer** – An unsigned integer is a value that is between 0 through $2^{32}-1$
1048 inclusive. Within the abstract specification, the *Possible Values* element will enumerate
1049 any restrictions beyond these limits for a particular field.

1050 **Unsigned Long Integer** – An unsigned long integer is a value that is between 0 through
1051 $2^{64}-1$ inclusive. Within the abstract specification, the *Possible Values* element will
1052 enumerate any restrictions beyond these limits for a particular field.

1053 **Unsigned Short Integer** – An unsigned short integer is a value that is between 0 through
1054 $2^{16}-1$ inclusive. Within the abstract specification, the *Possible Values* element will
1055 enumerate any restrictions beyond these limits for a particular field.

1056 **UTF-8 String** – A sequence of UTF-8 [UTF8] encoded characters.

1057 In addition to the basic types, fields can be defined as ‘lists’ of a basic type. A list is an
1058 ordered set of a basic type. The order is preserved by all bindings.

1059 **7.1.2 Messages**

1060 Each Message contains:

- 1061 • Version value that indicates the version of the protocol for this message.
- 1062 • Message Type value that uniquely identifies it within a protocol message.
- 1063 • Message ID: The Reader behavior SHALL be based upon starting the processing
1064 of messages in the order received over LLRP, however, the completion of

1065 execution of the message processing MAY not necessarily be in the same order
1066 inside the Reader. Hence, the Reader responses to the messages may be in a
1067 different order than the order of the Client messages. The Message ID is to
1068 facilitate multiple outstanding messages/requests from Client or Reader. The
1069 communications between the Client and the Reader is primarily of a request-
1070 response type - requests/commands from the Client to the Reader, and response
1071 from the Reader to the Client. The Message ID is used to associate a Reader
1072 response with the original Client message.

- 1073 • In addition, it may contain mandatory or optional parameters.

1074 **7.1.3 Parameters**

1075 LLRP Parameters are used to communicate specific details of LLRP operation in LLRP
1076 Messages. Each Parameter contains:

- 1077 • Parameter Type value that uniquely identifies it within a Message.
- 1078 • In addition, it may contain individual fields or sub-parameters.

1079 **7.1.3.1 General Parameters**

1080 This section describes the set of parameters that are used in multiple messages or
1081 parameters.

1082 **7.1.3.1.1 Timestamp**

1083 The timestamps in LLRP messages or parameters can be either the uptime or the UTC
1084 time [UTC]. If a Reader has an UTC clock, all timestamps reported by the Reader
1085 SHALL use an UTC timestamp parameter. If a Reader has no UTC clock capability, all
1086 timestamps reported by the Reader SHALL use the uptime parameter.

1087 **7.1.3.1.1.1 UTCTimestamp Parameter**

1088 **Compliance requirement:** Compliant Readers and Clients that have UTC clocks
1089 SHALL implement this parameter.

UTCTimestamp Parameter

MicroSeconds: Unsigned Long Integer. This is the time elapsed since the Epoch (00:00:00 UTC, January 1, 1970) measured in microseconds.

1090 **7.1.3.1.1.2 Uptime Parameter**

1091 **Compliance requirement:** Compliant Readers and Clients that do not have UTC clocks
1092 SHALL implement this parameter. Compliant Readers and Clients that have UTC clocks
1093 MAY implement this parameter.

Uptime Parameter

Microseconds: Unsigned Long Integer. This is the time elapsed since boot, measured in microseconds.

1094 7.1.4 Fields

1095 Messages and parameters may contain individual fields. In this section, we present the
1096 enumerations and the interpretation of the value of zero for certain fields.

1097 ProtocolID: This is the identifier of the air protocol. The air protocol enumerations used
1098 in the LLRP protocol are as follows:

1099 **Table 3: Air Protocol Enumerations used in LLRP**

Air Protocol Enumerations

Protocol ID : Integer

Possible Values:

Value	Protocol
0	Unspecified air protocol
1	EPCGlobal Class 1 Gen 2
2-255	Reserved for future use

1100 **Compliance requirement:** Compliant Readers and Clients SHALL use this enumeration.

1101

1102 AntennaID, ROSpecID, AccessSpecID, GPIPort, GPOPort: These fields are identifiers
1103 for LLRP-related objects within the Reader. For example, AntennaID is the identifier of
1104 the antenna; ROSpecID is the identifier of the ROSpec. The objects are indexed from 1.
1105 A value of non-zero for a field is a specific instance of the respective object. A value of
1106 zero means all instances of the respective object.

1107 7.1.5 Functional Grouping

1108 The LLRP messages are grouped into:

1109 • **Reader device capabilities:** Messages that query Reader capabilities. They
1110 include

1111 ○ GET_READER_CAPABILITIES

1112 ○ GET_READER_CAPABILITIES_RESPONSE

1113 • **Reader operations control:** Messages that control the Reader's air protocol
1114 inventory and RF operations. They include

1115 ○ ADD_ROSPEC

1116 ○ ADD_ROSPEC_RESPONSE


1117 ○ DELETE_ROSPEC

- 1118 ○ DELETE_ROSPEC_RESPONSE
- 1119 ○ START_ROSPEC
- 1120 ○ START_ROSPEC_RESPONSE
- 1121 ○ STOP_ROSPEC
- 1122 ○ STOP_ROSPEC_RESPONSE
- 1123 ○ ENABLE_ROSPEC
- 1124 ○ ENABLE_ROSPEC_RESPONSE
- 1125 ○ DISABLE_ROSPEC
- 1126 ○ DISABLE_ROSPEC_RESPONSE
- 1127 ○ GET_ROSPECS
- 1128 ○ GET_ROSPECS_RESPONSE
- 1129 • **Access control:** Messages that control the tag access operations performed by the
- 1130 Reader. They include
 - 1131 ○ ADD_ACCESSSPEC
 - 1132 ○ ADD_ACCESSSPEC_RESPONSE
 - 1133 ○ DELETE_ACCESSSPEC
 - 1134 ○ DELETE_ACCESSSPEC_RESPONSE
 - 1135 ○ ENABLE_ACCESSSPEC
 - 1136 ○ ENABLE_ACCESSSPEC_RESPONSE
 - 1137 ○ DISABLE_ACCESSSPEC
 - 1138 ○ DISABLE_ACCESSSPEC_RESPONSE
 - 1139 ○ GET_ACCESSSPECS
 - 1140 ○ GET_ACCESSSPECS_RESPONSE
 - 1141 ○ CLIENT_REQUEST_OP
 - 1142 ○ CLIENT_REQUEST_OP_RESPONSE
- 1143 • **Reader device configuration:** Messages that query/set Reader configuration, and
- 1144 close LLRP connection. They include
 - 1145 ○ GET_READER_CONFIG
 - 1146 ○ GET_READER_CONFIG_RESPONSE
 - 1147 ○ SET_READER_CONFIG
 - 1148 ○ SET_READER_CONFIG_RESPONSE
 - 1149 ○ CLOSE_CONNECTION
 - 1150 ○ CLOSE_CONNECTION_RESPONSE

- 1151 • **Reports:** These are messages that carry different reports from the Reader to the
1152 Client. Reports include Reader device status, tag data, RF analysis report. They
1153 include
- 1154 ○ GET_REPORT
 - 1155 ○ RO_ACCESS_REPORT
 - 1156 ○ READER_EVENT_NOTIFICATION
 - 1157 ○ KEEPALIVE
 - 1158 ○ KEEPALIVE_ACK
 - 1159 ○ ENABLE_EVENTS_AND_REPORTS
- 1160 • **Custom Extension:** This is a common mechanism for messages that contain
1161 vendor defined content.
- 1162 ○ CUSTOM_MESSAGE
- 1163 • **Errors:** Typically the errors in the LLRP defined messages are conveyed inside
1164 of the responses from the Reader. However, in cases where the message received
1165 by the Reader contains an unsupported message type, or a CUSTOM_MESSAGE
1166 with unsupported parameters or fields, the Reader SHALL respond with this
1167 generic error message.
- 1168 ○ ERROR_MESSAGE
- 1169 LLRP parameters are used to communicate specific settings of LLRP operation in the
1170 messages. A parameter contains one or more fields, and in some cases also may nest one
1171 or more other parameters.
- 1172 Typically, each message type has its own set of parameters; however, there may be
1173 exceptions in some cases, where two different message types use the same parameter
1174 because they require the same setting exposed by the parameter.

1175 **7.1.6 LLRP Messages and Actions**

1176 This section describes the corresponding LLRP-related actions in the Reader upon
1177 receiving the various LLRP protocol messages. Figure 11 uses UML synchronous
1178 messaging notation. Messages are asynchronous.



1179

1180 **Figure 11: LLRP Messages and Reader Actions**

1181 **8 Custom Extension**

1182 LLRP supports vendor extensions for defining commands and parameters within certain
 1183 commands. All LLRP bindings support these extension mechanisms.

1184 **8.1 CUSTOM_MESSAGE**

1185 This message carries a vendor defined format from Reader to Client or Client to Reader.
1186 In addition to the version and messageID, the custom message also carries the
1187 information below.

<p>CUSTOM_MESSAGE</p> <p>Vendor Identifier: Unsigned Integer. IANA Private Enterprise Number</p> <p>Message Subtype: Integer</p> <p><i>Possible Values:</i> 0-255.</p> <p>Data: vendor specific format</p>
--

1188

1189 No requirements are made as to the content or parameters contained within the Data
1190 portion of these messages. Clients MAY ignore CUSTOM_MESSAGES. Readers
1191 SHALL accept CUSTOM_MESSAGE and return an ERROR_MESSAGE if
1192 CUSTOM_MESSAGE is unsupported by the Reader or the CUSTOM_MESSAGE
1193 contains fields and/or parameters that are unsupported by the Reader.

1194 **8.2 Custom Parameter**

1195 Certain Messages and Parameter Sets within LLRP allow for the insertion of vendor
1196 defined parameters. These custom parameters have the following format.

<p>Custom Parameter</p> <p>Vendor Identifier: Unsigned Integer. IANA Private Enterprise Number</p> <p>Parameter Subtype: Unsigned IntegerData: vendor specific format</p>

1197

1198 Clients SHALL accept messages (except for CUSTOM_MESSAGE) that contain custom
1199 parameters but MAY ignore all custom parameters within these messages. Readers
1200 SHALL accept messages (except for CUSTOM_MESSAGE) that contain custom
1201 parameters and SHALL return an error when such parameters are unsupported.

1202 **8.3 Custom Extension in Commands**

1203 The following commands allow one or more custom Parameters in their message
1204 structure:

- 1205 GET_READER_CAPABILITIES
- 1206 GET_READER_CONFIG
- 1207 GET_READER_CAPABILITIES_RESPONSE

1208 GET_READER_CONFIG_RESPONSE
1209 SET_READER_CONFIG

1210 8.4 Custom Extension in Individual LLRP Parameters

1211 LLRP only allows extension to parameters where the parameter set is defined with a
1212 custom Parameter type in the abstract model. All custom extension points will be marked
1213 in the abstract standard using the notation

1214

1215 **Custom Extension Point List:** List of <custom Parameter> [optional]

1216 The following example illustrates a fictitious parameter that allows the embedding of
1217 custom extension parameters.

Example Parameter

Field1: Unsigned Integer

relatedData: Example Sub Parameter

Custom Extension Point List: List of <custom Parameter> [optional]

1218

1219 This example shows that the Example Parameter could contain an optional custom
1220 parameter that must adhere to the custom Parameter format.

1221 8.5 Allowable Parameter Extension

1222 All parameter values are specified within the abstract binding. A Reader or Client
1223 SHALL NOT extend the range of fields defined within the abstract specification unless
1224 the possible values indicate ranges for user defined options.

1225 For example, the Identification Parameter defines a field to carry the ID type.

1226 **IDType:** Integer

1227 *Possible Values:*

IDType	ID
0	MAC address
1	EPC

1233 A Client or Reader adhering to the standard SHALL generate an **IDType** field with only
1234 those values shown (0-1). A Reader or Client implementation SHALL generate an error
1235 upon receiving a value outside this range.

1236 9 Reader Device Capabilities

1237 There are four broad categories of capabilities that are advertised by the Reader: general
1238 device, LLRP, regulatory, and air protocol capabilities.

1239 **9.1 Messages**

1240 **9.1.1 GET_READER_CAPABILITIES**

1241 This message is sent from the Client to the Reader. The Client is able to request only a
1242 subset or all the capabilities from the Reader.

1243 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1244 message.

GET_READER_CAPABILITIES	
RequestedData: Integer	
<i>Possible Values:</i>	
Value	Requested Data
-----	-----
0	All
1	General Device Capabilities
2	LLRP Capabilities
3	Regulatory Capabilities
4	Air Protocol LLRP Capabilities
Custom Extension Point List: List of <custom Parameter> [optional]	

1245

1246 **9.1.2 GET_READER_CAPABILITIES_RESPONSE**

1247 This is the response from the Reader to the GET_READER_CAPABILITIES message.
1248 The response contains the LLRPStatus Parameter and the list of parameters for the
1249 requested capabilities conveyed via RequestedData in the
1250 GET_READER_CAPABILITIES message.

1251 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1252 message.

GET_READER_CAPABILITIES_RESPONSE
Response Data: Set of LLRP Parameters.
<i>Possible Values:</i> The possible members are <LLRPStatus Parameter>, and, one or more from the set < GeneralDeviceCapabilities Parameter, LLRPCapabilities Parameter, RegulatoryCapabilities Parameter, AirProtocolLLRPCapabilities Parameter >.
Custom Extension Point List: List of <custom Parameter> [optional]

1253 **9.2 Parameters**

1254 **9.2.1 GeneralDeviceCapabilities Parameter**

1255 This parameter carries the general capabilities of the device like supported air protocols,
1256 version of the Reader firmware, device hardware and software information, and receive
1257 sensitivity table.

1258 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1259 parameter.

GeneralDeviceCapabilities Parameter

Device manufacturer name: Unsigned Integer. The IANA Private Enterprise Number (PEN).

Model name: Unsigned Integer

Firmware version: UTF-8 String

Maximum number of antennas supported: Unsigned Short Integer

CanSetAntennaProperties: Boolean. If set to true, the Client can set antenna properties (Section 12.2.5), else, the Client can not set it, but only query it using GET_READER_CONFIG.

Receive Sensitivity Table: List of <ReceiveSensitivityTableEntry Parameter>

Per Antenna Receive Sensitivity Range: List of <PerAntennaReceiveSensitivityRange Parameter>

Air protocol supported per antenna: N instances of <PerAntennaAirProtocol Parameter>, where N = Maximum number of antennae supported.

GPIO Support: <GPIO Capabilities Parameter>

HasUTCclockCapability: Boolean. If set to true, the Reader reports time based on UTC timestamps (Section 7.1.3.1.1.1) in its reports, else, the Reader reports time based on Uptime (Section 7.1.3.1.1.2) in its reports.

1260 **9.2.1.1 ReceiveSensitivityTableEntry Parameter**

1261 This parameter specifies the index into the Receive Sensitivity Table for a receive
1262 sensitivity value. The receive sensitivity is expressed in dB and the value is relative to the
1263 maximum sensitivity. If the Reader does not allow control of receive sensitivity, a table
1264 of one entry is returned, the entry having the value of zero.

1265 If the Reader allows control of receive sensitivity and the Reader also supports multiple
1266 antennas where the antennas can have different receive sensitivity values, then the
1267 Receive Sensitivity Table should be a set of values representing the union of sensitivity
1268 values for all antennas.

1269 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1270 parameter.

ReceiveSensitivityTableEntry Parameter

Index: Unsigned Short Integer

Receive sensitivity value: Integer. The value is in dB relative to the maximum sensitivity.

Possible Values: 0 to 128.

1271 **9.2.1.2 PerAntennaReceiveSensitivityRange Parameter**

1272 For a particular antenna, this parameter specifies the Reader's valid index range in the
1273 Receive Sensitivity Table. A Reader should report this parameter if the Reader allows
1274 control of receive sensitivity (i.e., the Reader reports a Receive Sensitivity Table with
1275 more than one entry) and the Reader supports multiple antennas where the antennas can
1276 have different receive sensitivity values.

1277 If this parameter is omitted, then the Client SHALL assume that for all of the Reader's
1278 antennas the index range is the same as in the Receive Sensitivity Table.

1279 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1280 parameter.

PerAntennaReceiveSensitivityRange Parameter

Antenna ID: Unsigned Short Integer

Possible Values:

1 to N, where N is the maximum number of antennas supported by the device.

ReceiveSensitivityIndexMin: Unsigned Short Integer

Possible Values:

0 to S, where S is the number of Receive Sensitivity Table entries reported by the Reader.

ReceiveSensitivityIndexMax: Unsigned Short Integer

Possible Values:

Mn to S, where Mn is the ReceiveSensitivityIndexMin and S is the number of Receive Sensitivity Table entries reported by the Reader.

1281 **9.2.1.3 PerAntennaAirProtocol Parameter**

1282 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1283 parameter.

PerAntennaAirProtocol Parameter

Antenna ID: Unsigned Short Integer

Possible Values:

1 to N, where N is the maximum number of antennas supported by the device.

Air protocols supported: List of Protocol Ids enumerated based on Table 3.

1284 **9.2.1.4 GPIOCapabilities Parameter**

1285 This parameter describes the GPIO capabilities of the Reader. A value of zero for
1286 NumGPIs indicates that the Reader does not have general purpose inputs. A value of zero
1287 for NumGPOs indicates that the Reader does not have general purpose outputs.

1288

1289 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1290 parameter.

GPIOCapabilities Parameter

NumGPIs: Unsigned Short Integer. Number of general purpose inputs supported by the device.

NumGPOs: Unsigned Short Integer. Number of general purpose outputs supported by the device.

1291 **9.2.2 LLRPCapabilities Parameter**

1292 This parameter describes the LLRP protocol capabilities of the Reader. These include
1293 optional LLRP commands and parameters, capacities of data structures used in LLRP
1294 operations, and air protocol specific capabilities used by LLRP.

1295 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1296 parameter. Readers MAY support RFSurvey, MAY support tag inventory state aware
1297 singulation, MAY support UTC clocks, MAY support buffer fill warning reports, MAY
1298 support EventAndReportHolding upon reconnect, and MAY support
1299 ClientRequestOpspec. Readers SHALL support at least one ROSpec, one AISpec per
1300 ROSpec, one InventoryParameterSpec per AISpec, one AccessSpec, and one OpSpec per
1301 AccessSpec.

LLRPCapabilities Parameter

CanDoRFSurvey: Boolean. If set to true, the Reader can perform RFSurvey operations (Section 10.2.3).

CanDoTagInventoryStateAwareSingulation: Boolean. If set to true, the Reader can support tag inventory state aware singulation.

CanReportBufferFillWarning: Boolean. If set to true, the Reader can report buffer fill warning in the reader event notification (Section 13.2.6.5).

MaxNumROSpecs: Integer. If zero, there is no limit. This is the maximum number of ROSpecs that can be configured at the Reader.

MaxNumSpecsPerROSpec: Integer. If zero, there is no limit. This is the maximum number of Specs (either AISpec or RFSurveySpec) that can be configured as part of a

ROSpec at the Reader.

MaxNumInventoryParameterSpecsPerAISpec: Integer. If zero, there is no limit. This is the maximum number of InventoryParameterSpecs that can be configured per AISpec.

MaxPriorityLevelSupported: Integer. This is the maximum priority level supported in the reader. If set to less than or equal to 1, the Reader has no preemption support.

Possible Values: 0-7.

MaxNumAccessSpecs: Integer. If zero, there is no limit. This is the maximum number of AccessSpecs that can be configured at the Reader.

MaxNumOpSpecsPerAccessSpec: Integer. If zero, there is no limit. This is the maximum number of OpSpecs that can be configured per AccessSpec at the Reader.

SupportsClientRequestOpSpec: Boolean. If set to true, the Reader supports client request OpSpecs (Section 11.2.1.2.1).

ClientRequestOpSpecTimeout: Unsigned Short Integer (in milliseconds). The time the Reader will wait for the CLIENT_REQUEST_OP_RESPONSE from the Client after sending a RO_ACCESS_REPORT message upon executing the ClientRequestOpSpec OpSpec. This field is valid only if the Reader supports ClientRequestOpSpec (Section 11.2.1.2.1). If this field is 0, there is no limit.

SupportsEventAndReportHolding: Boolean. If set to True, the Reader supports the EventsAndReports Parameter and the ENABLE_EVENTS_AND_REPORTS message. If set to false, the Reader does not support the ENABLE_EVENTS_AND_REPORTS message or the EventsAndReports Parameter.

1302 **9.2.3 AirProtocolLLRPCapabilities Parameter**

1303 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1304 parameter.

AirProtocolLLRPCapabilities Parameter

Each air protocol's capabilities are expressed in a different LLRP Parameter. Each protocol's air protocol capabilities parameter SHALL be referenced not more than once. The air protocol specific capabilities LLRP Parameters are defined in section 15.1.

1305 **9.2.4 RegulatoryCapabilities Parameter**

1306 This parameter carries the RF regulation specific attributes. They include regulatory
1307 standard, frequency band information, power levels supported, frequencies supported,
1308 and any air protocol specific values that are determined based on regulatory restriction.

1309 The regulatory standard is encoded using two Integer fields, <Country Code,
1310 Communications standard> and it specifies the current operational regulatory mode of the
1311 device. This should not be used to reflect the ability to operate in regulatory
1312 environments which require configuration different from the current. This version of the
1313 LLRP protocol will have support for only the UHF band.

1314 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1315 parameter.

RegulatoryCapabilities Parameter

Country Code: Unsigned Short Integer. This field carries the numeric code of the country as specified in ISO 3166 [ISO3166]. 0 means unspecified.

Communications Standard: Unsigned Short Integer. This field carries the enumerations of the communications standard as specified below.

Possible Values:

Value	Communications Standard
0	Unspecified
1	US FCC Part 15
2	ETSI 302-208
3	ETSI 300-220
4	Australia LIPD 1W
5	Australia LIPD 4W
6	Japan: ARIB STD T89
7	Hong Kong: OFTA 1049
8	Taiwan: DGT LP0002
9	Korea: MIC Article 5-2
10-65535	Reserved for future use

UHFBandCapabilities: <UHFBandCapabilities Parameter> [optional]

Custom Extension Point List: List of <custom Parameter> [optional]

1316 **9.2.4.1 UHFBandCapabilities Parameter**

1317 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1318 parameter.

UHFBandCapabilities Parameter

TransmitPowerTable: List of <TransmitPowerLevelTableEntry Parameter>

Frequency Information: <FrequencyInformation Parameter>

UHF_RFModeTable: List of LLRP Parameter.

Possible Values:

Each air protocol's UHF RF mode table is expressed as a different LLRP parameter. Each protocol SHALL be referenced not more than once. The air protocol's UHF RF mode table capabilities LLRP Parameters are defined in section 15.1.

1319 **9.2.4.1.1 TransmitPowerLevelTableEntry Parameter**

1320 This parameter specifies the index into the TransmitPowerLevelTable for a transmit
1321 power value. The transmit power is expressed in dBm*100 to allow fractional dBm
1322 representation and is the conducted power at the connector of the Reader.

1323 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1324 parameter.

TransmitPowerLevelTableEntry Parameter

Index: Integer

Possible Values: 0-255

Transmit power value: Signed short integer. Transmit power expressed in dBm*100 to allow fractional dBm representation.

1325 **9.2.4.1.2 FrequencyInformation Parameter**

1326 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1327 parameter.

Frequency Information Parameter

Hopping: Boolean

Freq Hop Info: Zero or more instances of <FrequencyHopTable Parameter>. This is transmitted only when Hopping = true.

Fixed Freq Info: At most one instance of <FixedFrequencyTable>. This is transmitted only when Hopping = false.

1328 **9.2.4.1.2.1 FrequencyHopTable Parameter**

1329 This parameter carries the frequency hop table parameters. This is used for Readers
1330 operating in regions with frequency hopping regulatory requirements. If the Reader is
1331 capable of storing multiple hop tables, the Reader may send all of them to the Client.
1332 Each hop table contains:

- 1333 • HopTableID which is the index of the frequency hop table returned by the Reader.
- 1334 • This is followed by a list of the frequencies (in kHz) in hop table order. The one-
1335 based position of a frequency in the list is defined as its ChannelIndex (i.e. the
1336 first frequency is referred to as ChannelIndex one).

1337 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1338 parameter when operating in frequency hopping regulatory regions.

FrequencyHopTable Parameter

HopTableID : Integer

Possible Values: 0 - 255

Frequency Hop List: List of unsigned integers. Frequency in kHz.

1339 If multiple frequency hop tables are supported by the Reader, each table can be sent using
1340 a separate Frequency Hop Table Parameter.

1341 **9.2.4.1.2.2 FixedFrequencyTable Parameter**

1342 This parameter carries the fixed frequency list that can be used by the Reader. The one-
1343 based position of a frequency in the list is defined as its ChannelIndex (i.e. the first
1344 frequency is referred to as ChannelIndex one).

1345 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1346 parameter when operating in fixed frequency regulatory regions.

Fixed Frequency Parameter

Frequency List: List of unsigned integers. Frequency in kHz.

1347 **10 Reader Operation (RO)**

1348 This section presents the messages and the parameters used by the Client for specifying
1349 RO.

1350 **10.1 Messages**

1351 **10.1.1 ADD_ROSPEX**

1352 An ADD_ROSPEX message communicates the information of a *ROSPEX* to the Reader.
1353 LLRP supports configuration of multiple ROSPEXs. Each ROSPEX is uniquely identified
1354 using a ROSPEXID, generated by the Client. The *ROSPEX* starts at the Disabled state
1355 waiting for the ENABLE_ROSPEX message for the *ROSPEX* from the Client, upon which
1356 it transitions to the Inactive state.

1357 The Client SHALL add a ROSPEX in a Disabled State – i.e., CurrentState field in the
1358 ROSPEX Parameter (section 10.2.1) SHALL be set to disabled. If the CurrentState value
1359 is different than disabled, an error SHALL be returned in the
1360 ADD_ROSPEX_RESPONSE (e.g. P_FieldError).

1361 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1362 message.

ADD_ROSPEX

ROSPEX: ROSPEX Parameter

1363 **10.1.2 ADD_ROSPEX_RESPONSE**

1364 This is the response by the Reader to an ADD_ROSPEX message. If all the parameters
1365 specified in the ADD_ROSPEX command are successfully set, then the success code is
1366 returned in the LLRPStatus parameter. If there is an error, the appropriate error code is
1367 returned in the LLRPStatus parameter.

1368 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1369 message.

ADD_ROSPEX_RESPONSE

Response: LLRPStatus Parameter

1370 **10.1.3 DELETE_ROSPEC**

1371 This command is issued by the Client to the Reader. This command deletes the ROSpec
1372 at the Reader corresponding to ROSpecID passed in this message.

1373 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1374 message.

DELETE_ROSPEC

ROSpecID: Unsigned Integer. The identifier of the ROSpec to delete. 0 indicates to delete all ROSpecs.

1375 **10.1.4 DELETE_ROSPEC_RESPONSE**

1376 This is the response by the Reader to a DELETE_ROSPEC command. If there was a
1377 ROSpec corresponding to the ROSpecID that the Reader was presently executing, and
1378 the Reader was successful in stopping that execution, then the success code is returned in
1379 the LLRPStatus parameter. If there is an error, the appropriate error code is returned in
1380 the LLRPStatus parameter.

1381 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1382 message.

DELETE_ROSPEC_RESPONSE

Response: LLRPStatus Parameter

1383 **10.1.5 START_ROSPEC**

1384 This message is issued by the Client to the Reader. Upon receiving the message, the
1385 Reader starts the ROSpec corresponding to ROSpecID passed in this message, if the
1386 ROSpec is in the enabled state.

1387 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1388 message.

START_ROSPEC

ROSpecID: Unsigned Integer. The identifier of the ROSpec to start.

Possible Values: 0 is disallowed.

1389 **10.1.6 START_ROSPEC_RESPONSE**

1390 This is the response by the Reader to a START_ROSPEC command. If there was a
1391 ROSpec corresponding to the ROSpecID in the enabled state, and the Reader was able to
1392 start executing that ROSpec, then the success code is returned in the LLRPStatus
1393 parameter. If there is an error, the appropriate error code is returned in the LLRPStatus
1394 parameter.

1395 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1396 message.

START_ROSPEC_RESPONSE

Response: LLRPStatus Parameter

1397 10.1.7 STOP_ROSPEC

1398 This message is issued by the Client to the Reader. Upon receiving the message, the
1399 Reader stops the execution of the ROSpec corresponding to the ROSpecID passed in this
1400 message. STOP_ROSPEC overrides all other priorities and stops the execution. This
1401 basically moves the ROSpec's state to Inactive. This message does not delete the
1402 ROSpec.

1403 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1404 message.

STOP_ROSPEC

ROSpecID: Unsigned Integer. The identifier of the ROSpec to stop.

Possible Values: 0 is disallowed.

1405 10.1.8 STOP_ROSPEC_RESPONSE

1406 This is the response by the Reader to a STOP_ROSPEC command. If the Reader was
1407 currently executing the ROSpec corresponding to the ROSpecID, and the Reader was
1408 able to stop executing that ROSpec, then the success code is returned in the LLRPStatus
1409 parameter. If there is an error, the appropriate error code is returned in the LLRPStatus
1410 parameter.

1411 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1412 message.

STOP_ROSPEC_RESPONSE

Response: LLRPStatus Parameter

1413 10.1.9 ENABLE_ROSPEC

1414 This message is issued by the Client to the Reader. Upon receiving the message, the
1415 Reader moves the ROSpec corresponding to the ROSpecID passed in this message from
1416 the disabled to the inactive state.

1417 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1418 message.

ENABLE_ROSPEC

ROSpecID: Unsigned Integer. The identifier of the ROSpec to enable. If set to 0, all
ROSpecs are enabled.

1419 **10.1.10 ENABLE_ROSPEC_RESPONSE**

1420 This is the response by the Reader to a ENABLE_ROSPEC command. If there was a
1421 ROSpec corresponding to the ROSpecID, and the Reader was able to enable that
1422 ROSpec, then the success code is returned in the LLRPStatus parameter. If there is an
1423 error, the appropriate error code is returned in the LLRPStatus parameter.

1424 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1425 message.

ENABLE_ROSPEC_RESPONSE

Response: LLRPStatus Parameter

1426 **10.1.11 DISABLE_ROSPEC**

1427 This message is issued by the Client to the Reader. Upon receiving the message, the
1428 Reader moves the ROSpec corresponding to the ROSpecID passed in this message to the
1429 disabled state.

1430 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1431 message.

DISABLE_ROSPEC

ROSpecID: Unsigned Integer. The identifier of the ROSpec to disable. If set to 0, all
ROSpecs are disabled.

1432 **10.1.12 DISABLE_ROSPEC_RESPONSE**

1433 This is the response by the Reader to a DISABLE_ROSPEC command. If there was a
1434 ROSpec corresponding to the ROSpecID, and the Reader was able to disable that
1435 ROSpec, then the success code is returned in the LLRPStatus parameter. If there is an
1436 error, the appropriate error code is returned in the LLRPStatus parameter.

1437 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1438 message.

DISABLE_ROSPEC_RESPONSE

Response: LLRPStatus Parameter

1439 **10.1.13 GET_ROSPECS**

1440 This is the request from the Client to the Reader to retrieve all the ROSpecs that have
1441 been configured at the Reader.

1442 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1443 message.

GET_ROSPECS

1444 **10.1.14 GET_ROSPECS_RESPONSE**

1445 This is the response by the Reader to a GET_ROSPECS command. If there are no
1446 ROSpecs configured at the Reader, the response is just the LLRPStatus parameter with
1447 the success code. Else, a list of ROSpec parameter is returned by the Reader, along with
1448 the success code in the LLRPStatus parameter.

1449 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1450 message.

GET_ROSPECS_RESPONSE
Status: LLRPStatus Parameter
Response: List of <ROSpec Parameter> that are in the order in which they are added.

1451 **10.2 Parameters**

1452 **10.2.1 ROSpec Parameter**

1453 This parameter carries the information of the Reader inventory and survey operation.

1454 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1455 parameter.

ROSpec Parameter
ROSpecID: Unsigned Integer; 0 is an illegal ROSpecID for a ROSpec.
Priority: Integer. Lower numbered priority values are given higher priority.
Possible Values: 0-7.
CurrentState: Integer
Possible Values:

Value	Definition
-----	-----
0	Disabled
1	Inactive
2	Active

ROBoundarySpec: ROBoundarySpec Parameter **ListOfSpecs:** List of <AISpec Parameter> and/or <RFSurveySpec Parameter> and/or Custom Parameter.
ROReportSpec: ROReportSpec Parameter [optional] (Section 13.2.1)

1456 **10.2.1.1 ROBoundarySpec Parameter**

1457 This parameter carries the lifetime of the command, ROStartTrigger and ROStopTrigger
1458 parameters.

1459 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1460 parameter.

ROBoundarySpec Parameter

ROSpecStartTrigger: ROSpecStartTrigger Parameter

ROSpecStopTrigger: ROSpecStopTrigger Parameter

1461 10.2.1.1.1 *ROSpecStartTrigger Parameter*

1462 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1463 parameter.

ROSpecStartTrigger Parameter

ROSpecStartTriggerType: Integer

Possible Values:

Value	Definition
0	Null - No start trigger. The only way to start the ROSpec is with a START_ROSPEC from the Client.
1	Immediate
2	Periodic
3	GPI

PeriodicTriggerValue: PeriodicTriggerValue Parameter [Optional]. This parameter SHALL be present when ROSpecStartTriggerType = 2.

GPITriggerValue: GPITriggerValue Parameter [Optional]. This parameter SHALL be present when ROSpecStartTriggerType = 3.

1464 10.2.1.1.1.1 *PeriodicTriggerValue Parameter*

1465 Periodic trigger is specified using UTC time, offset and period.

1466 For one-shot inventory, period is set to 0, and for periodic inventory operation period > 0.

1467 If UTC time is not specified, the first start time is determined as (time of message receipt
1468 + offset), else, the first start time is determined as (UTC time + offset). Subsequent start
1469 times = first start time + k * period (where, k > 0).

1470 If the Reader does not support UTC clock (as indicated by HasUTCClockCapability), and
1471 it receives the UTC time as part of the PeriodicTriggerValue parameter from the Client,
1472 the Reader SHALL return an error.

1473 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1474 parameter. Compliant Readers and Clients MAY implement the UTCTimestamp
1475 parameter.

PeriodicTriggerValue Parameter

UTC Time: <UTCTimestamp Parameter> [Optional]

Offset: Unsigned Integer. Time offset specified in milliseconds.

Period: Unsigned Integer. Time period specified in milliseconds

1476 **10.2.1.1.1.2 GPITriggerValue Parameter**
 1477 This trigger is tied to an event on the General Purpose Input (GPI) of the Reader. The
 1478 event is represented as a boolean type, and it is up to the internal implementation of the
 1479 Reader to map exact physical event to a boolean type. For example, a 0 → 1 and a 1 → 0
 1480 transition on an input pin of the Reader could be mapped to a boolean true and a boolean
 1481 false event respectively.

1482 This trigger parameter has a timeout value field. The timeout is useful for specifying a
 1483 fail-safe timeout when this trigger is used as a stop trigger. When the timeout is 0, it
 1484 indicates that there is no timeout. When used as a start trigger, the timeout value SHALL
 1485 be ignored.

1486 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1487 parameter. Readers that do not support GPIs SHALL return zero for numGPIs in the
 1488 capabilities discovery. If the Client sets up the GPI trigger for such a Reader, the Reader
 1489 SHALL send an error message for the ADD_ROSPEC message and not add the ROSpec.

GPITriggerValue Parameter

GPIPortNum: Unsigned Short Integer.
Possible Values: 1-65535. Zero is invalid.

GPIEvent: Boolean. The Boolean value that causes a GPI event to trigger.

Timeout: Unsigned Integer. Trigger timeout in milliseconds. If set to zero, it indicates there is no timeout.

1490 **10.2.1.1.2 ROSpecStopTrigger Parameter**
 1491 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1492 parameter.

ROSpecStopTrigger Parameter

ROSpecStopTriggerType: Integer
Possible Values:

Value	Definition
-----	-----
0	Null - Stop when all AISpecs are done, or when Preempted, or with a STOP_ROSPEC from the Client.
1	Duration
2	GPI with a timeout value

DurationTriggerValue: Duration in milliseconds. This field is ignored when ROSpecStopTriggerType != 1.

GPITriggerValue: GPITriggerValue Parameter [Optional]. This parameter SHALL be present when ROSpecStopTriggerType = 2.

1493 **10.2.2 AISpec Parameter**
 1494 This parameter defines antenna inventory operations.

1495 **Compliance Requirement:** Compliant Readers and Clients SHALL implement this
 1496 parameter.

AISpec Parameter

AISpecStopTrigger: <AISpecStopTrigger Parameter>

AntennaIDs: Short Array. If this set contains an antenna ID of zero, this AISpec will utilize all the antennas of the Reader.

InventoryParameterSpecs: <List of InventoryParameterSpec Parameter>

Custom Extension Point List: List of <custom Parameter> [Optional]

1497 **10.2.2.1 AISpecStopTrigger Parameter**

1498 This parameter defines the stop (i.e., terminating boundary) of an antenna inventory
 1499 operation.

1500 **Compliance Requirement:** Compliant Readers and Clients SHALL implement this
 1501 parameter. If a Reader reports NumGPIS (see GPIO Capabilities Parameter) greater than
 1502 zero, then the Reader SHALL support GPI Trigger.

AISpecStopTrigger Parameter

AISpecStopTriggerType: Integer

Possible Values:

Value	Definition
-----	-----
0	Null - Stop when ROSpec is done.
1	Duration
2	GPI with a timeout value
3	Tag observation

Duration Trigger: Unsigned Integer. Duration of AISpec in milliseconds. This field SHALL be ignored when AISpecStopTriggerType != 1.

GPI Trigger : GPITrigger value Parameter [Optional]. This field SHALL be present when AISpecStopTriggerType = 2.

TagObservation Trigger : TagObservation Trigger Parameter [Optional]. This field SHALL be present when AISpecStopTriggerType = 3.

1503 **10.2.2.1.1 TagObservationTrigger Parameter**

1504 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1505 parameter.

Tag ObservationTrigger Parameter

TriggerType: Integer

Possible Values:

Value	Modulation
-----	-----
0	Upon seeing N tag observations, or timeout

- | | |
|---|---|
| 1 | Upon seeing no more new tag observations for t ms, or timeout |
| 2 | N attempts to see all tags in the FOV, or timeout |

NumberOfTags: Unsigned Short Integer. This field SHALL be ignored when TriggerType != 0.

NumberOfAttempts: Unsigned Short Integer. This field SHALL be ignored when TriggerType != 2.

T : Unsigned Short Integer. Idle time between tag responses in milliseconds. This field SHALL be ignored when TriggerType != 1.

Timeout : Unsigned Integer; Trigger timeout value in milliseconds. If set to zero, it indicates that there is no timeout.

1506 **10.2.2.2 InventoryParameterSpec Parameter**

1507 This parameter defines the inventory operation to be performed at all antennas specified
 1508 in the corresponding AISpec. This parameter is composed of
 1509 an InventoryParameterSpecID, a ProtocolID, and zero or more optional antenna
 1510 configuration parameters. Antenna configurations for antennas not indicated by the
 1511 AntennaIDs within the AISpec are ignored by the reader.

1512
 1513 **Compliance Requirement:** Compliant Readers and Clients SHALL implement this
 1514 parameter.

<p>InventoryParameterSpec Parameter</p> <p>InventoryParameterSpecID: Unsigned Short Integer. 0 is illegal.</p> <p>ProtocolID: Integer. Enumeration based on Table 3.</p> <p>AntennaConfiguration: List of <AntennaConfiguration Parameter> (Section 12.2.6) [Optional]</p> <p>Custom Extension Point List: List of <Custom Parameter> [Optional]</p>

1515 **10.2.3 RFSurveySpec Parameter**

1516 This parameter defines RF Survey operations. RF Survey is an operation during which
 1517 the Reader performs a scan and measures the power levels across a set of frequencies at
 1518 an antenna. This parameter defines the identifier of the antenna where this survey is to be
 1519 performed, the duration of the survey operation (specified via stop trigger), and the range
 1520 of frequencies to measure power levels of.

1521 **Compliance Requirement:** Compliant Readers and Clients MAY implement this
 1522 parameter.

<p>RFSurveySpec Parameter</p> <p>Antenna ID: Unsigned Short Integer.</p> <p><i>Possible Values:</i> 1 to N, where N is the maximum number of antennas supported</p>

by the Reader.

RFSurveySpecStopTrigger: RFSurveySpecStopTrigger parameter

StartFrequency: Unsigned Integer. The start (lower bound) frequency to survey specified in kHz.

EndFrequency: Unsigned Integer in kHz. The end (upper bound) frequency to survey specified in kHz.

Custom Extension Point List: List of <custom Parameter> [Optional]

1523 10.2.3.1 RFSurveySpecStopTrigger Parameter

1524 This parameter defines the stop trigger for RF Survey operations.

1525 **Compliance Requirement:** Compliant Readers and Clients MAY implement this
1526 parameter.

RFSurveySpecStopTrigger Parameter

StopTriggerType: Integer

Possible Values:

Value	Definition
-----	-----
0	Null
1	Duration
2	N iterations through the frequency range

Duration: Unsigned Integer; The maximum duration of the RFSurvey operation specified in milliseconds. This field SHALL be ignored when StopTriggerType != 1. When StopTriggerType = 1, the value SHALL be greater than zero.

N: Unsigned Integer. The maximum number of iterations through the specified frequency range. This field SHALL be ignored when StopTriggerType != 2. When StopTriggerType = 2, the value SHALL be greater than zero.

1527 11 Access Operation

1528 This section presents the messages and the parameters used by the Client for specifying
1529 access operation.

1530 11.1 Messages

1531 11.1.1 ADD_ACCESSSPEC

1532 This command creates a new AccessSpec at the Reader. The *AccessSpec* starts at the
1533 Disabled state waiting for the ENABLE_ACCESSSPEC message for the *AccessSpec*
1534 from the Client, upon which it transitions to the Active state. The AccessSpecID is
1535 generated by the Client.

1536 The Client SHALL add an AccessSpec in a Disabled State – i.e., CurrentState field in the
1537 AccessSpec Parameter (section 11.2.1) SHALL be set to false. If the CurrentState value

1538 is different than false, an error SHALL be returned in the
1539 ADD_ACCESSSPEC_RESPONSE (e.g. P_FieldError).

1540 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1541 message.

ADD_ACCESSSPEC

AccessSpec: AccessSpec parameter

1542 **11.1.2 ADD_ACCESSSPEC_RESPONSE**

1543 This is the response by the Reader to an ADD_ACCESSSPEC command. If the
1544 parameters passed in that ADD_ACCESSSPEC command were successfully accepted
1545 and set at the Reader, then the success code is returned in the LLRPStatus parameter.
1546 However, if the *AccessSpec* was not successfully created at the Reader, the Reader sends
1547 a LLRPStatus parameter describing the error in the message.

1548 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1549 message.

ADD_ACCESSSPEC_RESPONSE

Response: LLRPStatus Parameter

1550 **11.1.3 DELETE_ACCESSSPEC**

1551 This command is issued by the Client to the Reader. The Reader deletes the AccessSpec
1552 corresponding to the AccessSpecId, and this AccessSpec will stop taking effect from the
1553 next inventory round.

1554 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1555 message.

DELETE_ACCESSSPEC

AccessSpecID : Unsigned Integer.

Possible Values: If set to 0, all AccessSpecs are deleted.

1556 **11.1.4 DELETE_ACCESSSPEC_RESPONSE**

1557 This is the response by the Reader to a DELETE_ACCESSSPEC command. If there was
1558 an AccessSpec at the Reader corresponding to the AccessSpecID passed in the
1559 DELETE_ACCESSSPEC command, and the Reader was successful in deleting that
1560 AccessSpec, then the success code is returned in the LLRPStatus parameter. If there is an
1561 error, the appropriate error code is returned in the LLRPStatus parameter.

1562 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1563 message.

DELETE_ACCESSSPEC_RESPONSE

Response: LLRPStatus Parameter

1564 11.1.5 ENABLE_ACCESSSPEC

1565 This message is issued by the Client to the Reader. Upon receiving the message, the
1566 Reader moves the AccessSpec corresponding to the AccessSpecID in this message from
1567 the Disabled state to the Active state. The Reader executes this access-spec until it gets a
1568 DISABLE_ACCESSSPEC or a DELETE_ACCESSSPEC from the Client. The
1569 AccessSpec takes effect with the next (and subsequent) inventory rounds.

1570 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1571 message.

ENABLE_ACCESSSPEC

AccessSpecID: Unsigned Integer. If set to 0, all AccessSpecs are enabled.

1572 11.1.6 ENABLE_ACCESSSPEC_RESPONSE

1573 This is the response by the Reader to a START_ACCESSSPEC command. If there was
1574 an AccessSpec corresponding to the AccessSpecID, and the Reader was able to move that
1575 AccessSpec from the disabled to the active state, then the success code is returned in the
1576 LLRPStatus parameter. If there is an error, the appropriate error code is returned in the
1577 LLRPStatus parameter.

1578 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1579 message.

ENABLE_ACCESSSPEC_RESPONSE

Response: LLRPStatus Parameter

1580 11.1.7 DISABLE_ACCESSSPEC

1581 This message is issued by the Client to the Reader. Upon receiving the message, the
1582 Reader stops the execution of the AccessSpec corresponding to AccessSpecID in this
1583 message. This basically moves the AccessSpec's state to Disabled. This message does not
1584 delete the AccessSpec. The AccessSpec will stop taking effect from the next inventory
1585 round.

1586 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1587 message.

DISABLE_ACCESSSPEC

AccessSpecID: Unsigned Integer. If set to 0, all AccessSpecs are disabled.

1588 **11.1.8 DISABLE_ACCESSSPEC_RESPONSE**

1589 This is the response by the Reader to a STOP_ACCESSSPEC command. If the Reader
1590 was currently executing the AccessSpec corresponding to the AccessSpecID, and the
1591 Reader was able to disable that AccessSpec, then the success code is returned in the
1592 LLRPStatus parameter. If there is an error, the appropriate error code is returned in the
1593 LLRPStatus parameter.

1594 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1595 message.

DISABLE_ACCESSSPEC_RESPONSE

Response: LLRPStatus Parameter

1596 **11.1.9 GET_ACCESSSPECS**

1597 This is the request from the Client to the Reader to retrieve all the AccessSpecs that have
1598 been configured at the Reader.

1599 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1600 message.

GET_ACCESSSPECS

1601 **11.1.10 GET_ACCESSSPECS_RESPONSE**

1602 This is the response by the Reader to a GET_ACCESSSPECS command. If there are no
1603 AccessSpecs configured at the Reader, the response is just the LLRPStatus parameter
1604 with the success code. Else, a list of <AccessSpecID, AccessSpec parameter> is returned
1605 by the Reader, along with the LLRPStatus parameter containing the success code. The
1606 order of the AccessSpecs listed in the message is normatively the order in which the
1607 AccessSpecs were created at the Reader.

1608 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1609 message.

GET_ACCESSSPECS_RESPONSE

Status: LLRPStatus Parameter

Response: List of <AccessSpec Parameter>. The ordering of the AccessSpecs in this list is the order in which the AccessSpecs were created at the Reader.

1610 **11.1.11 CLIENT_REQUEST_OP**

1611 This message is sent by the Reader to the Client upon executing a ClientRequestOpSpec
1612 OpSpec (section 11.2.1.2.1). This message carries the TagReportData (section 13.2.3)
1613 that contains information collected for the tag which includes singulation results and the
1614 results of OpSpecs executed till that point.

1615 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1616 message.

CLIENT_REQUEST_OP

TagReport: <TagReportData Parameter> (Section 13.2.3)

1617 **11.1.12 CLIENT_REQUEST_OP_RESPONSE**

1618 This is the response by the Client to the Reader. This is in response to the
1619 CLIENT_REQUEST_OP sent by the Reader due to the execution of a
1620 ClientRequestOpSpec. This is a response to the CLIENT_REQUEST_OP message; thus,
1621 the messageID in this message is the messageID of the CLIENT_REQUEST_OP.

1622 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1623 message. Readers that do not support ClientRequestOpSpec MAY ignore this message.

CLIENT_REQUEST_OP_RESPONSE

Response: ClientRequestResponse Parameter

1624

1625 **11.2 Parameters**

1626 **11.2.1 AccessSpec Parameter**

1627 This parameter carries information of the Reader access operation.

1628 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1629 parameter.

AccessSpec Parameter

AccessSpecID: Unsigned Integer. 0 is illegal.

Antenna ID: Unsigned Short Integer. If 0, this spec is operational on all antennas.

ProtocolID: Integer.

Possible Values: Enumeration based on Table 3.

CurrentState: Boolean. This is the current state of the AccessSpec. false = Disabled,
true = Active.

ROSpecID: Unsigned Integer. If 0, this spec is operational for all ROSpecs.

AccessSpecStopTrigger: AccessSpecStopTrigger Parameter

Access Command Operation: AccessCommand Parameter

AccessReportSpec: AccessReportSpec Parameter [Optional]

Custom Extension Point List: List of <custom Parameter> [Optional]

1630 **11.2.1.1 AccessSpecStopTrigger Parameter**
 1631 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1632 parameter.

AccessSpecStopTrigger Parameter

AccessSpecStopTriggerType: Integer

Possible Values:

Value	Definition
-----	-----
0	Null - No stop trigger defined.
1	Operation count

OperationCountValue: Unsigned Short Integer. A count to indicate the number of times this Spec is executed before it is deleted. If set to 0, this is equivalent to no stop trigger defined.

1633 **11.2.1.2 AccessCommand Parameter**
 1634 This parameter defines the air protocol access-specific settings. It contains a TagSpec and
 1635 an OpSpec Parameter. The TagSpec specifies the tag filters in terms of air protocol
 1636 specific memory capabilities (e.g., memory banks, pointer and length). The OpSpec
 1637 specifies all the details of the operations required for the air protocol specific access
 1638 operation commands.
 1639 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1640 parameter.

AccessCommand Parameter

TagSpec: LLRP Parameter

Possible Values:

Each air protocol's TagSpec parameter is expressed as a different LLRP Parameter. The air protocol specific TagSpec LLRP Parameters are defined in section 15.1. This field carries a single TagSpec parameter corresponding to the air protocol referenced by the ProtocolID in the AccessSpec Parameter.

OpSpec: List of LLRP Parameters

Possible Values:

Each parameter can be either an air protocol specific OpSpec LLRP Parameter or a <ClientRequestOpSpec Parameter>.

Regarding the air protocol specific OpSpec LLRP Parameter: Each air protocol's OpSpec parameter is expressed as a different LLRP Parameter. The air protocol specific OpSpec LLRP Parameters are defined in section 15.1. The list of OpSpecs in this field is comprised of OpSpec parameters corresponding to the air protocol referenced by the ProtocolID in the AccessSpec Parameter.

Custom Extension Point List: List of <Custom Parameter> [Optional]

1641

1642 In case there are multiple AccessSpecs that get matched during a TagSpec lookup, the
1643 Reader SHALL only execute the first enabled AccessSpec that matches, where the
1644 ordering of the AccessSpecs is the order in which the AccessSpecs were created by the
1645 Client.

1646 The order of execution of OpSpecs within an AccessSpec is the order in which the
1647 OpSpecs were set up in the AccessSpec. If an OpSpec execution fails, the Reader
1648 SHALL stop the execution of the AccessSpec.

1649 **11.2.1.2.1 ClientRequestOpSpec Parameter**

1650 This parameter is sent as part of the possible values for the AccessSpec OpSpec list. One
1651 or more ClientRequestOpSpec operations may be performed on a tag in succession.
1652 Upon executing a ClientRequestOpSpec Parameter, a Reader will immediately send the
1653 CLIENT_REQUEST_OP message to the Client. This CLIENT_REQUEST_OP message
1654 carries the TagReportData (section 13.2.3) that contains information collected for the tag
1655 which includes singulation results and the results of OpSpecs executed till that point.

1656 A global timeout is associated with this request. If the Client does not return a
1657 ClientRequestResponse within the *ClientRequestOpSpecTimeout* (LLRP Capabilities)
1658 period, or the AirProtocolOpSpec List is empty in the ClientRequestResponse, the
1659 execution of the AccessSpec is cancelled.

1660 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1661 parameter. Readers that do not support ClientRequestOpSpec SHALL set
1662 SupportClientRequestOpSpec to false in LLRPCapabilities. If such a Reader receives an
1663 ADD_ACCESSSPEC with an AccessSpec that contained this OpSpec parameter, the
1664 Reader SHALL return an error for that message, and not add the AccessSpec.

ClientRequestOpSpec Parameter

OpSpecID: Unsigned Short Integer.

Possible Values: 0 is an illegal value.

1665 **11.2.2 ClientRequestResponse Parameter**

1666 This parameter describes the list of OpSpecs that the Reader has to execute on the tag for
1667 which a Client request was initiated. The AccessSpecID is the identifier of the
1668 AccessSpec that had the Client request; the EPC data is the singulated data of the tag for
1669 which this Client request was initiated. The AirProtocolOpSpec list contained in the
1670 ClientRequestResponse SHALL be processed as the next OpSpecs sent over the air
1671 interface. If the AirProtocolOpSpec List is empty, then the execution of the AccessSpec
1672 specified by AccessSpecID is cancelled.

1673 **Compliance requirement:** Compliant Readers MAY implement this parameter. Readers
1674 that do not support ClientRequestOpSpec MAY ignore this parameter.

ClientRequestResponse Parameter

AccessSpecID: Unsigned Integer. The ID of the AccessSpec that triggered this request.

EPCdata: <EPCData Parameter>. The electronic product code of the RFID tag that triggered this request.

AirProtocolOpSpecList: List of LLRP OpSpec Parameter.

Possible Values:

Each air protocol's OpSpec parameter is expressed as a different LLRP Parameter. The air protocol specific OpSpec LLRP Parameters are defined in section 15.1. This field carries a list of OpSpec parameters corresponding to the air protocol referenced by ProtocolID in the AccessSpec that generated the Client request.

1675 12 Reader Device Configuration

1676 This section contains the messages and parameters for getting and setting configuration.

1677 12.1 Messages

1678 12.1.1 GET_READER_CONFIG

1679 This command is issued by the Client to get the current configuration information of the
1680 Reader. The Requested Data passed in the command represents the parameter(s) of
1681 interest to the Client that has to be returned by the Reader.

1682 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1683 message.

GET_READER_CONFIG

RequestedData : Integer

Possible Values:

Value	Requested Data
0	All
1	Identification
2	AntennaProperties
3	AntennaConfiguration
4	ROReportSpec
5	ReaderEventNotificationSpec
6	AccessReportSpec
7	LLRPConfigurationStateValue
8	KeepaliveSpec
9	GPIPortCurrentState
10	GPOWriteData
11	EventsAndReports

AntennaID: Unsigned Short Integer. This field is ignored when RequestedData != 0 or 2 or 3. If the AntennaID is 0, get antenna information (AntennaProperties, AntennaConfiguration) for all antennas.

GPIPortNum: Unsigned Short Integer. This field is ignored when RequestedData != 0 or 9. If the GPIPortNum is 0, get GPI port current state for all GPI ports.

GPOPortNum: Unsigned Short Integer. This field is ignored when RequestedData != 0 or 10. If the GPOPortNum is 0, get GPO port current state for all GPO ports.

Custom Extension Point List: List of <custom Parameter> [Optional]

1684 **12.1.2 GET_READER_CONFIG_RESPONSE**

1685 This is the response by the Reader to the GET_READER_CONFIG message. The
1686 response is the LLRPStatus Parameter and the list of configuration parameters based on
1687 the RequestedData in GET_READER_CONFIG. If the GET_READER_CONFIG
1688 message did not have any errors, the success code is returned in the LLRPStatus
1689 parameter, and in addition the requested configuration parameters are returned. If there is
1690 an error, the appropriate error code is returned in the LLRPStatus parameter. The
1691 response contains at most one instance of each configuration parameter except for two
1692 cases, which are as follows:

- 1693 • If RequestedData is 0, 2 or 3, and AntennaID is set to 0 in the
1694 GET_READER_CONFIG message, the Reader SHALL return one instance of
1695 AntennaProperties Parameter or AntennaConfiguration Parameter per requested
1696 antenna.
- 1697 • If RequestedData is 0 or 9 (10), and GPIPortNum (GPOPortNum) is set to 0 in the
1698 GET_READER_CONFIG message, and, if the Reader supports GPI (GPO), the
1699 Reader SHALL return one instance of GPIPortCurrentState (GPOWriteData)
1700 Parameter per requested GPI Port (GPO Port).

1701 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1702 message.

GET_READER_CONFIG_RESPONSE

Status: LLRPStatus Parameter

Response Data: Set of LLRP Parameters.

Possible Values: The possible members are zero or more of

```
{< LLRPConfigurationStateValue Parameter>,  
 <ReaderEventNotificationSpec Parameter>,  
 <Antenna Properties Parameter>,  
 <Antenna Configuration Parameter>,  
 <ROReportSpec Parameter>,  
 <AccessReportSpec Parameter>,  
 <Identification Parameter>,  
 <KeepaliveSpec Parameter>,  
 <GPIPortCurrentState Parameter>,  
 <GPOWriteData Parameter>,  
 <EventsAndReports Parameter>  
}
```

Custom Extension Point List: List of <custom Parameter> [Optional]

1703 12.1.3 SET_READER_CONFIG

1704 This command is issued by the Client to the Reader. This command sets the Reader
1705 configuration using the parameters specified in this command. Values passed by the
1706 SET_READER_CONFIG SHALL apply for the duration of the LLRP connection, or
1707 until the values are changed by additional SET_READER_CONFIG messages.

1708 For example, ROReportSpec defines the reporting of ROReport format and trigger for a
1709 ROSpec. ROReportSpec sent as part of SET_READER_CONFIG becomes the default
1710 ROReportSpec for the Reader. A ROReportSpec sent as part of ROSpec in the
1711 ADD_ROSPEC command overrides the default value for that ROSpec. However, in
1712 cases where there is no ROReportSpec specified in a ROSpec sent as part of
1713 ADD_ROSPEC, that particular ROSpec inherits the default ROReportSpec.

1714 The data field ResetToFactoryDefault informs the Reader to set all configurable values to
1715 factory defaults before applying the remaining parameters.

1716 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1717 message.

SET_READER_CONFIG

ResetToFactoryDefault: Boolean. If true, the Reader will set all configurable values to factory defaults before applying the remaining parameters.

Configuration Data: Set of LLRP Parameters

Possible Values: The possible members of the set are

{<ReaderEventNotificationSpec Parameter>,
<Antenna Properties Parameter>,
<Antenna Configuration Parameter>,
<ROReportSpec Parameter>,
<AccessReportSpec Parameter>,
<KeepaliveSpec Parameter>,
<GPOWriteData Parameter>,
<GPIPortCurrentState Parameter>,
<EventsAndReports Parameter>}

Custom Extension Point List: List of <custom Parameter> [Optional]

1718 12.1.4 SET_READER_CONFIG_RESPONSE

1719 This is the response by the Reader to a SET_READER_CONFIG command. If all the
1720 parameters specified in the SET_READER_CONFIG command are successfully set, then
1721 the success code is returned in the LLRPStatus parameter. If there is an error, the
1722 appropriate error code is returned in the LLRPStatus parameter.

1723 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1724 message.

SET_READER_CONFIG_RESPONSE

Response: < LLRPStatus Parameter>

1725 12.1.5 CLOSE_CONNECTION

1726 This command is issued by the Client to the Reader. This command instructs the Reader
1727 to gracefully close its connection with the Client. Under normal operating conditions, a
1728 Client SHALL attempt to send this command before closing an LLRP connection. A
1729 Client should wait briefly for the Reader to respond with a
1730 CLOSE_CONNECTION_RESPONSE.

1731 Upon receipt of this command, the Reader SHALL respond with the
1732 CLOSE_CONNECTION_REPONSE message and it should then attempt to close the
1733 connection between the Reader and Client.

1734 Having executed a CLOSE_CONNECTION command, a Reader MAY persist its
1735 configuration state as defined by the ReaderConfigurationStateValue parameter specified
1736 in section 12.2.1.

1737 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1738 message.

CLOSE_CONNECTION

1739 12.1.6 CLOSE_CONNECTION_RESPONSE

1740 This is the response by the Reader to a CLOSE_CONNECTON command from the
1741 Client. Upon receiving a CLOSE_CONNECTION command, the Reader SHALL
1742 attempt to send this response to the Client. After attempting to send this response, the
1743 Reader SHALL close its connection with the Client.

1744 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1745 message.

CLOSE_CONNECTION_RESPONSE

Status: <LLRPStatus Parameter>

1746

1747 12.2 Parameters

1748 12.2.1 LLRPConfigurationStateValue Parameter

1749 This parameter, LLRPConfigurationStateValue, is a 32-bit value which represents a
1750 Reader's entire LLRP configuration state including: LLRP configuration parameters,
1751 vendor extension configuration parameters, ROSpecs, and AccessSpecs. A Reader
1752 SHALL change this value only:

- 1753 • Upon successful execution of any of the following messages:
 - 1754 ○ ADD_ROSPEX
 - 1755 ○ DELETE_ROSPEX
 - 1756 ○ ADD_ACCESSSPEC
 - 1757 ○ DELETE_ACCESSSPEC
 - 1758 ○ SET_READER_CONFIG
 - 1759 ○ Any CUSTOM_MESSAGE command that alters the reader's internal
1760 configuration.
- 1761 • Upon an automatically deleted AccessSpec due to completion of
1762 OperationCountValue number of operations (Section 11.2.1.1).

1763 A Reader SHALL not change this value when the CurrentState of a ROSpec or
1764 AccessSpec changes.

1765 The mechanism used to compute the LLRP configuration state value is implementation
1766 dependent. However, a good implementation will insure that there's a high probability
1767 that the value will change when the Reader's configuration state changes.

1768 It is expected that a Client will configure the Reader and then request the Reader's
1769 configuration state value. The Client will then save this state value. If this value does not
1770 change between two requests for it, then a Client may assume that the above components
1771 of the LLRP configuration have also not changed.

1772

1773 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1774 parameter. When requested by a Client, the Reader SHALL compute a state value based
1775 upon the Reader's current configuration state. Upon each request, the Reader SHALL
1776 return the same state value provided a Client has not altered the Reader's configuration
1777 state between requests. Aside from this requirement, the computation of the state value is
1778 implementation dependent.

LLRPConfigurationStateValue Parameter

LLRPConfigurationStateValue: Unsigned Integer

1779 **12.2.2 Identification Parameter**

1780 This parameter carries an identification parameter that is unique within the local
1781 administration domain. The identifier could be the Reader MAC address or EPC. The
1782 IDType defines the type of the identification value contained in this Parameter.

1783 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1784 parameter.

Identification Parameter

IDType: Integer

Possible Values:

IDType	ID
0	MAC address
1	EPC

Reader ID: Byte array. If IDType=0, the MAC address SHALL be encoded as EUI-64.[EUI64]

1785 **12.2.3 GPOWriteData Parameter**

1786 This parameter carries the data pertinent to perform the write to a general purpose output
1787 port.

1788 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1789 parameter. Readers that do not support GPOs SHALL set NumGPOs in the
1790 GPIOCapabilities to zero. If such a Reader receives a SET_READER_CONFIG with

1791 GPOWriteData Parameter, the Reader SHALL return an error message and not process
1792 any of the parameters in that message.

GPOWriteData Parameter

GPO Port Number : Unsigned Short Integer. 0 is invalid.

GPO Data: Boolean. The state to output on the specified GPO port.

1793 **12.2.4 KeepaliveSpec Parameter**

1794 This parameter carries the specification for the keepalive message generation by the
1795 Reader. This includes the definition of the periodic trigger to send the keepalive message.

1796 **Compliance requirement**: Compliant Readers and Clients SHALL implement this
1797 parameter.

KeepaliveSpec Parameter

KeepaliveTriggerType: Integer

Possible Values:

Value	Definition
-----	-----
0	Null - No keepalives SHALL be sent by the Reader
1	Periodic

PeriodicTriggerValue: Integer. Time interval in milliseconds. This field is ignored when KeepaliveTriggerType is not 1.

1798 **12.2.5 AntennaProperties Parameter**

1799 This parameter carries a single antenna's properties. The properties include the gain and
1800 the connectivity status of the antenna. The antenna gain is the composite gain and includes
1801 the loss of the associated cable from the Reader to the antenna. The gain is represented in
1802 dBi*100 to allow fractional dBi representation.

1803 **Compliance requirement**: Compliant Readers and Clients MAY implement this
1804 parameter.

AntennaProperties Parameter

AntennaID: Unsigned Short Integer

Possible Values:

1 to N, where N is the maximum number of antennas supported by the device.

AntennaGain: Signed short integer. The gain of the antenna in dBi*100 (dB relative to Isotropic) to allow for fractional dBi representation.

AntennaConnected: Boolean. False = not connected, True = connected.

1805 **12.2.6 AntennaConfiguration Parameter**

1806 This parameter carries a single antenna's configuration and it specifies the default values
1807 for the parameter set that are passed in this parameter block. The scope of the default
1808 values is the antenna. The default values are used for parameters during an operation on
1809 this antenna if the parameter was unspecified in the spec that describes the operation.

1810 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1811 parameter.

AntennaConfiguration Parameter

Antenna ID: Unsigned Short Integer. If set to zero, this configuration applies to all the antennas.

RFReceiverSettings: <RFReceiver Parameter> [Optional]

RFTransmitterSettings: <RFTransmitter Parameter> [Optional]

AirProtocolInventoryCommandSettings: List of LLRP parameters. [Optional]

Possible Values:

Each air protocol's inventory command parameter is expressed as a different LLRP Parameter. The air protocol specific inventory command LLRP Parameters are defined in section 15.1. This field is a list of inventory command LLRP Parameters, one per air protocol, that the Client would like to use as the default inventory command setting for inventory operations using the air protocol on this antenna.

1812 **12.2.6.1 RFReceiver Parameter**

1813 This Parameter carries the RF receiver information. The Receiver Sensitivity defines the
1814 sensitivity setting at the receiver. The value is the index into the ReceiveSensitivityTable
1815 (section 9.2.1.1).

1816 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1817 parameter.

RFReceiver Parameter

ReceiverSensitivity: Unsigned Short Integer - an index into the ReceiveSensitivity Table (section 9.2.1.1)

1818 **12.2.6.2 RFTransmitter Parameter**

1819 This Parameter carries the RF transmitter information. The Transmit Power defines the
1820 transmit power for the antenna expressed as an index into the TransmitPowerTable
1821 (section 9.2.4.1.1). The HopTableID is the index of the frequency hop table to be used by
1822 the Reader (section 9.2.4.1.2.1) and is used when operating in frequency-hopping
1823 regulatory regions. This field is ignored in non-frequency-hopping regulatory regions.
1824 The ChannelIndex is the one-based channel index in the FixedFrequencyTable to use
1825 during transmission (section 9.2.4.1.2.2) and is used when operating in non-frequency-

1826 hopping regulatory regions. This field is ignored in frequency-hopping regulatory
 1827 regions.
 1828 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1829 parameter.

RFTransmitter Parameter
Transmit Power: Unsigned Short Integer - an index into the Transmit Power table.
HopTableID : Unsigned Short Integer
ChannelIndex : Unsigned Short Integer. This is the index of the frequency to use.

1830 **12.2.6.3 GPIPortCurrentState Parameter**

1831 This Parameter carries the current configuration and state of a single GPI port. In a
 1832 SET_READER_CONFIG message, this parameter is used to enable or disable the GPI
 1833 port using the GPIConfig field; the GPIState field is ignored by the reader. In a
 1834 GET_READER_CONFIG message, this parameter reports both the configuration and
 1835 state of the GPI port.

1836
 1837 When a ROSpec or AISpec is configured on a GPI-capable reader with GPI start and/or
 1838 stop triggers, those GPIs must be enabled by the client with a SET_READER_CONFIG
 1839 message for the triggers to function.

1840
 1841 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 1842 parameter. Readers that do not support GPIs SHALL set NumGPIs in the
 1843 GPIOCapabilities to zero. If such a Reader receives a GET_READER_CONFIG with a
 1844 GPIPortCurrentState Parameter, the Reader SHALL return an error message and not
 1845 process any of the parameters in that message.

GPIPortCurrentState Parameter
GPIPortNum: Unsigned Short Integer. Zero is illegal.
GPIConfig : Boolean (0 for disabled, 1 for enabled)
GPIState : Integer (ignored in SET_READER_CONFIG messages)
Possible Values:

Value	Definition
-----	-----
0	GPI state is low
1	GPI state is high
2	GPI state is unknown

1846 **12.2.6.4 EventsAndReports Parameter**

1847 This parameter controls the behavior of the Reader when a new LLRP connection is
 1848 established. In a SET_READER_CONFIG message, this parameter is used to enable or
 1849 disable the holding of events and reports upon connection using the
 1850 HoldEventsAndReportsUponReconnect field. In a GET_READER_CONFIG message,
 1851 this parameter reports the current configuration. If the

1852 HoldEventsAndReportsUponReconnect is true, the reader will not deliver any reports or
1853 events (except the ConnectionAttemptEvent) to the Client until the Client issues an
1854 ENABLE_EVENTS_AND_REPORTS message. Once the
1855 ENABLE_EVENTS_AND_REPORTS message is received the reader ceases its hold on
1856 events and reports for the duration of the connection.

1857
1858 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1859 parameter.

EventsAndReports Parameter

HoldEventsAndReportsUponReconnect: Boolean. (False does not hold reports and events, True holds reports and events)

1860 13 Reports, Notifications and Keepalives

1861 This section describes the messages and parameters used in reports, event notifications
1862 and keepalives that are generated by the Reader and sent to the Client.

1863 The Reader SHALL send reports only when

- 1864 • A reporting trigger (ROReportTrigger or AccessReportTrigger) generates a report
1865 while a connection is open, or
- 1866 • In response to an explicit Client request (GET_REPORT or
1867 ENABLE_EVENTS_AND_REPORTS), or
- 1868 • A notification event occurs and the event is enabled.

1869 The triggers may be specified per ROSpec and AccessSpec using ROReportSpec and
1870 AccessReportSpec parameters. In a report, the Reader SHALL send new data (results of
1871 ROSpecs and/or AccessSpecs) acquired since the last report message. The tag report data
1872 generated by the AccessReport trigger SHALL NOT duplicate the tag report data
1873 generated by the ROReportTrigger, and vice-versa.

1874 13.1 Messages

1875 13.1.1 GET_REPORT

1876 This message is issued by the Client to the Reader to get the tag reports. In response to
1877 this message, the Reader SHALL return tag reports accumulated.

1878 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1879 message.

GET_REPORT

1880 **13.1.2 RO_ACCESS_REPORT**

1881 This message is issued by the Reader to the Client, and it contains the results of the RO
1882 and Access operations. The ROReportSpec and AccessReportSpec parameters define the
1883 contents and triggers for this message.

1884 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1885 message.

RO_ACCESS_REPORT

InventoryAccessReportData: List of <TagReportData Parameter> [Optional]

RFSurveyReportData: List of <RFSurveyReportData Parameter> [Optional]

Custom Extension Point List: List of <custom Parameter> [Optional]

1886 **13.1.3 KEEPALIVE**

1887 This message is issued by the Reader to the Client. This message can be used by the
1888 Client to monitor the LLRP-layer connectivity with the Reader. The Client configures the
1889 trigger at the Reader to send the Keepalive message. The configuration is done using the
1890 KeepaliveSpec parameter (section 12.2.4).

1891 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1892 message.

KEEPALIVE

1893 **13.1.4 KEEPALIVE_ACK**

1894 A Client SHALL generate a KEEPALIVE_ACK in response to each KEEPALIVE
1895 received by the reader.

1896 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1897 message.

KEEPALIVE_ACK

1898 **13.1.5 READER_EVENT_NOTIFICATION**

1899 This message is issued by the Reader to the Client whenever an event that the Client
1900 subscribed to occurs. The pertinent event data is conveyed using the
1901 ReaderEventNotificationData parameter.

1902 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1903 message.

READER_EVENT_NOTIFICATION

ReaderEventNotificationData: ReaderEventNotificationData Parameter

1904

1905 **13.1.6 ENABLE_EVENTS_AND_REPORTS**

1906 This message can be issued by the Client to the Reader after a LLRP connection is
1907 established. The Client uses this message to inform the Reader that it can remove its hold
1908 on event and report messages. Readers that are configured to hold events and reports on
1909 reconnection (See Section 12.2.6.4) respond to this message by returning the tag reports
1910 accumulated (same way they respond to GET_REPORT (See Section 13.1.1)).

1911 **Compliance requirement:** Compliant Readers and Clients MAY implement this
1912 message.

ENABLE_EVENTS_AND_REPORTS

1913

1914 **13.2 Parameters**

1915 **13.2.1 ROReportSpec Parameter**

1916 This Parameter carries the Reader inventory and RF survey reporting definition for the
1917 antenna. This parameter describes the contents of the report sent by the Reader and
1918 defines the events that cause the report to be sent.

1919 The ROReportTrigger field defines the events that cause the report to be sent.

1920 The TagReportContentSelector parameter defines the desired contents of the report. The
1921 ROReportTrigger defines the event that causes the report to be sent by the Reader to the
1922 Client.

1923 See section 13.2.6.1 for details about the order that reports are to be sent with respect to
1924 Reader event notifications.

1925 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1926 parameter.

ROReportSpec Parameter
ROReportTrigger: Integer
Possible Values:

Value	Definition
-----	-----
0	None
1	(Upon N TagReportData Parameters or End of AISpec) Or (End of RFSurveySpec) - N=0 is unlimited.
2	Upon N TagReportData Parameters or End of ROSpec - N=0 is unlimited.

N: Unsigned Short Integer. This is the number of TagReportData Parameters used in
ROReportTrigger = 1 and 2. If N = 0, there is no limit on the number of
TagReportData Parameters. This field SHALL be ignored when ROReportTrigger =

0.

ReportContents: <TagReportContentSelector Parameter>

Custom Extension Point List: List of <Custom Parameter> [Optional]

1927 **13.2.1.1 TagReportContentSelector Parameter**

1928 This parameter is used to configure the contents that are of interest in TagReportData. If
1929 enabled, the field is reported along with the tag data in the TagReportData.

1930 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1931 parameter.

TagReportContentSelector

EnableROSpecID: Boolean

EnableSpecIndex: Boolean

EnableInventoryParameterSpecID: Boolean

EnableAntennaID: Boolean

EnableChannelIndex: Boolean

EnablePeakRSSI: Boolean

EnableFirstSeenTimestamp: Boolean

EnableLastSeenTimestamp: Boolean

EnableTagSeenCount: Boolean

AirProtocolSpecificEPCMemorySelector: LLRP parameter.

Possible Values:

Each air protocol's EPC memory selector parameter is expressed as a different LLRP Parameter. The air protocol specific EPC memory selector LLRP Parameters are defined in section 15.1. This field is the EPC memory selector LLRP Parameter corresponding to the air protocol referenced by the ProtocolID in the ROSpec that the ROReportSpec is part of.

EnableAccessSpecID: Boolean

1932 **13.2.2 AccessReportSpec Parameter**

1933 This parameter sets up the triggers for the Reader to send the access results to the Client.
1934 In addition, the Client can enable or disable reporting of ROSpec details in the access
1935 results.

1936 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
1937 parameter.

AccessReportSpec

AccessReportTrigger: Integer

Possible Values:

Value	Definition
0	Whenever ROReport is generated for the RO that triggered the execution of this AccessSpec.
1	End of AccessSpec

1938 **13.2.3 TagReportData Parameter**

1939 This report parameter is generated per tag per accumulation scope. The only mandatory
1940 portion of this parameter is the EPCData parameter. If there was an access operation
1941 performed on the tag, the results of the OpSpecs are mandatory in the report. The other
1942 sub-parameters in this report are optional. LLRP provides three ways to make the tag
1943 reporting efficient:

- 1944 (i) Allow parameters to be enabled or disabled via TagReportContentSelector
1945 (section 13.2.1.1) in TagReportSpec.
- 1946 (ii) If an optional parameter is enabled, and is absent in the report, the Client
1947 SHALL assume that the value is identical to the last parameter of the same
1948 type received. For example, this allows the Readers to not send a parameter in
1949 the report whose value has not changed since the last time it was sent by the
1950 Reader.
- 1951 (iii) Allow accumulation of tag reports. See next section for details of
1952 accumulation.

1953 **Compliance Requirement:** Compliant Readers and Clients SHALL implement this
1954 parameter.

TagReportData Parameter

EPCData: <EPCData Parameter>

ROSpecID: <ROSpecID Parameter> [Optional]

SpecIndex: <SpecIndex Parameter> [Optional]

InventoryParameterSpecID: <InventoryParameterSpecID Parameter> [Optional]

AntennaID: <AntennaID Parameter> [Optional]

PeakRSSI: <PeakRSSI Parameter> [Optional]

ChannelIndex: <ChannelIndex Parameter> [Optional]

FirstSeenTimestampUTC: <UTCFirstSeenTimestamp Parameter> [Optional]

FirstSeenTimeStamPUptime: <UptimeFirstSeenTimestamp Parameter> [Optional]

LastSeenTimestampUTC: <UTCLastSeenTimestamp Parameter> [Optional]

LastSeenTimeStamPUptime: <UptimeLastSeenTimestamp Parameter> [Optional]

TagSeenCount: <TagSeenCount Parameter> [Optional]

AirProtocolTagData: LLRP Parameters (e.g., C1G2EPC-PC, C1G2EPC-CRC) [Optional]

Possible Values:

Each air protocol's AirProtocolTagData parameter is expressed as a different LLRP Parameter. The air protocol specific AirProtocolTagData LLRP Parameters are defined in section 15.1. This field is the AirProtocolTagData LLRP Parameter corresponding to the air protocol referenced by the ProtocolID of the InventoryParameterSpec during whose execution this tag was observed.

AccessSpecID: <AccessSpecID Parameter> [Optional]

OpSpecResultList: List of LLRP parameters [Optional]

Possible Values of each LLRP Parameter: Air protocol specific OpSpecResult parameter or <ClientRequestOpSpecResult Parameter>.

Regarding the air protocol specific OpSpecResult parameter: Each air protocol's OpSpecResult parameter is expressed as a different LLRP Parameter. The air protocol specific OpSpecResult LLRP Parameters are defined in section 15.1. This field is a list of OpSpecResult LLRP Parameters corresponding to the air protocol referenced by the ProtocolID of the AccessSpec.

Custom Extension Point List: List of <Custom Parameter> [Optional]

1955 **13.2.3.1 Accumulation of TagReportData**

1956 A Reader MAY accumulate multiple tag reports into a single tag report.. If a Reader
1957 accumulates, the Reader SHALL follow the accumulation rules specified in this section.
1958 The following specifies the rules for accumulating multiple tag observations into a single
1959 TagReportData:

- 1960 • EPCData:
 - 1961 ○ The Reader SHALL not accumulate tag reports that do not have the same
 - 1962 EPCData value.
- 1963 • OpSpecResultList:
 - 1964 ○ The Reader SHALL not accumulate tag reports that do not have the same
 - 1965 value for the OpSpec results in the OpSpecResultList.
- 1966 • SpecID, SpecIndex, InventoryParameterSpecID, AntennaID,
1967 AirProtocolTagData, AccessSpecID:
 - 1968 ○ These fields are optional, and their reporting can be enabled by the Client.
 - 1969 If the Client has enabled one or more fields listed above, the Reader
 - 1970 SHALL not accumulate tag reports that do not have the same value for all
 - 1971 the enabled fields.
- 1972 • FirstSeenTimestamp, LastSeenTimestamp, PeakRSSI, TagSeenCount,
1973 ChannelIndex

- 1974 ○ These fields are optional, and their reporting can be enabled by the Client.
 1975 If the field is enabled, the Reader sets the value of these fields as follows:
- 1976 ▪ FirstSeenTimestamp: The Reader SHALL set it to the time of the
 1977 first observation amongst the tag reports that get accumulated in
 1978 the TagReportData.
 - 1979 ▪ LastSeenTimestamp: The Reader SHALL set it to the time of the
 1980 last observation amongst the tag reports that get accumulated in the
 1981 TagReportData.
 - 1982 ▪ PeakRSSI: The Reader SHALL set it to the maximum RSSI value
 1983 observed amongst the tag reports that get accumulated in the
 1984 TagReportData.
 - 1985 ▪ ChannelIndex: The Reader MAY set it to the index of the first
 1986 channel the tag was seen.
 - 1987 ▪ TagSeenCount: The Reader SHALL set it to the number of tag
 1988 reports that get accumulated in the TagReportData.

1989 **13.2.3.2 EPCData Parameter**

1990 This parameter carries the EPC identifier information.

1991 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1992 parameter.

EPCData Parameter
EPC: Bit array

1993 **13.2.3.3 ROSpecID Parameter**

1994 This parameter carries the ROSpecID information.

1995 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 1996 parameter.

ROSpecID Parameter
ROSpecID: Unsigned Integer

1997 **13.2.3.4 SpecIndex Parameter**

1998 This parameter carries the SpecIndex information. The SpecIndex indicates the item
 1999 within the ROSpec that was being executed at the time the tag was observed.

2000 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2001 parameter.

SpecIndex Parameter
SpecIndex: Unsigned Short Integer

2002 **13.2.3.5 InventoryParameterSpecID Parameter**
2003 This parameter carries the InventoryParameterSpecID information.
2004 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2005 parameter.

InventoryParameterSpecID Parameter
InventoryParameterSpecID: Unsigned Short Integer

2006 **13.2.3.6 AntennaID Parameter**
2007 This parameter carries the AntennaID information.
2008 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2009 parameter.

AntennaID Parameter
AntennaID: Unsigned Short Integer

2010 **13.2.3.7 PeakRSSI Parameter**
2011 This parameter carries the PeakRSSI information.
2012 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2013 parameter.

PeakRSSI Parameter
PeakRSSI: Signed Integer. The peak received power of the EPC backscatter in dBm.
Possible Values:
-128 to +127.

2014 **13.2.3.8 ChannelIndex Parameter**
2015 This parameter carries the one-based ChannelIndex value.
2016 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2017 parameter.

ChannelIndex Parameter
ChannelIndex: Unsigned Integer
Possible Values: 0 to 255.

2018 **13.2.3.9 FirstSeenTimestampUTC Parameter**
2019 This parameter carries the FirstSeenTimestamp information in UTC.
2020 **Compliance requirement:** Compliant Readers and Clients that have UTC clocks
2021 SHALL implement this parameter.

FirstSeenTimestampUTC Parameter

Microseconds: Unsigned long Integer. This is the time elapsed since the Epoch (00:00:00 UTC, January 1, 1970) measured in microseconds.

2022 **13.2.3.10 FirstSeenTimestampUptime Parameter**

2023 This parameter carries the FirstSeenTimestamp information in Uptime.

2024 **Compliance requirement:** Compliant Readers and Clients that do not have UTC clocks
2025 SHALL implement this parameter. Compliant Readers and Clients that have UTC clocks
2026 MAY implement this parameter.

FirstSeenTimestampUptime Parameter

Microseconds: Unsigned long Integer. This is the time elapsed since boot, measured in microseconds.

2027 **13.2.3.11 LastSeenTimestampUTC Parameter**

2028 This parameter carries the LastSeenTimestamp information in UTC.

2029 **Compliance requirement:** Compliant Readers and Clients that have UTC clocks
2030 SHALL implement this parameter.

LastSeenTimestampUTC Parameter

Microseconds: Unsigned long Integer. This is the time elapsed since the Epoch (00:00:00 UTC, January 1, 1970) measured in microseconds.

2031 **13.2.3.12 LastSeenTimestampUptime Parameter**

2032 This parameter carries the LastSeenTimestamp information in Uptime.

2033 **Compliance requirement:** Compliant Readers and Clients that do not have UTC clocks
2034 SHALL implement this parameter. Compliant Readers and Clients that have UTC clocks
2035 MAY implement this parameter.

LastSeenTimestampUptime Parameter

Microseconds: Unsigned long Integer. This is the time elapsed since boot, measured in microseconds.

2036 **13.2.3.13 TagSeenCount Parameter**

2037 This parameter carries the tag seen count information. If TagSeenCount > 65535 for the
2038 report period, the reader SHALL report 65535.

2039 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2040 parameter.

TagSeenCount Parameter

Count: Unsigned Short Integer

2041 **13.2.3.14 ClientRequestOpSpecResult Parameter**
2042 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2043 parameter.

ClientRequestOpSpecResult Parameter

OpSpecID: Unsigned Short Integer. 0 is illegal.

2044 **13.2.3.15 AccessSpecID Parameter**

2045 This parameter carries the AccessSpecID information.

2046 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2047 parameter.

AccessSpecID Parameter

AccessSpecID: Unsigned Integer

2048 **13.2.4 RFSurveyReportData Parameter**

2049 This describes the content of the RF Survey Report.

2050 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2051 parameter.

RFSurveyReportData Parameter

ROSpecID: <ROSpecID Parameter> [Optional]

SpecIndex: <SpecIndex Parameter> [Optional]

FrequencyPowerLevelList: List of <FrequencyRSSILevelEntry Parameter>

Custom Extension Point List: List of <custom Parameter> [Optional]

2052 **13.2.4.1 FrequencyRSSILevelEntry Parameter**

2053 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2054 parameter.

FrequencyRSSILevelEntry Parameter

Timestamp: Either <UTCTimestamp Parameter> or <Uptime Parameter>

Frequency: Unsigned Integer. The frequency on which the measurement was taken, specified in kHz.

Bandwidth: Unsigned Integer. The measurement bandwidth of the measurement in kHz.

Average RSSI: Integer in dBm. The average power level observed at this frequency.

Possible Values:

-128 to + 127

Peak RSSI: Integer in dBm. The peak power level observed at this frequency.

Possible Values:

-128 to + 127

2055 **13.2.5 ReaderEventNotificationSpec Parameter**

2056 This parameter is used by the Client to enable or disable notification of one or more
2057 Reader events. Notification of buffer overflow events and connection events
2058 (attempt/close) are mandatory, and not configurable.

2059 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2060 parameter.

ReaderEventNotificationSpec Parameter

EventNotificationSpecTable: List of <EventNotificationState Parameter>

2061 **13.2.5.1 EventNotificationState Parameter**

2062 This parameter is used to enable or disable notification of a single Reader event type.

2063 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2064 parameter.

EventNotificationState Parameter

EventType:

Possible Values:

Value	Definition
-----	-----
0	Upon hopping to next channel (e.g., in FCC regulatory region)
1	GPI event
2	ROSpec event (start/end/preempt)
3	Report buffer fill warning
4	Reader exception event
5	RFSurvey event (start/end)
6	AISpec event (end)
7	AISpec event (end) with singulation details
8	Antenna event (disconnect/connect)

NotificationState: Boolean; enable = true, disable = false.

2065 **13.2.6 ReaderEventNotificationData Parameter**

2066 This parameter describes the contents of the event notification sent by the Reader, and
2067 defines the events that cause the notification to be sent. Event notification messages may
2068 be sent by the Reader due to connection establishment/closing event, critical events such
2069 as hopping, fault-detection in a Reader functional block, buffer overflow, due to the
2070 activation of a Reader accessory trigger input (e.g. motion detection), or due to
2071 performance monitoring events such as abnormalities in the RF environment.

2072 Timestamp is the time that the events reported occurred.
2073 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2074 parameter.

<p>ReaderEventNotificationData Parameter</p> <p>Timestamp: Either <UTCTimestamp Parameter> or <Uptime Parameter></p> <p>Events: List of events.</p> <p><i>Possible Values:</i> The possible members of the list are</p> <pre>{ <HoppingEventParameter>, <GPIEvent Parameter>, <ROSpecEvent Parameter>, <ReportBufferLevelWarningEvent Parameter>, <ReportBufferOverflowErrorEvent Parameter>, <ReaderExceptionEvent Parameter>, <RFSurveyEvent Parameter>, <AISpecEvent Parameter>, <AntennaEvent Parameter>, <ConnectionAttemptEvent Parameter>, <ConnectionCloseEvent Parameter> }</pre> <p>Custom Extension Point List: List of <custom Parameter> [optional]</p>
--

2075 **13.2.6.1 Requirements for Ordering of Event Reporting**
2076 LLRP assumes a reliable stream transport mechanism. Messages sent through LLRP will
2077 arrive in the order that they were sent over the transport and binding utilized. Status
2078 events within the same message SHALL be ordered chronologically.

2079 Status events delivered by reader event notifications are useful, especially in conjunction
2080 with the tag report data. The following describes the requirements of the reader event
2081 notifications ordering with respect to the ordering of tag reports and Reader Event
2082 Notifications.

2083 The following requirements are made on the ordering of Event Parameters with respect to
2084 each other and to tag report Parameters. These statements apply if the respective status
2085 events and report triggers are enabled.

2086 If the start of an ROSpec is triggered by a GPI, the GPIEvent Parameter SHALL be sent
2087 before the ROSpecEvent Parameter signaling the start of the ROSpec.

2088 If the end of an ROSpec is triggered by a GPI, the GPIEvent Parameter SHALL be sent
2089 before the ROSpecEvent Parameter signaling the end of the ROSpec.

2090 If an ROSpec contains one or more AISpecs, the ROSpecEvent parameter signaling the
2091 end of an ROSpec SHALL be sent after the AISpecEvent Parameter signaling the end of
2092 the last AISpec within that ROSpec.

2093 If one ROSpec pre-empts another ROSpec, the ROSpecEvent parameter signaling the
2094 preemption of the first ROSpec SHALL be sent before the ROSpecEvent parameter
2095 signaling the start of the next ROSpec.

2096 Tag data received during an ROSpec execution SHALL be sent between the
2097 ROSpecEvent parameter signaling the start of the ROSpec and the ROSpecEvent
2098 parameter signaling the end or preemption of the ROSpec if the ROReportTrigger is not
2099 set to 'None'.

2100 Tag data received during an AISpec execution SHALL be sent before the AISpecEvent
2101 Parameter signaling the end of the AISpec if the ROReportTrigger is not 'None' or 'end
2102 of RO Spec'

2103 Tag data received during the time on a channel SHALL be sent after the HoppingEvent
2104 parameter that announced this channel and before the next HoppingEvent parameter
2105 when the ROReportTrigger is not 'None' and N=1.

2106 **13.2.6.2 HoppingEvent Parameter**

2107 A Reader reports this event every time it hops frequency.

2108 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2109 parameter.

HoppingEvent Parameter

HopTableID: Unsigned Short Integer

NextChannelIndex: Unsigned Short Integer. This is the one-based ChannelIndex of the next channel to which the Reader is going to change.

2110 **13.2.6.3 GPIEvent Parameter**

2111 A reader reports this event every time an enabled GPI changes GPIstate.

2112 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2113 parameter.

GPIEvent Parameter

GPIPortNumber: Unsigned Short Integer

GPIEvent: Boolean – True/False.

2114 **13.2.6.4 ROSpecEvent Parameter**

2115 This parameter carries the ROSpec event details. The EventType could be start or end of
2116 the ROSpec.

2117 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2118 parameter.

ROSpecEvent Parameter	
ROSpecID: Unsigned Integer. This is the ID of the ROSpec that started, ended or got preempted.	
EventType: Integer	
<i>Possible Values:</i>	
Value	Definition
-----	-----
0	Start of ROSpec
1	End of ROSpec
2	Preemption of ROSpec
PreemptingROSpecID: Integer. This field is ignored when EventType != 2. This field carries the ID of the preempting ROSpec.	

2119 **13.2.6.5 ReportBufferLevelWarningEvent Parameter**

2120 A Reader can warn the Client that the Reader’s report buffer is filling up. A Client can
2121 act upon this warning by requesting report data from the Reader, thereby freeing the
2122 Reader’s report memory resources.

ReportBufferLevelWarningEvent Parameter
ReportBufferPercentageFull: Integer
<i>Possible Values:</i> 0-100

2123

2124 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2125 parameter. A Reader MAY send a report buffer level warning event whenever the
2126 Reader senses that its report memory resources are running short. The buffer level at
2127 which a warning is reported is Reader implementation dependent. A Client MAY act
2128 upon a report buffer level warning event by requesting report data from the Reader and
2129 thereby free report memory resources in the Reader.

2130 **13.2.6.6 ReportBufferOverflowErrorEvent Parameter**

2131 A Reader reports a buffer overflow event whenever report data is lost due to lack of
2132 memory resources.

ReportBufferOverflowErrorEvent Parameter

2133 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2134 parameter. A Reader SHALL report a buffer overflow event whenever report data is lost
2135 due to lack of memory resources.

2136 **13.2.6.7 ReaderExceptionEvent Parameter**

2137 The reader exception status event notifies the client that an unexpected event has
2138 occurred on the reader. Optional parameters provide more detail to the client as to the
2139 nature and scope of the event.

2140 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2141 parameter.

<p>ReaderExceptionEvent Parameter</p> <p>ROSpecID: <ROSpecID Parameter> [Optional]</p> <p>SpecIndex: <Spec Index Parameter> [Optional]</p> <p>InventoryParameterSpecID: <InventoryParameterSpecID Parameter> [Optional]</p> <p>AntennaID: <AntennaID Parameter> [Optional]</p> <p>AccessSpecID: <AccessSpecID Parameter> [Optional]</p> <p>OpSpecID: <OpSpecID Parameter> [Optional]</p> <p>Message: UTF-8 String</p> <p>Custom Extension Point List: List of <custom Parameter> [Optional]</p>
--

2142 **13.2.6.7.1 OpSpecID Parameter**

2143 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2144 parameter.

<p>OpSpecID Parameter</p> <p>OpSpecId: Unsigned Short Integer. 0 is illegal.</p>
--

2145 **13.2.6.8 RFSurveyEvent Parameter**

2146 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2147 parameter.

<p>RFSurveyEvent Parameter</p> <p>ROSpecID: Unsigned Integer. The identifier of the ROSpec that contains the RFSurveySpec.</p> <p>SpecIndex: Unsigned Short Integer. The index of the spec in the ROSpec.</p> <p>EventType: Integer</p> <p><i>Possible Values:</i></p> <table> <thead> <tr> <th>Value</th> <th>Definition</th> </tr> <tr> <th>-----</th> <th>-----</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Start of RFSurvey</td> </tr> <tr> <td>1</td> <td>End of RFSurvey</td> </tr> </tbody> </table>	Value	Definition	-----	-----	0	Start of RFSurvey	1	End of RFSurvey
Value	Definition							
-----	-----							
0	Start of RFSurvey							
1	End of RFSurvey							

2148 **13.2.6.9 AISpecEvent Parameter**

2149 This parameter carries the AISpec event details. The EventType is the end of the AISpec.
2150 When reporting the end event, the AirProtocolSingulationDetails MAY be reported if it is
2151 supported by the Reader and EventType of 7 has been enabled (Section 13.2.5.1).

2152 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2153 parameter.

AISpecEvent Parameter						
ROSpecID: Unsigned Integer. The identifier of the ROSpec that contains the AISpec.						
SpecIndex: Unsigned Short Integer. The index of the spec in the ROSpec.						
EventType: Integer						
<i>Possible Values:</i>						
<table> <thead> <tr><th>Value</th><th>Definition</th></tr> <tr><th>-----</th><th>-----</th></tr> </thead> <tbody> <tr><td>0</td><td>End of AISpec</td></tr> </tbody> </table>	Value	Definition	-----	-----	0	End of AISpec
Value	Definition					
-----	-----					
0	End of AISpec					
AirProtocolSingulationDetails: LLRP parameter [Optional]						
<i>Possible Values:</i>						
Each air protocol's AirProtocolSingulationDetails parameter is expressed as a different LLRP Parameter. The air protocol specific AirProtocolSingulationDetails LLRP Parameters are defined in section 15.1. This field is the AirProtocolSingulationDetails LLRP Parameter corresponding to the air protocol referenced by the ProtocolID of the InventoryParameterSpec upon whose execution completion this event report was generated.						

2154 **13.2.6.10 AntennaEvent Parameter**

2155 This event is generated when the Reader detects that an antenna is connected or
2156 disconnected.

2157 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2158 parameter.

AntennaEvent Parameter								
AntennaID: Unsigned Short Integer								
EventType: Integer								
<i>Possible Values:</i>								
<table> <thead> <tr><th>Value</th><th>Definition</th></tr> <tr><th>-----</th><th>-----</th></tr> </thead> <tbody> <tr><td>0</td><td>Antenna disconnected</td></tr> <tr><td>1</td><td>Antenna connected</td></tr> </tbody> </table>	Value	Definition	-----	-----	0	Antenna disconnected	1	Antenna connected
Value	Definition							
-----	-----							
0	Antenna disconnected							
1	Antenna connected							

2159 **13.2.6.11 ConnectionAttemptEvent Parameter**

2160 This status report parameter establishes Reader connection status when the Client or
2161 Reader initiates a connection. See section 18.1, TCP Transport, for more details
2162 regarding the use of this report.

2163 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2164 parameter.

ConnectionAttemptEvent Parameter	
Status: Integer	
<i>Possible Values:</i>	
Value	Definition
-----	-----
0	Success
1	Failed (a Reader initiated connection already exists)
2	Failed (a Client initiated connection already exists)
3	Failed (any reason other than a connection already exists)
4	Another connection attempted

2165 **13.2.6.12 ConnectionCloseEvent Parameter**

2166 This status report parameter informs the Client that, unsolicited by the Client, the Reader
2167 will close the connection between the Reader and Client. Before the Reader closes a
2168 connection with the Client that is not solicited by the Client, the Reader SHALL first
2169 attempt to send a READER_EVENT_NOTIFICATION containing this parameter to the
2170 Client.

2171 Once the Reader sends this event to the Client, the Reader SHALL close the connection
2172 to the Client. This is also to say that, once the Reader sends this event, the Reader
2173 SHALL send no additional messages to the Client and the Reader SHALL ignore any
2174 messages received from the Client until another new connection is established.

2175 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2176 parameter.

ConnectionCloseEvent Parameter

2177

2178 **14 Errors**

2179 This section describes the errors that are solely based on LLRP protocol message parsing.
2180 The Reader SHALL discard the message if there is at least one error in the message, or
2181 cannot be fully processed. In addition, no portion of the message containing an error
2182 SHALL be executed by the Reader. In case the message has one or more errors, the
2183 Reader SHALL return at least one error parameter for one of the errors. The Reader
2184 MAY return more than one error parameter, one for each error. The errors are conveyed
2185 using a combination of ‘generic error codes’, a pointer to the culprit parameter/field, and
2186 a description of the error encoded as a string of UTF-8 characters.

2187 Typically the errors in the LLRP defined messages are conveyed inside of the responses
 2188 from the Reader. However, in cases where the message received by the Reader contains
 2189 an unsupported message type, or a CUSTOM_MESSAGE with unsupported parameters
 2190 or fields, the Reader SHALL respond with the ERROR_MESSAGE.

2191 When a Reader or Client receives a command or notification with a version that is not
 2192 supported, the receiver SHALL send an ERROR_MESSAGE in reply consisting of: A
 2193 version that is the same as the received message, the message ID that matches the
 2194 received message, and an LLRPStatusParameter with the ErrorCode set to
 2195 M_UnsupportedVersion. This message SHALL contain no sub-parameters (such as Field
 2196 Error, Parameter Error).

2197 Readers and Clients SHALL not respond to an ERROR_MESSAGE.

2198 14.1 Messages

2199 14.1.1 ERROR_MESSAGE

2200 This message is issued by the Reader to the Client, and it contains the LLRPStatus
 2201 parameter that describes the error in the message.

2202 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2203 message.

ERROR_MESSAGE

Error: <LLRPStatus Parameter>

2204 14.2 Parameters

2205 First, the error codes are presented, and then later, error parameters are presented that
 2206 identify the culprit field in the message.

2207 14.2.1 LLRP Status Codes

2208 Status can be a success or one of the error conditions. This section lists a set of generic
 2209 error conditions that, in combination with the identifier of the culprit field, conveys the
 2210 error condition. The codes are broken into four scopes: message, parameter, field and
 2211 device. The device code indicates that the error is in the Reader device rather than the
 2212 message, parameter or field.

2213

StatusCode	Name	Scope	Description
0	M_Success	Message	This code SHALL indicate that the message was received and processed successfully.
100	M_ParameterError		This code SHALL indicate that an error occurred with a parameter of this message.

101	M_FieldError		This code SHALL indicate that an error occurred with a field of this message.
102	M_UnexpectedParameter		This code SHALL indicate that an unexpected parameter was received with this message.
103	M_MissingParameter		This code SHALL indicate that a required parameter was missing from this message.
104	M_DuplicateParameter		This code SHALL indicate that a parameter, for which there must only be one instance at the Reader, was seen more than once in this message.
105	M_OverflowParameter		This code SHALL indicate that the maximum number of instances of the parameter has been exceeded at the Reader.
106	M_OverflowField		This code SHALL indicate that the maximum number of instances of the field has been exceeded at the Reader.
107	M_UnknownParameter		This code SHALL indicate that an unknown parameter was received in the message.
108	M_UnknownField		This code SHALL indicate that the field is unknown or not found at the Reader.
109	M_UnsupportedMessage		This code SHALL indicate that an unsupported message type was received.
110	M_UnsupportedVersion		This code SHALL indicate that the LLRP version in the received message is not supported by the Reader.
111	M_UnsupportedParameter		This code MAY indicate that the Parameter in the received message is not supported by the Reader.
200	P_ParameterError	Parameter	This code SHALL indicate that an error occurred with a parameter of this parameter.
201	P_FieldError		This code SHALL indicate that an error occurred with a field of this parameter.
202	P_UnexpectedParameter		This code SHALL indicate that an unexpected parameter was

			received with this message.
203	P_MissingParameter		This code SHALL indicate that a required parameter was missing from this parameter.
204	P_DuplicateParameter		This code SHALL indicate that a parameter, for which there must only be one instance, was seen more than once in this parameter.
205	P_OverflowParameter		This code SHALL indicate that the maximum number of instances of the parameter has been exceeded at the Reader.
206	P_OverflowField		This code SHALL indicate that the maximum number of instances of the field has been exceeded at the Reader.
207	P_UnknownParameter		This code SHALL indicate that an unknown parameter was received with this message.
208	P_UnknownField		This code SHALL indicate that the field is unknown or not found at the Reader.
209	P_UnsupportedParameter		This code SHALL indicate that an unsupported parameter was received.
300	A_Invalid	Field	This code SHALL indicate that the field value was considered invalid for a non specific reason. An example is a message with invalid SpecID for a ROSpec or AccessSpec.
301	A_OutOfRange		This code SHALL indicate that the field value did not fall within an acceptable range.
401	R_DeviceError	Reader	This code MAY indicate that there is a problem on the Reader rather than with a message, parameter, or field.

2214 **14.2.2 LLRPStatus Parameter**

2215 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2216 parameter.

LLRPStatus Parameter

StatusCode: Integer.

Possible Values:

See the error code table (section 14.2.1) for possible values within the Message, Parameter or Field scope.

FieldError: <FieldError Parameter> [Optional]

ParameterError: <ParameterError Parameter> [Optional]

ErrorDescription: UTF-8 String

2217 **14.2.2.1 FieldError Parameter**

2218 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2219 parameter.

FieldError Parameter

FieldNum: Integer. Field number for which the error applies. The fields are numbered after the order in which they appear in the parameter or message body.

Possible Values:

0-65535

ErrorCode: Integer.

Possible Values:

See the error code table (section 14.2.1) for possible values within the Argument scope.

2220 **14.2.2.2 ParameterError Parameter**

2221 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2222 parameter.

ParameterError Parameter

ParameterType: Integer. The parameter type that caused this error.

Possible Values:

0 - 1023

ErrorCode: Integer.

Possible Values:

See the error code table (section 14.2.1) for possible values within the Parameter scope.

FieldError: <FieldError Parameter> [Optional]

ParameterError: <ParameterError Parameter> [Optional]

2223

2224 **15 Air Protocol Specific Parameters**

2225 For each air protocol supported by LLRP, the following subsection, 15.1, provides a table
 2226 cross-referencing LLRP parameters and their corresponding air protocol specific
 2227 parameters. All LLRP air protocol specific parameters are specified in the next
 2228 subsection, 15.2.

2229 **15.1 LLRP Air Protocol Cross-Reference Tables**

2230 Within this section there is a separate subsection for each air protocol specified by LLRP.
 2231 Each air protocol subsection includes a table cross-referencing LLRP parameters and
 2232 their corresponding air protocol specific parameters.

2233 Support for a new air protocol can be added to LLRP by adding new subsections to this
 2234 section e.g., 15.1.2 and 15.1.3.

2235 **15.1.1 Class-1 Generation-2 (C1G2) Air Protocol**

2236 The Class-1 Generation-2 (C1G2) Air Protocol is specified by the EPCglobal Class-1
 2237 Generation-2 UHF RFID Protocol v1.1.0 specification.

2238 The following table cross-references LLRP parameters to C1G2 air protocol specific
 2239 parameters.

LLRP Parameter (Section #)	C1G2 Parameter (Section #)
AirProtocolLLRPCapabilities (9.2.3)	C1G2LLRPCapabilities 15.2.1.1.1
UHF_RFModeTable (9.2.4.1)	UHFC1G2RFModeTable (15.2.1.1.2)
AirProtocolInventoryCommandSettings (12.2.6)	C1G2InventoryCommand (15.2.1.2.1)
TagSpec (11.2.1.2)	C1G2TagSpec (15.2.1.3.1)
OpSpec (11.2.1.2)	C1G2OpSpec (15.2.1.3.2)
AirProtocolOpSpecList (11.2.2)	C1G2OpSpec (15.2.1.3.2)
AirProtocolSpecificEPCMemorySelector (13.2.1.1)	C1G2EPCMemorySelector (15.2.1.5.1)
AirProtocolTagData (13.2.3)	C1G2PC and C1G2CRC (15.2.1.5.2, 15.2.1.5.3)
AirProtocolSingulationDetails (13.2.6.9)	C1G2SingulationDetails (15.2.1.5.4)
Op Spec Results (13.2.3)	C1G2OpSpecResult (15.2.1.5.5)

2240 **15.2 LLRP Air Protocol Specific Parameters**

2241 Within this section there is a separate subsection for each air protocol specified by LLRP.
2242 Each air protocol subsection includes a definition for each air protocol specific
2243 parameter. Section 15.1 above cross-references LLRP parameters to the air protocol
2244 specific parameters specified in this section.

2245 Support for a new air protocol can be added to LLRP by adding new subsections to this
2246 section e.g., 15.2.2 and 15.2.3.

2247 **15.2.1 Class-1 Generation-2 (C1G2) Air Protocol**

2248 The Class-1 Generation-2 (C1G2) Air Protocol is specified by EPCglobal Class-1
2249 Generation-2 UHF RFID Protocol v1.1.0 specification.

2250 The following subsections specify LLRP air protocol specific parameters. These
2251 subsections are partitioned to correlate with major sections of the LLRP specification:

- 2252 - Reader Device Capabilities
- 2253 - Inventory Operation
- 2254 - Access Operation
- 2255 - Reader Device Configuration
- 2256 - Reports

2257 **15.2.1.1 Reader Device Capabilities**

2258 This section of air protocol specific parameters corresponds to LLRP parameters
2259 specified in section 9.

2260 **15.2.1.1.1 C1G2LLRPCapabilities Parameter**

2261 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2262 parameter. Readers MAY support BlockErase, and MAY support BlockWrite. Readers
2263 SHALL support at least one select filter per query.

<p>C1G2LLRPCapabilities Parameter</p> <p>CanSupportBlockErase: Boolean</p> <p>CanSupportBlockWrite: Boolean</p> <p>MaxNumSelectFiltersPerQuery: Unsigned Short Integer. If set to zero, it indicates there is no maximum limit.</p>

2264 **15.2.1.1.2 UHFC1G2RFModeTable Parameter**

2265 This parameter carries the set of C1G2 RF modes that the Reader is capable of operating.

2266 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2267 parameter.

UHFC1G2RFModeTable Parameter

UHFC1G2RFModeSet: List of <UHFC1G2RFModeTableEntry Parameter>

2268 15.2.1.1.2.1 UHFC1G2RFModeTableEntry Parameter

2269 This parameter carries the information for each UHFC1G2 RF mode. A mode that has
2270 been tested for conformance by the EPCGlobal Hardware Action Group's Testing and
2271 Conformance (HAG T&C) group, is indicated using a conformance flag.

2272 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2273 parameter.

UHFC1G2RFModeTableEntry Parameter

Mode identifier: Unsigned Integer. This is a Reader defined identifier that the client may use to set the Gen2 operating parameters.

DR Value: Integer. Divide ratio.

Possible Values:

Value	DR
0	8
1	64/3

BDR Value: Integer. Backscatter data rate in bps.

Possible Values:

40000 – 640000 bps

M value: Integer. Modulation.

Possible Values:

Value	M
0	FM0
1	2
2	4
3	8

Forward link modulation: Integer

Possible Values:

Value	Modulation
0	PR-ASK
1	SSB-ASK
2	DSB-ASK

PIE Value: Integer. One thousand times the ratio of data-0 symbol length and data-1 symbol length in pulse-interval encoding. The C1G2 spec specifies a ratio range of 1.5 – 2.0. (see section 6.3.1.2.4 in [C1G2]).

Possible Values:

1500-2000

MinTariValue: Integer. Minimum Tari time in nanoseconds (see section 6.3.1.2.4 in [C1G2])

Possible Values:

6250-25000

MaxTariValue: Integer. Maximum Tari time in nanoseconds. (see section 6.3.1.2.4 in [C1G2]).

Possible Values:

6250-25000

StepTariValue: Integer. Tari Step size in nanoseconds.(see section 6.3.1.2.4 in [C1G2])

Possible Values:

0 – 18750 nsec

Spectral Mask Indicator: Integer. Spectral mask characteristics of the mode. The Reader SHALL advertise this value if and only if the spectral mask value is valid for all the Tari steps in the range.

Possible Values:

Value	Modulation
-----	-----
0	Unknown
1	SI - Meets [C1G2] Single-Interrogator Mode Mask
2	MI - Meets [C1G2] Multi-Interrogator Mode Mask
3	DI - Meets [C1G2] Dense-Interrogator Mode Mask

EPC HAG T&C Conformance: Boolean. This flag indicates if the Reader vendor has received the certification for the parameter sets specified in this mode. The Reader SHALL set this flag to true only if the Reader vendor has received EPCGlobal conformance for this mode as specified in EPCGlobal Testing and Conformance.

2274 15.2.1.2 Inventory Operation

2275 This section of air protocol specific parameters corresponds to LLRP parameters
2276 specified in section 10.

2277 15.2.1.2.1 C1G2InventoryCommand Parameter

2278 This parameter defines the C1G2 inventory-specific settings to be used during a
2279 particular C1G2 inventory operation. This comprises of C1G2Filter Parameter, C1G2RF
2280 Parameter and C1G2Singulation Parameter. It is not necessary that the Filter, RF Control
2281 and Singulation Control Parameters be specified in each and every inventory command.
2282 They are optional parameters. If not specified, the default values in the Reader are used
2283 during the inventory operation. If multiple C1G2Filter parameters are encapsulated by the
2284 Client in the C1G2InventoryCommand parameter, the ordering of the filter parameters
2285 determine the order of C1G2 air-protocol commands (e.g., Select command) generated by
2286 the Reader.

2287 The TagInventoryStateAware flag is used to determine how to process all the C1G2Filter
2288 and C1G2Singulation parameters in this command. At a functional level, if the Client is
2289 managing the tag states during an inventory operation, it would set that flag to true and
2290 pass the appropriate fields in the C1G2 Filter and C1G2 Singulation parameters. If a
2291 reader set CanDoTagInventoryStateAwareSingulation to False in LLRPCapabilities
2292 (section 9.2.2), it SHALL ignore the TagInventoryStateAware flag.

2293 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2294 parameter.

C1G2InventoryCommand Parameter

TagInventoryStateAware: Boolean

C1G2 Filter : List of <C1G2Filter Parameter> [if absent, use default]

C1G2 RF: <C1G2RFControl Parameter> [if absent, use default]

C1G2 Singulation Control : <C1G2SingulationControl Parameter> [if absent, use default]

Custom Extension Point List: List of <Custom Parameter> (optional)

2295 **15.2.1.2.1.1 C1G2Filter Parameter**

2296 This parameter carries information specific to C1G2 filter (in particular, the parameters
2297 for the select command) operation, and are optionally sent with each inventory command
2298 from the Client to the Reader. This sets up the target tag population that gets inventoried.
2299 For an inventory operation with multiple filters, multiple instances of filter parameters
2300 are sent. A filter parameter contains the following fields:

- 2301 • Target tag mask: This contains the information for the tag memory data pattern
2302 used for the select operation.
- 2303 • T: This value is set if the Client is interested in only a truncated portion of the tag
2304 to be backscattered by the tag. The portion that gets backscattered includes the
2305 portion of the tag ID following the mask. This bit has to be set only in the last
2306 filter-spec.
- 2307 • TagInventoryStateAwareFilterAction: This is used if the TagInventoryStateAware
2308 flag is set to true in the InventoryParameterSpec.
- 2309 • TagInventoryStateUnawareFilterAction: This is used if the
2310 TagInventoryStateAware flag is set to false in the InventoryParameterSpec.

2311 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2312 parameter.

C1G2Filter Parameter

Target Tag Mask: <C1G2TagInventoryMask Parameter>

T: Integer

Possible Values:

Value	Truncate action
-----	-----
0	Unspecified: The Reader decides what truncate action to take.
1	Do not truncate
2	Truncate

TagInventoryStateAwareAction: C1G2TagInventoryStateAwareFilterAction
Parameter (optional)

TagInventoryStateUnawareAction: C1G2TagInventoryStateUnawareFilterAction
Parameter (optional)

2313 15.2.1.2.1.1.1 C1G2TagInventoryMask Parameter
 2314 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2315 parameter.

<p>C1G2TagInventoryMask Parameter</p> <p>MB: Integer. C1G2 Tag memory bank.</p> <p><i>Possible Values:</i></p> <p>1-3. The mask used for the C1G2 select command applies only to EPC, TID or User memory, and not to Reserved memory (MB 0).</p> <p>Pointer: Unsigned Short Integer. The first (msb) bit location of the specified memory bank against which to compare the TagMask.</p> <p>TagMask: Bit array. The pattern against which to compare.</p>

2316 15.2.1.2.1.1.2 C1G2TagInventoryStateAwareFilterAction Parameter
 2317 This parameter is used by the Client to manage the tag states during an inventory
 2318 operation. In order to use this parameter during inventory, the TagInventoryStateAware
 2319 flag is set to true in the InventoryParameterSpec. This parameter contains:

- 2320 • Target: This value indicates which flag in the tag to modify – whether the SL flag
 2321 or its inventoried flag for a particular session.
- 2322 • Action describes the action for matching and non-matching tags. The actions are
 2323 specific about the tag-inventory states - e.g., do nothing, assert or deassert SL,
 2324 assign inventoried S0/S1/S2/S3 to A or B.

2325 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 2326 parameter. Readers that do not support tag inventory state aware singulation SHALL set
 2327 CanDoTagInventoryStateAwareSingulation to false in LLRPCapabilities.

<p>C1G2TagInventoryStateAwareFilterAction Parameter</p> <p>Target: Integer</p> <p><i>Possible Values:</i></p> <table> <thead> <tr> <th>Value</th> <th>Definition</th> </tr> </thead> <tbody> </tbody> </table>	Value	Definition
Value	Definition	

0	SL
1	Inventoried state for session S0
2	Inventoried state for session S1
3	Inventoried state for session S2
4	Inventoried state for session S3
Action : Integer	
<i>Possible Values:</i>	
Value	Definition
0	Matching tags: assert SL or inventoried state → A. Non-matching tags: deassert SL or inventoried state → B.
1	Matching tags: assert SL or inventoried state → A. Non-matching tags: do nothing
2	Matching tags: do nothing Non-matching tags: deassert SL or inventoried state → B
3	Matching tags: negate SL or (A→B, B→A) Non-matching tags: do nothing
4	Matching tags: deassert SL or inventoried state → B Non-matching tags: assert SL or inventoried state → A
5	Matching tags: deassert SL or inventoried state → B Non-matching tags: do nothing
6	Matching tags: do nothing Non-matching tags: assert SL or inventoried state → A
7	Matching tags: do nothing Non-matching tags: negate SL or (A→B, B→A)

2328 15.2.1.2.1.1.3 C1G2TagInventoryStateUnawareFilterAction Parameter

2329 This parameter is used by the Client if it does not want to manage the tag states during an
 2330 inventory operation. Using this parameter, the Client instructs the Reader about the tags
 2331 that should and should not participate in the inventory action. In order to use this
 2332 parameter during inventory, the TagInventoryStateAware flag is set to false in the
 2333 InventoryParameterSpec. This parameter contains:

- 2334 • Action describes the action for matching and non-matching tags. However, the
 2335 action is simply specifying whether matching or non-matching tags partake in this
 2336 inventory. The Reader is expected to handle the tag inventory states to facilitate
 2337 this.

2338 In this parameter, Action=Select means search for pattern in Inventory, and
 2339 Action=Unselect means do not search for pattern in Inventory.

2340 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2341 parameter.

C1G2TagInventoryStateUnawareFilterAction Parameter

Action : Integer

<i>Possible Values:</i>		
Value	Matching Tags	Non-matching Tags
-----	-----	-----
0	Select	Unselect
1	Select	Do nothing
2	Do nothing	Unselect
3	Unselect	Do nothing
4	Unselect	Select
5	Do nothing	Select

2342 **15.2.1.2.1.2 C1G2RF Control Parameter**

2343 This Parameter carries the settings relevant to RF forward and reverse link control in the
 2344 C1G2 air protocol. This is basically the C1G2 RF Mode and the Tari value to use for the
 2345 inventory operation.

2346 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2347 parameter.

<p>C1G2RFControl Parameter</p> <p>ModeIndex: Unsigned Integer. This is an index into the UHFC1G2RFModeTable.</p> <p>Tari: Integer. Value of Tari to use for this mode specified in nsec. This is specified if the mode selected has a Tari range. If the selected mode has a range, and the Tari is set to zero, the Reader implementation picks up any Tari value within the range. If the selected mode has a range, and the specified Tari is out of that range and is not set to zero, an error message is generated.</p> <p><i>Possible Values:</i></p> <p>0 or 6250-25000 nsec</p>

2348 **15.2.1.2.1.3 C1G2SingulationControl Parameter**

2349 This C1G2SingulationControl Parameter provides controls particular to the singulation
 2350 process in the C1G2 air protocol. The singulation process is started using a Query
 2351 command in the C1G2 protocol. The Query command describes the session number, tag
 2352 state, the start Q value to use, and the RF link parameters. The RF link parameters are
 2353 specified using the C1G2RFControl Parameter (see section 15.2.1.2.1.2). This
 2354 Singulation Parameter specifies the session, tag state and description of the target
 2355 singulation environment. The following attributes are specified to provide guidance to the
 2356 Reader for the singulation algorithm:

- 2357 • Tag transit time: This is the measure of expected tag mobility in the field of view
 2358 of the antenna where this inventory operation is getting executed.
- 2359 • Tag population: This is the expected tag population in the field of view of the
 2360 antenna.

2361 In addition, the Singulation Parameter allows setting of the following:

- 2362 • Session ID: This is the C1G2 session number that the tags use to update the
 2363 inventory state upon successful singulation.

- 2364 • TagInventoryStateAwareSingulationAction: This is used if the
 2365 TagInventoryStateAware flag is set to true in the InventoryParameterSpec.
- 2366 ○ I: This is the inventoried state of the target tag population in the selected
 2367 session. Only tags that match the session state participate in the inventory
 2368 round. If the Ignore value is specified, the Reader ignores this field, and
 2369 its up to the Reader implementation to determine the value of I used in the
 2370 inventory round.
- 2371 ○ S: This is the state of the SL flag in the tag. Only tags that match that tag
 2372 state participate in the inventory round. If the Ignore value is specified, the
 2373 Reader ignores this field, and its up to the Reader implementation to
 2374 determine the value of S used in the inventory round.
- 2375 If a reader sets CanDoTagInventoryStateAwareSingulation to False in LLRPCapabilities
 2376 (section 9.2.2), it SHALL ignore the TagInventoryStateAwareSingulationAction field.
- 2377 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2378 parameter.

C1G2SingulationControl Parameter

Session: Integer. Session number to use for the inventory operation.

Possible Values:

0-3

Tag population: Unsigned Short Integer. An estimate of the tag population in view of the RF field of the antenna.

Tag transit time: Unsigned Integer. An estimate of the time a tag will typically remain in the RF field of the antenna specified in milliseconds.

TagInventoryStateAwareSingulationAction:
 <C1G2TagInventoryStateAwareSingulationAction Parameter> (optional)

- 2379 15.2.1.2.1.3.1 C1G2TagInventoryStateAwareSingulationAction Parameter
- 2380 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 2381 parameter. Readers that do not support tag inventory state aware singulation SHALL set
 2382 CanDoTagInventoryStateAwareSingulation to false in LLRPCapabilities.

C1G2TagInventoryStateAwareSingulationAction Parameter

I: Integer

Possible Values:

Value	Definition
0	State A
1	State B

S: Integer

<i>Possible Values:</i>	
Value	Definition
-----	-----
0	SL
1	~SL

2383 **15.2.1.3 Access Operation**

2384 This section of air protocol specific parameters corresponds to LLRP parameters
 2385 specified in section 11.

2386 **15.2.1.3.1 C1G2TagSpec Parameter**

2387 This parameter describes the target tag population on which certain operations have to be
 2388 performed. This Parameter is similar to the selection C1G2Filter Parameter described
 2389 earlier. However, because these tags are stored in the Reader's memory and ternary
 2390 comparisons are to be allowed for, each bit *i* in the target tag is represented using 2 bits -
 2391 bit *i* in mask, and bit *i* in tag pattern. If bit *i* in the mask is zero, then bit *i* of the target tag
 2392 is a don't care (X); if bit *i* in the mask is one, then bit *i* of the target tag is bit *i* of the tag
 2393 pattern. For example, "all tags" is specified using a mask length of zero.

2394 This parameter can carry up to two tag patterns. If more than one pattern is present, a
 2395 Boolean AND is implied. Each tag pattern has a match or a non-match flag, allowing (A
 2396 and B,!A and B, !A and !B, A and !B), where A and B are the tag patterns.

2397 The tagSpec contains:

- 2398 • TagPattern1
- 2399 • TagPattern2

2400 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2401 parameter.

<p>C1G2TagSpec Parameter</p> <p>TagPattern1: <C1G2TargetTag Parameter></p> <p>TagPattern2: <C1G2TargetTag Parameter> [optional]</p>
--

2402 **15.2.1.3.1.1 C1G2TargetTag Parameter**

2403 If Length is zero, this pattern will match all tags regardless of MB, pointer, mask and
 2404 data.

2405 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2406 parameter.

<p>C1G2TargetTag Parameter</p> <p>MB: Integer. Memory bank.</p> <p><i>Possible Values:</i> 0-3.</p> <p>Pointer: Unsigned Short Integer. The address of the first (msb) bit against which to apply</p>
--

the Tag Mask and compare with the value.

TagMask : Bit array

TagData: Bit array

Match: Boolean

2407 **15.2.1.3.2 C1G2 OpSpec Parameters**

2408 This section describes the C1G2 specific OpSpec parameters that are sent as part of the
2409 AccessSpec. Each OpSpec parameter has an OpSpecID that is used when reporting
2410 results of the operation.

2411 **15.2.1.3.2.1 C1G2Read Parameter**

2412 MB is the memory bank to use. WordPtr is the starting word address. WordCount is the
2413 number of 16-bit words to be read. Following is text reproduced from the C1G2
2414 specification regarding WordCount=0. [If WordCount = 0, the tag backscatters the
2415 contents of the chosen memory bank starting at WordPtr and ending at the end of the
2416 bank, unless MB = 1, in which case the Tag shall backscatter the EPC memory contents
2417 starting at WordPtr and ending at the length of the EPC specified by the first 5 bits of the
2418 PC if WordPtr lies within the EPC, and shall backscatter the EPC memory contents
2419 starting at WordPtr and ending at the end of EPC memory if WordPtr lies outside the
2420 EPC.]

2421 Access Password is the password used by the Reader to transition the tag to the secure
2422 state so that it can read protected tag memory regions. For example, the Tag's Reserved
2423 memory is locked but not permalocked, meaning that the Reader must issue the access
2424 password and transition the Tag to the secured state before performing the read operation.

2425 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2426 parameter.

C1G2Read Parameter

OpSpecID: Unsigned Short Integer

MB: Integer. Memory bank.

Possible Values: 0-3

WordPtr: Unsigned Short Integer. The word address of the first word to read from the
chosen memory bank.

WordCount: Unsigned Short Integer

AccessPassword: Unsigned Integer

2427 **15.2.1.3.2.2 C1G2Write Parameter**

2428 MB is the memory bank to use. WordPtr is the starting word address. Write Data is the
2429 data to be written to the tag. Word Count is the number of words to be written.
2430 Depending on the word count, the Reader may have to execute multiple C1G2 air

2431 protocol Write commands. Access Password is the password used by the Reader to
2432 transition the tag to the secure state so that it can write to protected tag memory regions.

2433 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2434 parameter.

C1G2Write Parameter

OpSpecID : Unsigned Short Integer

MB: Integer. Memory bank.

Possible Values: 0-3

WordPtr: Unsigned Short Integer. The word address of the first word to be written to the chosen memory bank.

Write Data: Short array. The data to write to the chosen memory bank.

AccessPassword: Unsigned Integer

2435 **15.2.1.3.2.3 C1G2Kill Parameter**

2436 Kill Password is the value of the kill password to be used or set.

2437 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2438 parameter.

C1G2Kill Parameter

OpSpecID : Unsigned Short Integer

Kill Password: Unsigned Integer

2439 **15.2.1.3.2.4 C1G2Lock Parameter**

2440 This parameter contains the definition of the access privilege updates
2441 (read/write/permalock) to be performed in various locations of the memory. The five data
2442 fields for which we can define access control using the lock command are: Kill Password,
2443 Access Password, EPC memory, TID memory and User memory. The access privilege
2444 updates are expressed as a list of C1G2LockPayload Parameters, one for each memory
2445 location.

2446 The Access Password provides the password to enter the *secured* state. A Reader can
2447 perform a lock operation on a tag only if the tag is in the *secured* state. The tag enters the
2448 secured state only using the Access Password (if a non-zero value).

2449 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2450 parameter.

C1G2Lock Parameter

OpSpecID : Unsigned Short Integer

LockCommandPayloadList: List of <C1G2LockPayload Parameter>

Access Password: Unsigned Integer

2451 15.2.1.3.2.4.1 C1G2LockPayload Parameter
 2452 This parameter contains the definition of the access privilege updates
 2453 (read/write/permalock) to be performed for a single location of the tag memory. The five
 2454 data fields for which we can define access control using the lock command are: Kill
 2455 Password, Access Password, EPC memory, TID memory and User memory.
 2456 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2457 parameter.

C1G2LockPayload Parameter	
OpSpecID : Unsigned Short Integer	
Privilege: Integer. Value indicates the access privilege to be applied.	
<i>Possible Values:</i>	
Value	Access Privilege
-----	-----
0	Read/Write
1	Permalock
2	Permaunlock
3	Unlock
DataField: Unsigned Integer. Value indicates to which data field the access privilege will be applied.	
<i>Possible Values:</i>	
Value	Field
-----	-----
0	Kill Password
1	Access Password
2	EPC Memory
3	TID Memory
4	User Memory

2458 **15.2.1.3.2.5 C1G2BlockErase Parameter**
 2459 MB is the memory bank to use. WordPtr is the starting word address. Word Count is the
 2460 number of 16-bit words to be read. Access Password is the password used by the Reader
 2461 to transition the tag to the secure state so that it can erase protected tag memory regions.
 2462 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 2463 parameter. Readers that do not support C1G2BlockErase SHALL set
 2464 CanSupportBlockErase to false in C1G2LLRPCapabilities. If such a Reader receives an
 2465 ADD_ACCESSSPEC with an AccessSpec that contained this OpSpec parameter, the
 2466 Reader SHALL return an error for that message and not add the AccessSpec.

C1G2BlockErase Parameter	
OpSpecID : Unsigned Short Integer	
MB: Integer. Memory bank.	
<i>Possible Values:</i> 0-3	
WordPtr: Unsigned Short Integer. Word address of first word to be erased.	

Word Count: Unsigned Short Integer. Number of words to erase.

Access Password: Unsigned Integer

2467 **15.2.1.3.2.6 C1G2BlockWrite Parameter**

2468 MB is the memory bank to use. WordPtr is the starting word address. Word Count is the
2469 number of 16-bit words to be written. Depending on the word count, the Reader may
2470 have to execute multiple C1G2 air protocol block write commands. Write Data is the data
2471 to be written to the tag. Access Password is the password used by the Reader to transition
2472 the tag to the secure state so that it can write to protected tag memory regions.

2473 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2474 parameter. Readers that do not support C1G2BlockWrite SHALL set
2475 CanSupportBlockWrite to false in C1G2LLRPCapabilities. If such a Reader receives an
2476 ADD_ACCESSSPEC with an AccessSpec that contained this OpSpec parameter, the
2477 Reader SHALL return an error for that message and not add the AccessSpec.

C1G2BlockWrite Parameter

OpSpecID : Unsigned Short Integer

MB: Integer. Memory bank.

Possible Values: 0-3

WordPtr: Unsigned Short Integer. Word address of first word to be written.

Write Data: Short array

Access Password: Unsigned Integer

2478 **15.2.1.4 Reader Device Configuration**

2479 This section of air protocol specific parameters corresponds to LLRP parameters
2480 specified in section 12. The only air protocol specific parameter is
2481 AirProtocolInventoryCommandSettings parameter in the AntennaConfiguration (section
2482 12.2.6). The C1G2 specific InventoryCommand is already defined in section 15.2.1.2.1.

2483 **15.2.1.5 Reports**

2484 This section of air protocol specific parameters corresponds to LLRP parameters
2485 specified in section 13.2.1.1.

2486 **15.2.1.5.1 C1G2EPCMemorySelector Parameter**

2487 This parameter is used to determine what contents are of interest in the C1G2EPC
2488 memory bank for reporting. If enableCRC and enablePC is set to false, only the EPC is
2489 returned in the RO Report. If enablePC is set to true, the PC bits and the EPC are returned
2490 in the RO Report. If enablePC and enableCRC is set to true, the EPC, PC bits and CRC
2491 are returned in the RO Report.

2492 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2493 parameter.

C1G2EPCMemorySelector

enablePC: Boolean

enableCRC: Boolean

2494 **15.2.1.5.2 C1G2PC Parameter**

2495 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2496 parameter.

C1G2PC Parameter

PC bits: Unsigned Short Integer

2497 **15.2.1.5.3 C1G2CRC Parameter**

2498 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2499 parameter.

C1G2CRC Parameter

CRC: Unsigned Short Integer

2500 **15.2.1.5.4 C1G2SingulationDetails Parameter**

2501 **Compliance requirement:** Compliant Readers and Clients MAY implement this
2502 parameter.

C1G2SingulationDetails Parameter

NumCollisionSlots: Unsigned Short Integer. The number of slots detected as collided over the duration of this report.

NumEmptySlots: Unsigned Short Integer. The number of slots detected as empty over the duration of this report.

2503 **15.2.1.5.5 C1G2 OpSpec Results**

2504 **15.2.1.5.5.1 C1G2ReadOpSpecResult Parameter**

2505 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2506 parameter.

C1G2ReadOpSpecResult Parameter

OpSpecID: Unsigned Short Integer

ReadData: Short Array. The data read from the RFID tag.

Result: Integer

Possible Values:

Value	Definition
-----	-----
0	Success
1	Non-specific tag error
2	No response from tag
3	Non-specific reader error

2507 **15.2.1.5.5.2 C1G2WriteOpSpecResult Parameter**

2508 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2509 parameter.

C1G2WriteOpSpecResult Parameter

OpSpecID: Unsigned Short Integer

NumWordsWritten: Unsigned Short Integer. The number of words written as a result of this OpSpec. If the number of words written is not equal to the length of the data pattern to write, the Result below SHALL be non-zero.

Result: Integer

Possible Values:

Value	Definition
-----	-----
0	Success
1	Tag memory overrun error
2	Tag memory locked error
3	Insufficient power to perform memory-write operation
4	Non-specific tag error
5	No response from tag
6	Non-specific reader error

2510 **15.2.1.5.5.3 C1G2KillOpSpecResult Parameter**

2511 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
2512 parameter.

C1G2KillOpSpecResult Parameter

OpSpecID: Unsigned Short Integer

Result: Integer

Possible Values:

Value	Definition
-----	-----
0	Success
1	Zero kill password error
2	Insufficient power to perform kill operation
3	Non-specific tag error
4	No response from tag
5	Non-specific reader error

2513 **15.2.1.5.5.4 C1G2LockOpSpecResult Parameter**
 2514 **Compliance requirement:** Compliant Readers and Clients SHALL implement this
 2515 parameter.

C1G2LockOpSpecResult Parameter	
OpSpecID: Unsigned Short Integer	
Result: Integer	
<i>Possible Values:</i>	
Value	Definition
-----	-----
0	Success
1	Insufficient power to perform lock operation
2	Non-specific tag error
3	No response from tag
4	Non-specific reader error

2516 **15.2.1.5.5.5 C1G2BlockEraseOpSpecResult Parameter**
 2517 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 2518 parameter. Readers that do not support C1G2 Block Erase SHALL set
 2519 CanSupportBlockErase to false in C1G2LLRPCapabilities. If such a Reader receives an
 2520 ADD_ACCESSSPEC with an AccessSpec that contains this OpSpec parameter, the
 2521 Reader SHALL return an error for that message and not add the AccessSpec.

C1G2BlockEraseOpSpecResult Parameter	
OpSpecID: Unsigned Short Integer	
Result: Integer	
<i>Possible Values:</i>	
Value	Definition
-----	-----
0	Success
1	Tag memory overrun error
2	Tag memory locked error
3	Insufficient power to perform block erase operation
4	Non-specific tag error
5	No response from tag
6	Non-specific reader error

2522 **15.2.1.5.5.6 C1G2BlockWriteOpSpecResult Parameter**
 2523 **Compliance requirement:** Compliant Readers and Clients MAY implement this
 2524 parameter. Readers that do not support C1G2 Block Write SHALL set
 2525 CanSupportBlockWrite to false in C1G2LLRPCapabilities. If such a Reader receives an
 2526 ADD_ACCESSSPEC with an AccessSpec that contains this OpSpec parameter, the
 2527 Reader SHALL return an error for that message and not add the AccessSpec.

C1G2BlockWriteOpSpecResult Parameter

2583 As stated earlier, the communications between the Client and the Reader are primarily of a request-
2584 response type - requests/commands from the Client to the Reader, and responses from the Reader to the
2585 Client. In order to facilitate multiple outstanding commands/requests from the Client, LLRP uses a
2586 Message sequence number in each message. The Message sequence number is used to correlate a
2587 response with the original request. This sequence number is local to the LLRP channel.
2588
2589 Message Value: variable length
2590 Dependent on the Message Type.

2606 **16.1.4 ADD_ROSPEC_RESPONSE**

2607

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 30											Message Length [31:16]																
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]																															
LLRPStatus Parameter																															

2608

2609 See section 10.1.2.

2610

2611 **16.1.5 DELETE_ROSPEC**

2612

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 21											Message Length [31:16]																
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]															ROSpecID[31:16]																
ROSpecID[15:0]																															

2613

2614 See section 10.1.3.

2615

2616 **16.1.6 DELETE_ROSPEC_RESPONSE**

2617

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 31											Message Length [31:16]																
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]																															
LLRPStatus Parameter																															

2618

2619 See section 10.1.4.

2620

2621 **16.1.7 START_ROSPEC**

2622

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 22											Message Length [31:16]																
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]															ROSpecID[31:16]																
ROSpecID[15:0]																															

2675 **16.1.19 DELETE_ACCESSSPEC**

2676

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 41										Message Length [31:16]																	
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]															AccessSpecId[31:16]																
AccessSpecId[15:0]																															

2677

2678 See Section 11.1.3.

2679

2680 **16.1.20 DELETE_ACCESSSPEC_RESPONSE**

2681

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 51										Message Length [31:16]																	
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]																															
LLRPStatus Parameter																															

2682

2683 See Section 11.1.4.

2684

2685 **16.1.21 ENABLE_ACCESSSPEC**

2686

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 42										Message Length [31:16]																	
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]															AccessSpecId[31:16]																
AccessSpecId[15:0]																															

2687

2688 See Section 11.1.5.

2689

2690 **16.1.22 ENABLE_ACCESSSPEC_RESPONSE**

2691

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Rsvd		Ver		Message Type = 52										Message Length [31:16]																	
Message Length [15:0]															Message ID[31:16]																
Message ID[15:0]																															
LLRPStatus Parameter																															

2816 TLV-parameters is 128 – 2047. The number space 0-127 is reserved for TV-parameters.
 2817
 2818 Parameter Length: 16 bits
 2819 This value represents the size of the entire parameter in bytes starting from bit offset 0 of the first word.
 2820 Therefore, if the Parameter Value field is zero-length, the Parameter Length field will be set to 4.
 2821
 2822 Parameter Value: variable length
 2823 Dependent on the Parameter Type.


2824 **16.2.1.1.1 Encoding Guidelines for TLV-Parameters**

2825 The following rules apply to TLV-Parameters:

- 2826 • Parameters may contain mandatory and optional fields.
- 2827 • Parameter fields may be passed by value or by sub-parameter.
- 2828 • Mandatory fields will always be present and optional fields may or may not be
 2829 present.
- 2830 • Mandatory fields of fixed length will be passed by value only, using the order,
 2831 size and alignment defined in this document.
- 2832 • A mandatory field of variable length must be passed by value if it is the only
 2833 field, mandatory or optional, of variable length in that parameter.
- 2834 • A parameter with multiple mandatory or optional fields of variable length must
 2835 pass them as sub-parameters.
- 2836 • A parameter containing a field of variable length being passed by value may not
 2837 contain sub-parameters.
- 2838 • Optional fields will always be passed as sub-parameters.

2839 The following rules apply to sub-parameters:

- 2840 • Sub-parameters follow all parameter rules.
- 2841 • A sub-parameter is a parameter that is encompassed within the length of a
 2842 preceding parameter and adds to the dataset of the encapsulating parameter.



- 2852 • Sub-parameters may be mandatory or optional.

2853 **16.2.1.2 TV-Parameters**

2854 LLRP TV-Parameters have the following encoding structure.

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1

0										1									2												3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 137										Length																	
MaxNumberOfAntennaSupported															C	T	Reserved															
Device manufacturer name																																
Model Name																																
FirmwareVersionByteCount																																
Reader Firmware Version: Variable length UTF-8 String																																
ReceiveSensitivityTableEntry Parameter (1-n)																																
PerAntennaReceiveSensitivityRange Parameter (0-n)																																
GPIOCapabilities Parameter																																
PerAntennaAirProtocol Parameter (1-n)																																

2880
2881
2882
2883
2884
2885
2886

See Section 9.2.1.

Abbreviations

C – CanSetAntennaProperties
T - HasUTCClockCapability

2887 16.2.3.1.1 ReceiveSensitivityTableEntry Parameter

0										1									2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 139										Length																
										Index					Receive Sensitivity Value																

2888
2889
2890

See Section 9.2.1.11.

2891 16.2.3.1.2 PerAntennaReceiveSensitivityRange Parameter

0										1									2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 149										Length																
										AntennaID					ReceiveSensitivityIndexMin																
										ReceiveSensitivityIndexMax																					

2892

See Section 9.2.1.22.

2894 16.2.3.1.3 PerAntennaAirProtocol Parameter

0										1									2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 140										Length																
										AntennaId					NumProtocols																
					ProtocolID#1					ProtocolID#2									ProtocolID#P											

2895
2896 See Section 9.2.1.33.

2897 **16.2.3.1.4** *GPIOCapabilities Parameter*

0										1										2										3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 141															Length														
NumGPIs										NumGPOs																								

2898
2899 See section 9.2.1.44.
2900

2901 **16.2.3.2** *LLRPCapabilities Parameter*

0										1										2											3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1				
Reserved					Type = 142															Length															
C	R	S	T	H	Reserved					MaxPriorityLevelSupported										ClientRequestOpSpecTimeout															
MaxNumROSspecs																																			
MaxNumSpecsPerROSspec																																			
MaxNumInventoryParameterSpecsPerAISpec																																			
MaxNumAccessSpecs																																			
MaxNumOpSpecsPerAccessSpec																																			

2902
2903 **Abbreviations**
2904 C – CanDoRFSurvey
2905 R – CanReportBufferFillWarning
2906 S – SupportsClientRequestOpSpec
2907 T – CanDoTagInventoryStateAwareSingulation
2908 H – SupportsEventAndReportHolding
2909 MaxNumPriority – MaxNumPriorityLevelsSupported
2910
2911 See Section 9.2.2.
2912

2913 **16.2.3.3** *AirProtocolLLRPCapabilities Parameter*

2914 See section 9.2.3.
2915
2916 There is no separate binary encoding for AirProtocolLLRPCapabilities. Each Air protocol’s capabilities are
2917 expressed in a different LLRP Parameter. Refer to Section 16.3 for air protocol specific capability
2918 parameters. For example, the C1G2LLRPCapabilities Parameter (Section 16.3.1.1.1) carries the C1G2 air
2919 protocol capabilities.
2920

2921 **16.2.3.4** *RegulatoryCapabilities Parameter*

0										1										2														3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1							
Reserved					Type = 143															Length																		
Country Code										Communications Standard																												
UHFBandCapabilities Parameter (0-1)																																						

Custom Parameter (0-n)																																												

2922

2923 See Section 9.2.4.

2924

2925 **16.2.3.4.1 UHFBandCapabilities Parameter**

0										1										2																						3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1															
Reserved										Type = 144										Length																										
TransmitPowerLevelTableEntry Parameter (1-n)																																														
FrequencyInformation Parameter																																														
UHFRFModeTable Parameter (1-n)																																														

2926

2927 See Section 9.2.4.1.

2928

2929 **16.2.3.4.1.1 TransmitPowerLevelTableEntry Parameter**

0										1										2																							3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																
Reserved										Type = 145										Length																											
Index															TransmitPowerValue																																

2930

2931 See Section 9.2.4.1.1.

2932

2933 **16.2.3.4.1.2 FrequencyInformation Parameter**

0										1										2																							3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																	
Reserved										Type = 146										Length																												
H	Reserved									FrequencyHopTable Parameter (0-n)																																						
FixedFrequencyTable (0-1)																																																

2934

2935 **Abbreviations**

2936 H – Hopping

2937

2938 See Section 9.2.4.1.2.

2939

2940 **16.2.3.4.1.2.1 FrequencyHopTable Parameter**

0										1										2																							3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																	
Reserved										Type = 147										Length																												
HopTableId										Reserved										NumHops																												
Frequency#1																																																

....																																							
Frequency#n																																							

- 2941
- 2942 NumHops: Number of entries in the List of Frequencies.
- 2943
- 2944 See Section 9.2.4.1.2.1.

2945 **16.2.3.4.1.2.2 FixedFrequencyTable Parameter**

0										1										2																		3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1									
Reserved										Type = 148										Length																				
NumFrequencies															Frequency#1[31:16]																									
Frequency#1[15:0]																																							
....																																								
Frequency#n [15:0]																																								

- 2946 NumFrequencies: Number of entries in the List of Frequencies.
- 2947
- 2948 See Section 9.2.4.1.2.2.
- 2949

2950 **16.2.4 Reader Operations Parameters**

2951 **16.2.4.1 ROSpec Parameter**

0										1										2																			3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1										
Reserved										Type = 177										Length																					
ROSpecID																																									
Priority										CurrentState																															
ROBoundarySpec Parameter																																									
SpecParameter (1-n) [See notes below]																																									
ROReportSpec Parameter (0-1)																																									

- 2952
- 2953 **Notes**
- 2954 Each SpecParameter can be one of the following types: AISpec Parameter or RFSurveySpec Parameter or
- 2955 Custom Parameter.
- 2956
- 2957 See Section 10.2.1.
- 2958

2959 **16.2.4.1.1 ROBoundarySpec Parameter**

0										1										2																						3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1													
Reserved										Type = 178										Length																								
ROSpecStartTrigger Parameter																																												
ROSpecStopTrigger Parameter																																												

2960
 2961 See Section 10.2.1.1.
 2962

2963 **16.2.4.1.1.1 ROSpecStartTrigger Parameter**

0											1											2													3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1					
Reserved										Type = 179										Length																
ROSpecStartTriggerType										PeriodicTriggerValue Parameter (0-1)																										
																		GPITriggerValue Parameter (0-1)																		

2964
 2965 See Section 10.2.1.1.1.
 2966

2967 **16.2.4.1.1.1.1 PeriodicTriggerValue Parameter**

0											1																									3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1						
Reserved										Type = 180										Length																	
																		Offset																			
																		Period																			
																		UTCTimestamp Parameter (0-1)																			

2968
 2969 See Section 10.2.1.1.1.1.
 2970

2971 **16.2.4.1.1.1.2 GPITriggerValue Parameter**

0											1																										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1							
Reserved										Type = 181										Length																		
GPIPortNum										E		Reserved						Timeout[31:24]																				
																		Timeout [23:0]																				

2972
 2973 **Abbreviations**
 2974 E – GPIEvent
 2975
 2976 See section 10.2.1.1.1.2.
 2977

2978 **16.2.4.1.1.2 ROSpecStopTrigger Parameter**

0											1																											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 182										Length																			
ROSpecStopTriggerType										DurationTriggerValue[31:8]																													
DurationTriggerValue[7:0]										GPITriggerValue Parameter (0-1)																													

2979	
2980	See section 10.2.1.1.2.
2981	

2982 **16.2.4.2 AISpec Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 183										Length																
										AntennaCount						AntennaID#1															
															AntennaID#n															
AISpecStopTrigger Parameter																															
InventoryParameter Spec Parameter (1-n)																															
Custom Parameter (0-n)																															

2983
2984 See section 10.2.2.
2985

2986 **16.2.4.2.1 AISpecStopTrigger Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 184										Length																
AISpecStopTriggerType										DurationTrigger[31:24]																					
DurationTrigger[7:0]																															
GPITriggerValue Parameter (0-1)																															
TagObservationTrigger Parameter (0-1)																															

2987
2988 See section 10.2.2.1.
2989

2990 **16.2.4.2.1.1 TagObservationTrigger Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 185										Length																
TriggerType										Reserved						NumberOfTags															
										NumberOfAttempts						T															
Timeout																															

2991
2992 See section 10.2.2.1.1.
2993

2994 **16.2.4.2.2 InventoryParameterSpec Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 186										Length																
										InventoryParameterSpecID						ProtocolID															
AntennaConfigurationParameter (0-n)																															

3011 See section 11.2.1.
 3012

3013 **16.2.5.1.1 AccessSpecStopTrigger Parameter**

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved										Type = 208										Length											
AccessSpecStopTrigger										OperationCountValue																					

3014
 3015 See Section 11.2.1.1.
 3016

3017 **16.2.5.1.2 AccessCommand Parameter**

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved										Type = 209										Length											
TagSpecParameter [See notes below]																															
OpSpecParameter (1-n) [See notes below]																															
Custom Parameter (0-n)																															

3018
 3019 **Notes**
 3020 TagSpecParameter is the air protocol specific tag spec parameter. For C1G2, it is C1G2TagSpec Parameter.
 3021
 3022 Each OpSpecParameter can be one of two types: Air protocol specific OpSpec (e.g., C1G2OpSpec
 3023 Parameter) or ClientRequestOpSpec Parameter.
 3024
 3025 See Section 11.2.1.2.

3026 **16.2.5.1.3 ClientRequestOpSpec Parameter**

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved										Type = 210										Length											
OpSpecID																															

3027
 3028 See Section 11.2.1.2.1.

3029 **16.2.5.1.3.1 ClientRequestResponse Parameter**

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved										Type = 211										Length											
AccessSpecID																															
EPCDataParameter																															
OpSpecParameter (0-n) [See notes below]																															

3031

- 3032 **Notes**
3033 Each OpSpecParameter is an Air protocol specific opspec (e.g., C1G2OpSpec Parameter).
3034
3035 See Section 11.2.2.

3036 16.2.6 Configuration Parameters

3037 16.2.6.1 LLRPConfigurationStateValue Parameter

3038

0										1									2												3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 217										Length																	
LLRPConfigurationStateValue																																

- 3039
3040 See section 12.2.1.

3041 16.2.6.2 Identification Parameter

0										1									2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 218										Length																	
IDType										ByteCount																						
Reader ID(Variable length)																																

- 3042
3043 See Section 12.2.2.

3044 16.2.6.3 GPOWriteData Parameter

0										1									2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 219										Length																	
GPO Port Number										W	Reserved																					

- 3045
3046 **Abbreviations**
3047 W – GPO Data
3048
3049 See Section 12.2.3.

3050 16.2.6.4 KeepaliveSpec Parameter

0										1									2											3							
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1						
Reserved					Type = 220										Length																						
KeepaliveTriggerType										TimeInterval																											
TimeInterval																																					

3051
 3052 See Section 12.2.4.

3053 **16.2.6.5 AntennaProperties Parameter**

0										1										2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved						Type = 221												Length														
C	Reserved						AntennaId												AntennaGain[15:8]													
AntennaGain[7:0]																																

3054
 3055 **Abbreviations**
 3056 C – Antenna connected
 3057
 3058 See Section 12.2.5.
 3059

3060 **16.2.6.6 AntennaConfiguration Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 222												Length													
						AntennaId																									
																		RFReceiver Parameter (0-1)													
																		RFTransmitter Parameter (0-1)													
																		AirProtocolInventoryCommandSettings Parameter (0-n)													

3061
 3062 **Notes:**
 3063 Each AirProtocolInventoryCommandSettingsParameter instance is an Air protocol specific Parameter (e.g.,
 3064 C1G2InventoryCommand Parameter).
 3065
 3066 See Section 12.2.6.
 3067

3068 **16.2.6.7 RFReceiver Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 223												Length													
						Receiver Sensitivity																									

3069
 3070 See Section 12.2.6.1.
 3071

3072 **16.2.6.8 RFTransmitter Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 224												Length													
						HopTableId						ChannelIndex																			
						TransmitPower																									

0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 238										Length																
R	I	P	A	C	R	F	L	T	S	Reserved																					
AirProtocolSpecificEPCMemorySelectorParameter (0-n) [See notes below]																															

3097 **Abbreviations**

3098

3099 R – EnableROSpecID

3100 I – EnableSpecIndex

3101 P – EnableInventoryParameterSpecID

3102 A – EnableAntennaID

3103 C – EnableChannelIndex

3104 R – EnablePeakRSSI

3105 F – EnableFirstSeenTimestamp

3106 L – EnableLastSeenTimestamp

3107 T – EnableTagSeenCount

3108 S – EnableAccessSpecID

3109

3110 **Notes:**

3111 Each instance of AirProtocolSpecificEPCMemorySelectorParameter is one of the air protocol specific selector parameters (e.g., C1G2EPCMemorySelector Parameter).

3112

3113 See section 13.2.1.1.

3114

3116 **16.2.7.2 AccessReportSpec Parameter**

0											1											2											3	1
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 239										Length																			
AccessReportTrigger																																		

3117

3118 See section 13.2.2.

3119 **16.2.7.3 TagReportData Parameter**

0											1											2											3	1
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 240										Length																			
EPCDataParameter [See notes below]																																		
ROSpecID Parameter (0-1)																																		
SpecIndex Parameter (0-1)																																		
InventoryParameterSpecID Parameter (0-1)																																		
AntennaID Parameter (0-1)																																		
PeakRSSI Parameter (0-1)																																		
ChannelIndex Parameter (0-1)																																		
FirstSeenTimestampUTC Parameter (0-1)																																		
FirstSeenTimestampUptime Parameter (0-1)																																		
LastSeenTimestampUTC Parameter (0-1)																																		
LastSeenTimestampUptime Parameter (0-1)																																		
TagSeenCount Parameter (0-1)																																		
AirProtocolTagDataParameter (0-n)[See Notes below]																																		
AccessSpecID Parameter (0-1)																																		

3146 **16.2.7.3.4 SpecIndex Parameter (TV-Encoding)**

0										1										2										3													
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1												
1	Type=14										SpecIndex																																

3147

3148 See Section 13.2.3.4.

3149 **16.2.7.3.5 InventoryParameterSpecID Parameter (TV-Encoding)**

0										1											2										3												
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1												
1	Type=10										InventoryParameterSpecId																																

3150

3151 See Section 13.2.3.5.

3152 **16.2.7.3.6 AntennaID Parameter (TV-Encoding)**

0										1											2										3												
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1												
1	Type=1										AntennaId																																

3153

3154 See Section 13.2.3.6.

3155 **16.2.7.3.7 PeakRSSI Parameter (TV-Encoding)**

0										1											2										3													
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1													
1	Type=6										PeakRSSI																																	

3156

3157 See Section 13.2.3.7.

3158 **16.2.7.3.8 ChannelIndex Parameter (TV-Encoding)**

0										1											2										3													
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1													
1	Type=7										ChannelIndex																																	

3159

3160 See Section 13.2.3.8.

3161 **16.2.7.3.9 FirstSeenTimestampUTC Parameter (TV-Encoding)**

0										1											2										3																
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																
1	Type=2										Microseconds [63:40]																																				
	Microseconds [39:8]																																														
	Microseconds[7:0]																																														

3162

3163 See Section 13.2.3.9.

3164 **16.2.7.3.10 FirstSeenTimestampUptime Parameter (TV-Encoding)**

0										1											2										3	
---	--	--	--	--	--	--	--	--	--	---	--	--	--	--	--	--	--	--	--	--	---	--	--	--	--	--	--	--	--	--	---	--

0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
1	Type=3							Microseconds[63:40]																								
Microseconds [39:8]																																
Microseconds[7:0]																																

3165

3166 See Section 13.2.3.10.

3167 **16.2.7.3.11 LastSeenTimestampUTC Parameter (TV-Encoding)**

0										1											2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
1	Type=4							Microseconds[63:40]																									
Microseconds [39:8]																																	
Microseconds[7:0]																																	

3168

3169 See Section 13.2.3.11.

3170 **16.2.7.3.12 LastSeenTimestampUptime Parameter (TV-Encoding)**

0										1											2										3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
1	Type=5							Microseconds[63:40]																										
Microseconds [39:8]																																		
Microseconds[7:0]																																		

3171

3172 See Section 13.2.3.12.

3173 **16.2.7.3.13 TagSeenCount Parameter (TV-Encoding)**

0										1											2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
1	Type=8							TagCount																								

3174

3175 See Section 13.2.3.13.

3176 **16.2.7.3.14 ClientRequestOpSpecResult Parameter (TV-Encoding)**

0										1											2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
1	Type=15							OpSpecID																								

3177

3178 See Section 13.2.3.14.

3179 **16.2.7.3.15 AccessSpecID Parameter (TV-Encoding)**

0										1											2										3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
1	Type=16							AccessSpecID[31:8]																										
AccessSpecID[7:0]																																		

3180

3181 See Section 13.2.3.15.

3182

3183

3184 16.2.7.4 RFSurveyReportData Parameter

3185

0										1										2													3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 242										Length																			
ROSpecID Parameter (0-1)																																		
SpecIndex Parameter (0-1)																																		
FrequencyRSSIlevelEntry Parameter (1-n)																																		
Custom Parameter (0-n)																																		

3186

3187 See Section 13.2.3.15.

3188

3189 16.2.7.4.1 FrequencyRSSIlevelEntry Parameter

3190

0										1										2												3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 243										Length																			
Frequency Bandwidth																																		
Average RSSI																Peak RSSI																		
TimestampParameter [See notes below]																																		

3191

3192 **Notes:**

3193 TimestampParameter: Either UTCTimestamp Parameter or UptimeParameter.

3194

3195 See section 13.2.4.1

3196

3197 16.2.7.5 ReaderEventNotificationSpec Parameter

3198

0										1										2												3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 244										Length																			
EventNotificationState Parameter(1-n)																																		

3199

3200 See Section 13.2.5.

3201

3202

3203 **16.2.7.5.1 EventNotificationState Parameter**

3204

0										1								2								3								
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved						Type = 245										Length																		
Event Type															S	Reserved																		

3205

3206 **Abbreviations:**

3207 S – NotificationState

3208

3209 See Section 13.2.5.1.

3210

3211 **16.2.7.6 ReaderEventNotificationData Parameter**

0										1								2								3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 246										Length															
TimestampParameter [See notes below]																															
HoppingEvent Parameter (0-1)																															
GPIEvent Parameter (0-1)																															
ROSpecEvent Parameter (0-1)																															
ReportBufferLevelWarningEvent Parameter (0-1)																															
ReportBufferOverflowErrorEvent Parameter (0-1)																															
ReaderExceptionEvent Parameter (0-1)																															
RFSurveyEvent Parameter (0-1)																															
AISpecEvent Parameter (0-1)																															
AntennaEvent Parameter (0-1)																															
ConnectionAttemptEvent Parameter (0-1)																															
ConnectionCloseEvent Parameter (0-1)																															
Custom Parameter (0-n)																															

3212

3213 **Notes:**

3214 TimestampParameter: Either UTCTimestamp Parameter or Uptime Parameter.

3215

3216 See section 13.2.6.

3217

3218 **16.2.7.6.1 HoppingEvent Parameter**

0										1								2								3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 247										Length															
HopTableID															NextChannelIndex																

3219

3220 See section 13.2.6.2.

3221

3222 **16.2.7.6.2 GPIEvent Parameter**

0										1											2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 248											Length																		
GPIPortNumber											E	Reserved																						

3223 **Abbreviations**

3224 E – GPIEvent

3225

3226 See section 13.2.6.3.

3227

3228 **16.2.7.6.3 ROSpecEvent Parameter**

0										1											2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 249											Length																		
EventType											ROSpecID[31:8]																							
ROSpecID[7:0]											PreemptingROSpecID[31:8]																							
PreemptingROSpecID[7:0]																																		

3229

3230 See section 13.2.6.4.

3231

3232 **16.2.7.6.4 ReportBufferLevelWarningEvent Parameter**

0										1											2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 250											Length																		
ReportBufferPercentageFull																																		

3233

3234 See section 13.2.6.5.

3235

3236 **16.2.7.6.5 ReportBufferOverflowErrorEvent Parameter**

0										1											2											3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1			
Reserved					Type = 251											Length																		

3237

3238 See section 13.2.6.6.

3239

3240 **16.2.7.6.6 ReaderExceptionEvent Parameter**

0										1											2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
Reserved					Type = 252											Length																	
Message String											ByteCount																						

0										1									2												3																	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																	
Reserved					Type = 255										Length																																	
Event Type					AntennaID																																											

3261
3262 See Section 13.2.6.10.
3263

3264 **16.2.7.6.10 ConnectionAttemptEvent Parameter**

0										1									2											3																	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1																
Reserved					Type = 256										Length																																
Status																																															

3265
3266 See Section 13.2.6.11.
3267

3268 **16.2.7.6.11 ConnectionCloseEvent Parameter**

0										1									2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 257										Length																

3269
3270 See Section 13.2.6.12.
3271

3272 **16.2.8 LLRP Error Parameters**

3273 **16.2.8.1 LLRPStatus Parameter**

3274

0										1									2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 287										Length																
Status Code										Error Description ByteCount																					
Error Description: Variable length UTF-8 String																															
FieldError Parameter (0-1)																															
ParameterError Parameter (0-1)																															

3275
3276 See Section 14.2.2.
3277

3278 **16.2.8.1.1 FieldError Parameter**

3279

0										1									2											3
---	--	--	--	--	--	--	--	--	--	---	--	--	--	--	--	--	--	--	---	--	--	--	--	--	--	--	--	--	--	---

0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
Reserved					Type = 288										Length																		
FieldNum										ErrorCode																							

3280

3281 See section 14.2.2.1.

3282

3283 **16.2.8.1.2 ParameterError Parameter**

3284

0										1											2											3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
Reserved					Type = 289										Length																		
ParameterType										ErrorCode																							
Field Error Parameter (0-1)																																	
Parameter Error Parameter (0-1)																																	

3285

3286 See Section 14.2.2.2.

3287

3288 **16.2.9 Custom Parameter**

0										1											2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
Reserved					Type=1023										Parameter Length																		
Vendor ID																Subtype																	
VendorParameter Value																																	

3289

3290 See Section 8.2.

3291

3292 **16.3 Air Protocol Specific Parameters**

3293 This section defines air protocol specific parameter encodings. There is a separate
 3294 subsection here for each air protocol defined by LLRP. See section 15, in the LLRP
 3295 abstract specification, for more information regarding air protocol specific parameters.

3296 **16.3.1 Class-1 Generation-2 (C1G2) Protocol Parameters**

3297 The Class-1 Generation-2 (C1G2) Air Protocol is specified by the EPCglobal Class-1
 3298 Generation-2 UHF RFID Protocol v1.1.0 specification.

3299 The following subsections specify LLRP air protocol specific parameter encodings.
 3300 These subsections are partitioned to correlate with subsections of section 16.2:

- 3301 - Capabilities Parameters
- 3302 - Reader Operations Parameters

3325 M– Spectral Mask Indicator
 3326 Mod – M value / Modulation
 3327 FLM – Forward Link Modulation
 3328 C – EPC HAG T&C Conformance
 3329
 3330 See section 15.2.1.1.2.1.
 3331

3332 **16.3.1.2 Reader Operations Parameters**

3333 This section of air protocol specific parameters corresponds to LLRP parameters
 3334 encodings specified in section 15.2.1.2.

3335 **16.3.1.2.1 C1G2InventoryCommand Parameter**

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 330										Length																
S	Reserved					C1G2Filter Parameter (0-n)																									
C1G2RFControl Parameter (0-1)																															
C1G2SingulationControl Parameter (0-1)																															
Custom Parameter (0-n)																															

3336
 3337 **Abbreviations**
 3338 S – TagInventoryStateAware
 3339
 3340 See Section 15.2.1.2.1
 3341

3342 **16.3.1.2.1.1 C1G2Filter Parameter**

0										1											2									3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type =331										Length																
T	Reserved					C1G2TagInventoryMask Parameter																									
C1G2TagInventoryStateAwareFilterAction Parameter (0-1)																															
C1G2TagInventoryStateUnawareFilterAction Parameter (0-1)																															

3343
 3344 See Section 15.2.1.2.1.1.
 3345

3346 **16.3.1.2.1.1.1 C1G2TagInventoryMask Parameter**

0										1											2									3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 332										Length																
MB	Reserved					Pointer[15:0]										MaskBitCount[15:8]															
MaskBitCount[7:0]					Tag Mask																										

3368

3369 **16.3.1.2.1.3.1 C1G2TagInventoryStateAwareSingulationAction Parameter**

0									1										2								3				
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 337															Length											
I	S	Reserved																													

3370
3371 See section 15.2.1.2.1.3.1.
3372

3373 **16.3.1.3 Access Operation Parameters**

3374 This section of air protocol specific parameters corresponds to LLRP parameters
3375 encodings specified in section 15.2.1.3.

3376 **16.3.1.3.1 C1G2TagSpec Parameter**

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 338															Length											
C1G2TargetTag Parameter																															
C1G2TargetTag Parameter (0-1)																															

3377
3378 See section 15.2.1.3.1.
3379

3380 **16.3.1.3.1.1 C1G2TargetTag Parameter**

0										1									2									3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1		
Reserved					Type = 339															Length													
MB	M	Resvd					Pointer															MaskBitCount[15:8]											
MaskBitCount[7:0]																																	
Tag Mask																																	
DataBitCount																																	
Tag Data																																	

3382
3383 **Abbreviations**
3384 M – Match.
3385
3386 See section 15.2.1.3.1.1.
3387

3388 **16.3.1.3.2 C1G2 OpSpecs**

3389 **16.3.1.3.2.1 C1G2Read Parameter**

3390

0										1									2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 341										Length																
OpSpecID										AccessPassword[31:16]																					
AccessPassword[15:0]										MB			Reserved						WordPointer[15:8]												
WordPointer[7:0]							WordCount																								

3391

3392 See section 15.2.1.3.2.2.

3393 **16.3.1.3.2.2 C1G2Write Parameter**

3394

0										1									2										3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 342										Length																	
OpSpecID										AccessPassword[31:16]																						
AccessPassword[15:0]										MB			Reserved						WordPointer[15:8]													
WordPointer[7:0]							WriteDataWordCount																									
Write Data																																

3395 See section 15.2.1.3.2.2.

3396

3397 **16.3.1.3.2.3 C1G2Kill Parameter**

0										1									2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved					Type = 343										Length																
OpSpecID										KillPassword[31:16]																					
KillPassword[15:0]																															

3398

3399 See section 15.2.1.3.2.3.

3400 **16.3.1.3.2.4 C1G2Lock Parameter**

3401

0										1									2										3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	
Reserved					Type = 344										Length																	
OpSpecID										AccessPassword[31:16]																						
AccessPassword[15:0]																																
C1G2LockPayload Parameter (1-n)																																

3402

3403 See section 15.2.1.3.2.4.
3404

3405 16.3.1.3.2.4.1 C1G2LockPayload Parameter

3406

0										1									2									3			
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 345										Length															
Privilege										DataField																					

3407

3408 See section 15.2.1.3.2.4.1.

3409

3410 16.3.1.3.2.5 C1G2BlockErase Parameter

3411

0										1									2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 346										Length															
OpSpecID										AccessPassword[31:16]																					
AccessPassword[15:0]										MB			Reserved						WordPointer[15:8]												
WordPointer[7:0]						WordCount																									

3412

3413 See section 16.3.1.3.2.5.

3414

3415 16.3.1.3.2.6 C1G2BlockWrite Parameter

3416

0										1									2										3		
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
Reserved						Type = 347										Length															
OpSpecID										AccessPassword[31:16]																					
AccessPassword[15:0]										MB			Reserved						WordPointer[15:8]												
WordPointer[7:0]						WriteDataWordCount																									
Write Data																															

3417

3418 See section 15.2.1.3.2.6.

3419

3420 16.3.1.4 Configuration Parameters

3421 This section of air protocol specific parameters corresponds to LLRP parameters
3422 specified in Section 12.2. The only air protocol specific parameter is the
3423 AirProtocolInventoryCommandSettings parameter in the AntennaConfiguration (Section
3424 12.2.6). The C1G2 specific InventoryCommand is already defined in Section 16.3.1.2.1.

3425

3426 **16.3.1.5 Reporting Parameters**

3427 This section of air protocol specific parameters corresponds to LLRP parameters
3428 encodings specified in section 15.2.1.5.

3429 **16.3.1.5.1 CIG2EPCMemorySelector Parameter**

3430

0										1										2														3								
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1											
Reserved										Type = 348										Length																						
C	P	Reserved																																								

3431
3432 **Abbreviations**

3433
3434 C – EnableCRC
3435 P – EnablePCBits

3436
3437 See section 15.2.1.5.1.
3438

3439 **16.3.1.5.2 CIG2PC Parameter (TV-Encoding)**

0										1																										3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1										
1	Type=12										PC-Bits																														

3440
3441 See section 15.2.1.5.2.

3442 **16.3.1.5.3 CIG2CRC Parameter (TV-Encoding)**

0										1																											3					
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1											
1	Type=11										CRC																															

3443
3444 See section 15.2.1.5.3.

3445 **16.3.1.5.4 CIG2SingulationDetails Parameter (TV-Encoding)**

0										1																												3						
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1													
1	Type=18										NumCollisionSlots										NumEmptySlots[15:8]																							
NumEmptySlots[7:0]																																												

3446
3447 See section 15.2.1.5.4.

3448 **16.3.1.5.5 CIG2 OpSpec Results**

3449 **16.3.1.5.5.1 CIG2ReadOpSpecResult Parameter**

0										1																												3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 349										Length																			
Result										OpSpecID										ReadDataWordCount[15:8]																			

ReadDataWordCount[7:0]										ReadData																													

3450

3451 See section 15.2.1.5.5.1.
3452

3453 16.3.1.5.5.2 C1G2WriteOpSpecResult Parameter

0										1										2										3									
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 350										Length																			
Result										OpSpecID										NumWordsWritten[15:8]																			
NumWordsWritten[7:0]																																							

3454

3455 See section 15.2.1.5.5.2.
3456

3457 16.3.1.5.5.3 C1G2KillOpSpecResult Parameter

0										1										2										3									
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 351										Length																			
Result										OpSpecID																													

3458

3459 See section 15.2.1.5.5.3.
3460

3461 16.3.1.5.5.4 C1G2LockOpSpecResult Parameter

0										1										2										3									
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 352										Length																			
Result										OpSpecID																													

3462

3463 See section 15.2.1.5.5.4.
3464

3465 16.3.1.5.5.5 C1G2BlockEraseOpSpecResult Parameter

0										1										2										3									
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1								
Reserved										Type = 353										Length																			
Result										OpSpecID																													

3466

3467 See section 15.2.1.5.5.5.

3468

3469 16.3.1.5.5.6 C1G2BlockWriteOpSpecResult Parameter

0										1																2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1						
Reserved							Type = 354										Length																				
Result							OpSpecID															NumWordsWritten[15:8]															
NumWordsWritten[7:0]																																					

3470

3471 See section 15.2.1.5.5.6.

3472 16.4 Listing of Message and Parameter Types

3473 This section lists the parameter and message types used in the binary encoding.

3474 Table 4: Message Listing

Message Name	Type
GET_READER_CAPABILITIES	1
GET_READER_CAPABILITIES_RESPONSE	11
ADD_ROSPEC	20
ADD_ROSPEC_RESPONSE	30
DELETE_ROSPEC	21
DELETE_ROSPEC_RESPONSE	31
START_ROSPEC	22
START_ROSPEC_RESPONSE	32
STOP_ROSPEC	23
STOP_ROSPEC_RESPONSE	33
ENABLE_ROSPEC	24
ENABLE_ROSPEC_RESPONSE	34
DISABLE_ROSPEC	25
DISABLE_ROSPEC_RESPONSE	35
GET_ROSPECS	26
GET_ROSPECS_RESPONSE	36
ADD_ACCESSSPEC	40
ADD_ACCESSSPEC_RESPONSE	50
DELETE_ACCESSSPEC	41
DELETE_ACCESSSPEC_RESPONSE	51
ENABLE_ACCESSSPEC	42
ENABLE_ACCESSSPEC_RESPONSE	52

DISABLE_ACCESSSPEC	43
DISABLE_ACCESSSPEC_RESPONSE	53
GET_ACCESSSPECS	44
GET_ACCESSSPECS_RESPONSE	54
CLIENT_REQUEST_OP	45
CLIENT_REQUEST_OP_RESPONSE	55
GET_REPORT	60
RO_ACCESS_REPORT	61
KEEPALIVE	62
KEEPALIVE_ACK	72
READER_EVENT_NOTIFICATION	63
ENABLE_EVENTS_AND_REPORTS	64
ERROR_MESSAGE	100
GET_READER_CONFIG	2
GET_READER_CONFIG_RESPONSE	12
SET_READER_CONFIG	3
SET_READER_CONFIG_RESPONSE	13
CLOSE_CONNECTION	14
CLOSE_CONNECTION_RESPONSE	4
CUSTOM_MESSAGE	1023

3475

3476

Table 5: Parameter Listing

Parameter Name	Type	TV-Encoded?
UTCTimeStamp	128	
Uptime	129	
GeneralDeviceCapabilities	137	
ReceiveSensitivityTableEntry	139	
PerAntennaAirProtocol	140	
GPIOCapabilities	141	
LLRPCapabilities	142	
RegulatoryCapabilities	143	
UHFBandCapabilities	144	
TransmitPowerLevelTableEntry	145	
FrequencyInformation	146	
FrequencyHopTable	147	

FixedFrequencyTable	148	
PerAntennaReceiveSensitivityRange	149	
ROSpec	177	
ROBoundarySpec	178	
ROSpecStartTrigger	179	
PeriodicTriggerValue	180	
GPITriggerValue	181	
ROSpecStopTrigger	182	
AI Spec	183	
AI SpecStopTrigger	184	
TagObservationTrigger	185	
InventoryParameterSpec	186	
RFSurveySpec	187	
RFSurveySpecStopTrigger	188	
AccessSpec	207	
AccessSpecStopTrigger	208	
AccessCommand	209	
ClientRequestOpSpec	210	
ClientRequestResponse	211	
LLRPConfigurationStateValue	217	
Identification	218	
GPOWriteData	219	
KeepaliveSpec	220	
AntennaProperties	221	
AntennaConfiguration	222	
RFReceiver	223	
RFTransmitter	224	
GPISPortCurrentState	225	
EventsAndReports	226	
ROReportSpec	237	
TagReportContentSelector	238	
AccessReportSpec	239	
TagReportData	240	
EPCData	241	
EPC-96	13	X

ROSpecID	9	X
SpecIndex	14	X
InventoryParameterSpecID	10	X
AntennaID	1	X
PeakRSSI	6	X
ChannelIndex	7	X
FirstSeenTimestampUTC	2	X
FirstSeenTimestampUptime	3	X
LastSeenTimestampUTC	4	X
LastSeenTimestampUptime	5	X
TagSeenCount	8	X
ClientRequestOpSpecResult	15	X
AccessSpecID	16	X
RFSurveyReportData	242	
FrequencyRSSILevelEntry	243	
ReaderEventNotificationSpec	244	
EventNotificationState	245	
ReaderEventNotificationData	246	
HoppingEvent	247	
GPIEvent	248	
ROSpecEvent	249	
ReportBufferLevelWarningEvent	250	
ReportBufferOverflowErrorEvent	251	
ReaderExceptionEvent	252	
OpSpecID	17	X
RFSurveyEvent	253	
AISpecEvent	254	
AntennaEvent	255	
ConnectionAttemptEvent	256	
ConnectionCloseEvent	257	
LLRPStatus	287	
FieldError	288	
ParameterError	289	
Custom	1023	
C1G2LLRPCapabilities	327	

UHFC1G2RFModeTable	328	
UHFC1G2RFModeTableEntry	329	
C1G2InventoryCommand	330	
C1G2Filter	331	
C1G2TagInventoryMask	332	
C1G2TagInventoryStateAwareFilterAction	333	
C1G2TagInventoryStateUnawareFilterAction	334	
C1G2RFControl	335	
C1G2SingulationControl	336	
C1G2TagInventoryStateAwareSingulationAction	337	
C1G2TagSpec	338	
C1G2TargetTag	339	
C1G2Read	341	
C1G2Write	342	
C1G2Kill	343	
C1G2Lock	344	
C1G2LockPayload	345	
C1G2BlockErase	346	
C1G2BlockWrite	347	
C1G2EPCMemorySelector	348	
C1G2PC	12	X
C1G2CRC	11	X
C1G2SingulationDetails	18	X
C1G2ReadOpSpecResult	349	
C1G2WriteOpSpecResult	350	
C1G2KillOpSpecResult	351	
C1G2LockOpSpecResult	352	
C1G2BlockEraseOpSpecResult	353	
C1G2BlockWriteOpSpecResult	354	

3477

3478

3479 **17 Transmitter Behavior of a Reader**

3480 A Reader SHALL enable its transmitter only under the following conditions:

- 3481
 - When an ROSpec is in the active state.

- 3482 • Between a GET/SET_READER_CONFIG containing a RequestedData field with
3483 value 0 (All) or 2 (Antenna Properties) and the corresponding
3484 GET/SET_READER_CONFIG_RESPONSE.

3485 **18 Connection and Transport**

3486 The Reader SHALL maintain LLRP configuration state during an LLRP connection.

3487 The Reader MAY maintain configuration or data state when a connection fails, or across
3488 LLRP connections.

3489 **18.1 TCP Transport**

3490 LLRP end-to-end communications based on TCP/IP connections SHALL be
3491 implemented in accordance with the requirements specified in this section. These
3492 requirements are defined as the LLRP *TCP Transport*.

3493 Readers SHALL be able to both initiate and accept LLRP TCP connections. Readers
3494 MAY be configured such that, at any given time, they only either initiate or accept an
3495 LLRP connection. If so, the mechanism for configuring a Reader to either initiate or
3496 accept an LLRP connection is not specified by LLRP.

3497 Clients SHALL be able both to initiate and accept LLRP TCP connections. Clients MAY
3498 be configured such that, at any given time, they only either initiate or accept an LLRP
3499 connection. If so, the mechanism for configuring a Client to either initiate or accept an
3500 LLRP connection is not specified by LLRP.

3501 For Readers and Clients, that are configured to accept connections, the default port is
3502 5084, as established by IANA (see <http://www.iana.org/assignments/port-numbers>), but
3503 other ports can be used.

3504 When a TCP connection (called the *established connection*) is initiated by either the
3505 Reader or the Client, the Reader SHALL reply with a status report message before
3506 communicating any other information. This report's status parameter,
3507 ConnectionAttemptEvent, SHALL be set to indicate connection success (see section
3508 13.2.6.11). No other parameters may be contained within this message. The Client
3509 SHALL not send any information to the Reader until this status report message is
3510 received.

3511 Readers SHALL limit communications to a single established connection on a Reader IP
3512 address and TCP port. Readers MAY momentarily accept TCP connections (called
3513 *momentary connections*) in addition to the Reader's one established connection on a
3514 Reader IP address and TCP port. If a momentary connection is accepted, then the Reader
3515 SHALL send a status report message on the Reader's established connection. This
3516 report's status parameter, ConnectionAttemptEvent, SHALL be set to indicate that
3517 another connection was attempted (see section 13.2.6.11). If this action results in a TCP
3518 error, then the Reader MAY close the established connection and then treat the
3519 momentary connection as a new established connection. In this case, the Reader SHALL
3520 reply with a status report message on the newly created established connection, as
3521 specified above, indicating connection success.


3522 If the established connection is not closed, then the Reader SHALL reply on the
 3523 momentary connection with a status report message. This report's status parameter,
 3524 ConnectionAttemptEvent, SHALL be set to indicate connection failure. The Reader
 3525 SHALL use the appropriate connection failed status value as defined in section 13.2.6.11.
 3526 Once the connection failure message is sent, the Reader SHALL close the momentary
 3527 connection.

3528 The following UML sequence diagrams illustrate different scenarios of a Reader and
 3529 Client initiating TCP connections.

3530

3531

Reader Initiated Connection
(normal case)




3532

3533 **Figure 14: Reader Initiated Connection (Normal)**

3534

Reader Initiated Connection
(exception case #1)



3535

3536 **Figure 15: Reader Initiated Connection (Exception)**


3537

3538

3539

3540


Client Initiated Connection
(normal case)



3541

3542 **Figure 16: Client Initiated Connection (Normal)**


3543



3544

3545

Figure 17: Client Initiated Connection (Exception #1)




3546

3547

3548

Figure 18: Client Initiated Connection (exception #2)


Client Initiated Connection
(exception case #3: Reader Refuses Another Connect)



3549
3550
3551
3552
3553


Figure 19: Client Initiated Connection (exception #3)

Client Initiated Connection
(exception case #4: New Established Connection)




3554
3555
3556

Figure 20: Client Initiated Connection (exception #4)




3557
3558
3559

Figure 21: Client Initiated Connection (exception #5)



3560
3561
3562

Figure 22: Reader Initiated Close




3563

3564

Figure 23: Client Initiated Close (Normal)

3565



3566

3567

Figure 24: Client Initiated Close (Exception)

3568 **18.2 Security in TCP Transport**

3569 This section describes the security aspects for LLRP connections running over a TCP
3570 transport binding. Refer to the previous section for any TCP connection related
3571 requirements.

3572 **18.2.1 Normative Section**

3573 The LLRP Client and LLRP Reader MAY implement TLS. The LLRP Client and LLRP
3574 Reader MAY use a different port for TLS LLRP connections and non-TLS LLRP
3575 connections.

3576 The LLRP Client MAY be capable of operating in a mixed deployment, where it
3577 communicates using TLS with a set of Readers and just plain TCP with a different set of
3578 Readers. In such mixed deployments, the LLRP Client MAY use different ports for TLS
3579 and non-TLS LLRP connections. The default port for TLS-LLRP connections is 5085, as
3580 established by IANA (see <http://www.iana.org/assignments/port-numbers>), but other
3581 ports can be used.

3582 The LLRP endpoint that initiates the TLS connection MAY be the same LLRP endpoint
3583 that initiated the underlying TCP connection.

3584 The LLRP endpoints SHALL use at least TLS1.0 [TLS10] and are recommended to use
3585 TLS1.1 [TLS11].

3586 If the Reader or Client uses X.509 certificates[X509] for authentication, the certificates
3587 SHALL be compliant with the EPCGlobal Security2 working group specification
3588 [SEC2].

3589 **18.2.2 Informative Section**

3590 **18.2.2.1 Overview of TLS**

3591 The TLS protocol provides privacy and data integrity between two authenticated
3592 communicating applications. TLS is a light weight transport protocol and has been
3593 proven to be reliable and secure by the use of millions of real users for many years. The
3594 strength of TLS can be chosen by the cipher suite negotiated by the two communicating
3595 parties through a flexible mechanism during the handshaking.

3596 TLS is particularly useful for TCP based applications. First, a TLS client initiates a
3597 connection with the TLS server. After a TLS connection is established, the applications
3598 can use the transport connection like an ordinary TCP connection, while having the added
3599 value that the data is protected and that both parties are mutually authenticated.

3600 For interoperability, a TLS client and server have to implement at least one common
3601 cipher suite. The credentials required for mutual authentication depend on the suite
3602 negotiated. For example, if the negotiated suite is using RSA for key exchange, then the
3603 server must own a server certificate (with private key) for RSA encryption purposes
3604 while the client must have a client certificate (with private key) for RSA signing
3605 purposes. Further, each side must have the root Certificate Authority (CA) certificates to

3606 verify the certificates presented by the peers. TLS also requires each party to present the
3607 CA certificates (except the root) that directly and indirectly issue the certificate.

3608 **18.2.2.2 Threat Analysis for LLRP**

3609 With TLS being used for Reader and Client communication, the following protections are
3610 provided, assuming that the credentials for the TLS client and server are not stolen:

- 3611 • Readers only talk to authorized LLRP Clients;
- 3612 • LLRP Clients only talk to authorized Readers;
- 3613 • No other party can read the LLRP messages (privacy protection) or inject/modify
3614 messages without being detected (integrity protection).

3615 Note that the strength of protection depends on the negotiated cipher suite.

3616 **18.2.2.3 Configuration Elements for TLS**

3617 In order to use TLS for LLRP, the following information has to be configured and/or
3618 provisioned at each entity (Reader or Client):

- 3619 • **TLS enabled:** Yes or no. If TLS is not enabled, the rest of the information need
3620 not be configured and the LLRP endpoint (Reader or Client) SHALL use TCP
3621 directly.
- 3622 • **TLS role:** Whether the LLRP endpoint is playing the TLS client or the TLS
3623 server role. A TLS client initiates a TCP connection to jump start TLS
3624 handshaking. A TLS server passively listens on the TCP server port.
- 3625 • **Preferred list of cipher suites:** A TLS client proposes the list of cipher suites to
3626 the TLS server during TLS handshaking. The TLS server will pick one suite from
3627 the proposed list if it is also in the preferred list maintained by the server. In TLS,
3628 the order of suites in the proposed list has no significance. Also, it is up to the
3629 server's local policy to select when there are multiple choices.
- 3630 • **Certificates and private keys:** A TLS server needs a server certificate (with
3631 private key) for TLS server authentication. A TLS client needs a client certificate
3632 (with private key) for TLS client authentication. In each case, all the CA
3633 certificates (except the root) in the chain have to be available.
- 3634 • **Root CA certificates:** A TLS server needs to maintain the root CA certificate of
3635 the client certificate. This is used for verifying client certificates. A TLS client
3636 needs to maintain the root CA certificate of the server certificate. This is used for
3637 verifying server certificates.
- 3638 • **List of authorized devices:** Each TLS server MAY have a list of authorized TLS
3639 clients that can connect to it. Likewise, each TLS client MAY have a list of
3640 authorized TLS servers that it can connect to.

3641

3642 The configuration and/or provisioning of a LLRP endpoint is out of the scope of TLS and
3643 LLRP. Provisioning is important but does not affect the interoperability of LLRP.
3644 Vendors should have the flexibility to choose the most cost-effective ways (for
3645 provisioning and protecting provisioned credentials) based on designs, available
3646 technologies, potential threats, security requirements, and so on. This is a topic that
3647 should be addressed in DCI.

3648 **18.2.2.4 Why different TLS server port?**

3649 It is recommended that the TLS server should listen to a TCP port different from that for
3650 non-TLS mode for the following reasons:

- 3651 • If one of the endpoints has to be deployed behind firewalls, IT managers are
3652 more willing to open a port they know only TLS traffic can pass through.
- 3653 • Without using a different port, a non-TLS server may be confused by the TLS
3654 Client-Hello handshaking message.
- 3655 • Without using a different port, a TLS server may be confused by the LLRP
3656 application message (non-TLS handshaking message).
- 3657 • Without using a different port, for each new TCP connection, a server in a mixed
3658 environment (TLS and non-TLS) may have to wait a few moments to see if a
3659 Client-Hello message ever arrives from the client before it can conclude whether
3660 it is a TLS connection or not.
- 3661 • Without using a different port, it is potentially harder to implement a hybrid
3662 server if the server relies on third-party libraries for handling TLS. This is
3663 because the server application has to read the first message from the client to
3664 know if it is a TLS connection. It may be difficult for the TLS library to take over
3665 a connection after the TLS Client-Hello message has been consumed.
3666


3667 However, if a deployment in totality is only TLS or only non-TLS, the LLRP endpoint
3668 can be configured only as a TLS server or non-TLS server exclusively, then there should
3669 be no problem using the same port, as long as a non-TLS server can ignore TLS
3670 handshaking messages from a TLS client and as long as a TLS server can ignore non-
3671 TLS handshaking messages from a non-TLS client.

3672 **19 (Informative) Object Model**

3673 The Object Model (OM) presented in this section illustrates the data structures inherent in
3674 the LLRP specification and further described in section 5. These OM diagrams are based
3675 upon Unified Modeling Language (UML) notation (see www.uml.org). There are two
3676 kinds of LLRP data structures: 1) *messages* and 2) *data parameters*. Messages can be
3677 composed of data parameters. Data parameters can be further composed of other data
3678 parameters. A simple data element (i.e., a data element with no subcomponents) is called
3679 a *data field*.

3680 In the OM, both kinds of data structures are represented by UML class diagrams. Data
3681 fields are represented as class attributes.

3682 A UML class is defined as a collection of objects with common structure, common
3683 relationships, etc. A UML class is illustrated as a rectangle partitioned into three
3684 compartments as follows:




3685

3686 The OM is used only to describe structure and therefore the *Operations* compartment is
 3687 left empty for all OM classes.

3688 There are three class relationship notations used in the OM:

3689 - Association with one-way navigation.

3690




3691

3692 This notation represents that one class includes a reference to another class (the
 3693 arrowhead side). LLRP data structures reference each other via an identifier (e.g.,
 3694 ROSpecID).

3695 A number or a range of numbers (e.g., 0..1) can appear on either side of the line.
 3696 This is the multiplicity of the relationship (e.g., the number of instances of one
 3697 class related to one instance of the other class). If no number appears on a side of
 3698 the line, then a one is implied.

3699 - Aggregation.

3700



3701

3702 This notation represents that one class (the diamond side) includes another class
 3703 embedded within it.

3704 A number or a range of numbers (e.g., 0..1) can appear on either side of the line.
 3705 This is the multiplicity of the relationship (e.g., the number of instances of one
 3706 class related to one instance of the other class). If no number appears on a side of
 3707 the line, then a one is implied.


3708 - Inheritance.

3709



3710 This notation represents that one class is a superclass of another class known as
 3711 the base class (the arrowhead side). A superclass includes all attributes and
 3712 relationships of the base class plus additional features.


3713 **19.1 Capabilities**



3714
3715


Figure 25: Capabilities

3716 **19.2 Configuration**



3717

3718 **Figure 26: Configuration**




3719

3720


Figure 27: Configuration Commands

3721 **19.3 ROSpec**



3722


3723 **Figure 28: RO Commands**




3724

3725 **Figure 29: ROSpec**

3726 **19.4 AccessSpec**




3727
3728 **Figure 30: Access Commands**




3729
3730 **Figure 31: AccessSpec**

3731 **19.5 C1G2 Parameters**



3732


3733 **Figure 32: C1G2 Parameters**



3734

3735 **Figure 33: C1G2 Inventory Command**


3736



3737


3738 Figure 34: C1G2 AccessSpec

3739 **19.6 Reporting and Notification**



3740


3741 Figure 35: Reporting and Notification



3742

3743


Figure 36: TagReportData



3744

3745

Figure 37: RfSurveyReportData




3746

3747

3748

Figure 38: Reader Event Notification Data

3749 **19.7 General**



3750

3751 **Figure 39: General Data**

3752 **20 (Informative) TCP Keepalives**

3753 The TCP specification doesn't specify any specific handling of idle connections, where
 3754 there is no data being transmitted by either end for a prolonged period of time. However,
 3755 in some TCP implementations, there is an option called TCP-keepalive which may be
 3756 turned on. If turned on, TCP-keepalive packets are sent only during periods of inactivity,
 3757 on a configurable interval. If the connection is still valid, the other end responds with a
 3758 segment containing an ack. If the connection is not valid the other end will reply with a
 3759 connection reset (RST) and the connection is closed by this end.

3760 Due to events like network failures, or Client failures, half connections may remain at the
 3761 Reader because the TCP connection was not cleanly terminated. If the Reader doesn't
 3762 implement TCP-keepalive, the only way to recover (i.e., reconnect to the Reader) may be
 3763 to reboot the Reader.

3764 However, there are Readers for which intermittent connectivity may be a normal mode of
 3765 operation – e.g., mobile Readers, handheld Readers. When connectivity is lost for these
 3766 devices, the use of TCP-keepalive acts negatively and closes the TCP session
 3767 prematurely before the TCP session would have timed out. If keepalives were not used,
 3768 the mobile Reader would just start sending LLRP messages as soon as the link layer is re-
 3769 established without requiring a re-establishment of the TCP session as long as the TCP
 3770 session did not timeout.

3771 **21 (Informative) References**

- 3772 [ISODir2] ISO, "Rules for the structure and drafting of International Standards (ISO/IEC
3773 Directives, Part 2, 2001, 4th edition)," July 2002.
- 3774 [C1G2] Class 1 Generation 2 UHF Air Interface Protocol Standard Version 1.0.9
3775 [http://www.epcglobalinc.org/standards_technology/EPCglobal2UHFRFIDProtocolV1091](http://www.epcglobalinc.org/standards_technology/EPCglobal2UHFRFIDProtocolV109122005.pdf)
3776 [22005.pdf](http://www.epcglobalinc.org/standards_technology/EPCglobal2UHFRFIDProtocolV109122005.pdf)
- 3777 [ALE 1.0] EPCglobal Application Level Events (ALE) 1.0 Specification
3778 [http://www.epcglobalinc.org/standards_technology/EPCglobal_ApplicationALE_Specifi](http://www.epcglobalinc.org/standards_technology/EPCglobal_ApplicationALE_Specification_v112-2005.pdf)
3779 [cation_v112-2005.pdf](http://www.epcglobalinc.org/standards_technology/EPCglobal_ApplicationALE_Specification_v112-2005.pdf)
- 3780 [Class0] 900 MHz Class 0 Radio Frequency (RF) Identification Tag Specification,
3781 http://www.epcglobalinc.org/standards_technology/Secure/v1.0/UHF-class0.pdf
- 3782 [Class1] 860MHz -- 930 MHz Class 1 Radio Frequency (RF) Identification Tag Radio
3783 Frequency & Logical Communication Interface Specification.,
3784 http://www.epcglobalinc.org/standards_technology/Secure/v1.0/UHF-class1.pdf
- 3785 [ARC] EPCglobal Architecture Framework 1.0
3786 http://www.epcglobalinc.org/standards_technology/Final-epcglobal-arch-20050701.pdf
- 3787 [ISO3166] ISO, "Codes for the Representation of Names of Countries".
3788 <http://www.iso.org/iso/en/prods-services/iso3166ma/index.html>
- 3789 [UTC] IETF RFC 3339, "Date and Time on the Internet: Timestamps", July 2002.
3790 <http://www.ietf.org/rfc/rfc3339.txt>
- 3791 [EUI64] "Guidelines For 64-bit Global Identifier (EUI-64)",
3792 <http://standards.ieee.org/db/oui/tutorials/EUI64.html>
- 3793 [TLS11] IETF RFC 4346, "The Transport Layer Security (TLS) Protocol Version 1.1".
3794 <http://www.ietf.org/rfc/rfc4346.txt>
- 3795 [TLS10] IETF RFC 2246, "The TLS Protocol Version 1.0",
3796 <http://www.ietf.org/rfc/rfc2246.txt>
- 3797 [X509] ITU-T Recommendation X.509 (1997 E): Information Technology - Open
3798 Systems Interconnection - "The Directory Authentication Framework". 1988.
- 3799 [SEC2] EPCGlobal Certificate Profile,
3800 [http://www.epcglobalinc.org/standards_technology/SAG%20Security%20Cert%20Profil](http://www.epcglobalinc.org/standards_technology/SAG%20Security%20Cert%20Profile%20March%208%202006.pdf)
3801 [e%20March%208%202006.pdf](http://www.epcglobalinc.org/standards_technology/SAG%20Security%20Cert%20Profile%20March%208%202006.pdf)
- 3802 [UTF8] IETF RFC 3629, "UTF-8, a transformation format of ISO 10646", November
3803 2003. See also Annex D of ISO 10646-1:2000. <http://www.ietf.org/rfc/rfc3629.txt>
- 3804 [HK] OFTA 1049,
3805 [http://www.ofta.gov.hk/en/standards/hktaspec/hkta1049.pdf#search=%22OFTA%201049](http://www.ofta.gov.hk/en/standards/hktaspec/hkta1049.pdf#search=%22OFTA%201049%22)
3806 [%22](http://www.ofta.gov.hk/en/standards/hktaspec/hkta1049.pdf#search=%22OFTA%201049%22)

3807 [TW] DGT LP0002,
3808 <http://www.dgt.gov.tw/English/Type-approval/8.4/LP0002/LP0002-940324.pdf>
3809 [JPN] ARIB STD T89, http://www.arib.or.jp/english/html/overview/st_j.html
3810 [KOR] MIC Article 5-2, (Radio Equipment for RFID/USN): Technical Requirements
3811 for the radio equipment for passive RFID using the frequency range of 908.5~914MHz.
3812

3813 **22 Acknowledgement of Contributors and Companies**
 3814 **Opt'd-in during the Creation of this Standard**
 3815 **(Informative)**
 3816

3817 Disclaimer

3818 *Whilst every effort has been made to ensure that this document and the*
 3819 *information contained herein are correct, EPCglobal and any other party involved*
 3820 *in the creation of the document hereby state that the document is provided on an*
 3821 *“as is” basis without warranty, either expressed or implied, including but not*
 3822 *limited to any warranty that the use of the information herein with not infringe any*
 3823 *rights, of accuracy or fitness for purpose, and hereby disclaim any liability, direct*
 3824 *or indirect, for damages or loss relating to the use of the document.*

3825

3826 Below is a list of more active participants and contributors in the development of
 3827 LLRP 1.0. This list does not acknowledge those who only monitored the process
 3828 or those who chose not to have their name listed here. Active participants status
 3829 was granted to those who generated emails, attended face-to-face meetings and
 3830 conference calls that were associated with the development of this Standard.

3831

First Name	Last Name	Company	Notable Role
Dave	Husak	Reva Systems	Co-Chair
Rob	Buck	Intermec	Co-Chair
Pattabhiraman	Krishna	Reva Systems	Editor
Mark	Frey	EPCglobal Inc.	Facilitator for WG
Software Team at Impinj		Impinj	Minutes Recorder
Marc	Horowitz	BEA Systems	
Suresh	Bhaskaran	Intelleflex	
Daniel	Paley	Tagent Corp.	
Bud	Biswas	Polaris Networks	
Bob	O'Hara	Cisco	
Daniel	Bowman	Kimberly-Clark Corp	
Margaret	Wasserman	ThingMagic, LLC	
Arthur	Howarth	Cisco	
Richard	Bach	GlobeRanger	
Rick	Schuessler	Symbol Tech./Motorola	

Howard	Kapustein	Manhattan Associates	
David	Missimer	Sirit	
Darrel	Pinson	Symbol Technologies, Inc.	
Matt	Poduska	Intermec	
Steve	Lockhart	Sirit	
David	Lavin	IBM	
Lynn	Hingst	Intermec	
John	Walter	Intermec	
Soumya	Roy chowdhury	Polaris Networks	
Martin	Jackson	Wal-Mart	
Steve	Lin	Sirit	
Bryan	Tracey	GlobeRanger	
Scott	de Deug	IBM	
Ted	Osinski	MET Labs	
Scott	Barvick	Reva Systems	
Manpreet	Singh	Symbol Technologies, Inc.	
Heena	Nandu	Intelleflex	
Gerhard	Gangl	7iD (formerly EOSS GmbH)	
Bill	Bares	Intelleflex	
Jim	Sykes	Savi Networks	
Sudhir	Hasbe	Sirit	
Albert	Lin	WJ Co.	
Shigeya	Suzuki	Auto-ID Labs - Japan	
Gay	Whitney	EPCglobal Inc.	
Jim	Reed	MET Labs	
Matthew	Harmon	Q.E.D. Systems	
Ricardo	Labiaga	Sun Microsystems	
Mark	Richardson	ThingMagic, LLC	
David	Nesbitt	Vue Technology	
Roger	Stewart	Applied Wireless (AWID)	
Yukiko	Yumoto	Auto Id Lab Japan	
Abel	Sanchez	Auto-ID Labs - MIT	
John	Williams	Auto-ID Labs - MIT	

Mark	Sompel	AWID	
Ken	Traub	BEA Systems	
Matt	Robshaw	France Telecom	
Wayne	Liu	Impinj	
Tareef	Al-Mahdawi	Intelleflex	
Joe	Kubler	Intermec	
John	Walter	Intermec	
Peter	Anderla	KCC	
John	Boulas	KCC	
John	Anderla	KCC	
Moon Suk	Kim	Metarights	
Chang Yeol	Lee	Metarights	
Jens	Kungl	Metro	
Isao	Kimata	NEC Corporation	
Satoshi	Kinoshita	NEC Corporation	
Hiroki	Tagato	NEC Corporation	
Sergio	Lobo	NXP Semiconductors	
Gregory	Grisco	Oracle Corporation	
Jahangir	Nakra	Procter & Gamble	
Trong	Le	Psion Teklogix Inc.	
Craig	Harmon	Q.E.D. Systems	
Peter	Spreadborough	Reva Systems	
Sudhir	Hasbe	Samsys	
Stephan	Haller	SAP	
Steve	Winkler	SAP	
Sengu	Elango	Savi	
Neal	Herman	Savi	
Don	Ahn	Savi Technology	
L. Julia	Zhu	Savi Technology	
Pankaj	Shukla	Symbol	
Jong	Park	Tibco	
Keith	Rider	Tyco / ADT	
Bob	Sawdye	Tyco / ADT	
David	Harty	VeriSign	
Richard	Campero	Vue Technology	

3833

3834 The following list in corporate alphabetical order contains all companies that were
3835 opt'd-in to the Reader Operations Working Group and have signed the
3836 EPCglobal IP Policy.

3837

Company
(ETRI) Electronics and Telecommunications Research Institute
7iD (formerly EOSS GmbH)
Accenture
Acer Cybercenter Service Inc.
Altria Group, Inc./Kraft Foods
Applied Wireless (AWID)
Ark Tech Ltd
Auto-ID Labs - Cambridge
Auto-ID Labs - Japan
Auto-ID Labs - MIT
BEA Systems
Blackbay Ltd.
CAEN
Cisco
Convergence Sys Ltd
Dai Nippon Printing
Denso Wave Inc
ECO, Inc.
EPCglobal Inc.
FEIG Electronic
France Telecom
Fujitsu Ltd
GlobeRanger
GS1 Australia EAN
GS1 Germany (CCG)
GS1 Hong Kong
GS1 Japan
GS1 South Korea
GS1 Taiwan (EAN)

GS1 US
IBM
Impinj
Infineon Technologies NA Corp
Institute for Information Industry
Intelleflex
Intermec
Internet Initiative Japan, Inc.
Johnson & Johnson
Kimberly-Clark Corp
KL-NET
Korea Computer Servs, Ltd
LIT (Research Ctr for Logistics Info Tech)
Loftware, Inc.
Manhattan Associates
MET Labs
Metarights
Metro
Microelectronics Technology, Inc.
Mstar Semiconductor
NCR
NEC Corporation
NXP Semiconductors
OatSystems
ODIN Technologies
Omron
Oracle Corporation
Panda Int'l Transp Ltd
Pango Networks, Inc.
Paxar
PepsiCo
Polaris Networks
Procter & Gamble
Psion Teklogix Inc.
Q.E.D. Systems

Raining Data Corporation
RetailTech
Reva Systems
RFIP Ltd. (formerly Radio Freq Ident Ctr)
RFXCEL Corp
SAP
Savi Technology
Sirit
SOFTBANK TELECOM Corp. (Japan)
Supply Insight, Inc.
SyGade Solutions
Symbol Technologies, Inc.
T3C Incorporated
Tagent Corporation
TagSys
TEGO, Inc.
ThingMagic, LLC
Tibco
Toppan Printing Co
Toray International, Inc.
Tyco / ADT
Ussen Limited Company
VeriSign
Vocollect
Vue Technology
Wal-Mart
Wish Unity
Yuen Foong Yu Paper

3838

3839